			WORK INSTRUCTION	Effectivity Date:	May 05, 2022						
		Process Name/Title:	TAPING ASSEMBLY F	Validity Date:	n/a						
		Model Code/Part Number:	724W / 7H0352W7020C Customer:	Document No.:	WI-ENG-PDE-477						
		Purpose:	PROTOTYPE PRE-LAUNCH	MASSPRO	Revision No.:	1 Page No.: 1 of 3					
PARTS:	PARTS: 1. Assy parts: Black vinyl tube ø5 L=149±3mm; Black tape [1pc.]										
NO.	F	PROCESS NAME	WORK PROCEDURE/ ILL	TOOLS/PPE	QUALITY POINTERS						
1	P1	∑ Table Lay-out	Table Lay-out Black viny Ø5 L=149: Assy parts Assy parts	Mary 18 500	Safety Instruction Be sure to wear prescribed personal protective equipment during operation (gloves, finger cots, etc.) Housekeeping 1. Maintain and always practice 5's. 2. Personal things on the workplace is prohibited. Keep it in your locker. Alert level For any trouble, inform the Assembly Assistant Supervisor or Line Leader for immediate corrective action.	No missing parts/tools No excess parts/tools					
	· '		Revision History		Prepared by Re	eviewed by Approved by					
05/05/22 1	Change do	ocument purpose from pre-launch to	masspro. Additional table lavout.	M. Catapang J. Loterte C. Villanueva A.	Arañes Arañes (M Till CM					
04/19/22 0	Initial issu				· · · · · · · · · · · · · · · · · · ·	J. Loterte C. Villanueva A. Arañes					
Eff. Date Rev. No			Details of Change			19, 2022					

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

NBC (Philippines)

MASTER COF

MASTER COPY

DCC Stamp



	Effectivity Date:	May 05, 2022								
Process Name/Title: TAPING ASSEMBLY PROCESS Validity						Validity Date:	n/a			
Model Code/Part Number: 724W /		7H0352W7020C	Customer:	NBS	Document No.:	WI-ENG-PDE-477		PDE-477		
Purpose:	□Р	ROTOTYPE		PRE-LAUNCH	MASSPRO	Revision No.:	1	Page No.:	2 of 3	

RTS:	1. Assy p 2. Black	vinyl tube ø5 L=149±3mm	3. Black t	JIG		n/a		
NO.	PI	ROCESS NAME	WORK PROCEDURE/ IL	TOOLS/PPE		QUALITY POINTERS		
2		Wire insertion to Black vinyl tube ø5 L=149±3mm		Get the Vinyl tube <mark>ø5 L=149±3mm</mark> using right and then insert the B-B wires.	n/a		1. No wrong use of parts	
3	P1	Taping 1 Black vinyl tube to wire near connector	3. After taping, check the measurement, wire	2. Get the BLACK TAPE and start taping using both hands. Note: Please refer to WI-PRO-ASY-001 for taping procedure. 40±3mm Confirm measurement of 40±3mm from end it tube up to terminal pointed tip using both ands.	MEASURING 6 7 8 9 10 1 2 3 4	5 6 7 8 9 (1. No peel-off tape 2. No flip-out tape 3. No loose tape 4. No wrong use of tape 5. No wrong dimension 6. No missing tape Note: Please use calibrated/verified measuring tape when getting the measurement.	

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

NBC (Philippines)

MASTER COPY

		WORK INSTRUCTION						May 05, 2022			
	Process Name/Title:	Process Name/Title: TAPING ASSEMBLY PROCESS						n/a			
	Model Code/Part Number:	724W / 7H0352W7020C Customer: NBS			Document No.:		WI-ENG-PDE-477				
	Purpose:	☐ PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:	1	Page No.:	3 of 3			
PARTS:	n/a				JIG	n/a					
NO.	PROCESS NAME	WOR	WORK PROCEDURE/ ILLUSTRATION TOOLS/PPE					QUALITY POINTERS			
4	Visual/By two's inspection	1. Check the double lock.	2. Check the taping cond	4. Compare to Master sam Note: Please refer to GL-PR Inspection of Sub-assy.	ple.	100	MASTER S	AMPLE			

6 7 8 9 10 1 2 3 4 5 6 7

Note: Please use calibrated/verified measuring tape when getting the measurement.



FOR HATSUMONO AND OWARIMONO ONLY

1. No wrong dimension

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

Measurement

P1

5

NBC (Philippines)

MASTER COPY