

		_	PROCESS NAME  TABLE LAY-OUT  Black VM tube (Sunprene) ø9 L=112±3mm  Black VM tube (Sunprene) vertical description (gloves, finger cots, etc.)  Housekeeping 1. Maintain and always practice 5's.											
			Process Name/Title:	Val	idity Date:									
			Model code/Part number:	·						Document No.:		WI-ENG-PDE-215B		15B
шШ			Purpose:	PROTOTYPE	PRE-LAUNCH	MASS	PRO		Re	vision No.:	n/a WI-ENG-PDE-215B  3 Page No.: 1 of 6  N/A  QUALITY POINTERS  2. No excess parts/tools 2. No excess parts/tools in			
												<u>'</u>		
PARTS:		1. All parts;Assy parts; Black VM tube (Sunprene) ø9 L=112±3mm; Black Tape								JIG: N/A				
N	0.	P	ROCESS NAME	<u>/3</u> \ W(	ORK PROCEDURE/ ILLUSTF	ATION				TOOLS/PPE		C	QUALITY POIN	TERS
			Table Lay-out	Black VM tube (Sunprene)						Be sure to wear prescribed person protective equipme during operation (gloves, finger cot	ial ent			
1	1	P2		Assy			y parts			Maintain and always practice 5's.     Personal things on the workplace is prohibited. Keep it in				
				131 £3mm 7068177795 18 × III 1 × 22 × 18 × 17 × 17 × 17 × 17 × 17 × 17 × 17					For any trouble, info he Assembly Assis Supervisor or Lin Leader for immedia	tant e ate				
		1		Revision H	istory		T	1		Prepared by	Reviev	wed by	Approved by	Noted by
07/31/24		Y-taping	from P1 (WI-ENG-PDE-215A)	embly to Clamp assembly process and trai due to process improvement. Inclusion of a able lay-out, Measurement and Visual ins	Car model "TOYOTA-HARRIER". Change		C. Villanueva	A. Arañes	n/a					
02/25/23	2		ck vinyl tube to Black SV tube (\	MP from 3MP to 2MP. Transfer Y-taping p /iny); Inclusion of Table lay-out (Page 1) a		D. Castillo	J.Loterte		A. Arañes	Jatus	1/1	5.H	ALAN	
04/26/21		Change t	from Pre-launch to Masspro. Ac	ld tape quantity. Change wind to windings		D. Castillo	J.Loterte	A. shimamura	A. Arañes	D. Castillo	C. Villa	4)//our	A. Araĝes	n/a
Eff. Date	Rev. No			Details of Change		Revised	Reviewed	Approved	Noted	Est. Date:	January 20	6, 2021		

			WORK INS	TRUCTION		Effectivity Date:		July 31, 2024	
		Process Name/Title:	TAPIN	Validity Date:	n/a WI-ENG-PDE-215B				
		Model code/Part number:	750B / 7M0681-7020A Customer: TRJ Car Model: TOYOTA HARRIER						Document No.:
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:	3	Page No.:	2 of 6
PARTS:	Assy parts     Black tape			JIG:	N/A				
NO.	F	PROCESS NAME	WORK P	TOOLS/PPE	QUALITY POINTERS				
2	P2	Y-Taping	Note: Do not exert excessive force during pulling & winding of tape.  2. Hold two SV tube using left hand and COT. Make 1 winding for pre-tape before shifting then wind the tape down to viny until 20±3mm.  taping direction  4. From COT, wind the tape down to S tube (1/2 shifting) until 20±3mm.	taping directs:  S. From SV tubside of corruga	20±3mm 20±3mm	6 7 8 9 10 1 2 3 4 5 6 7 8 9 8	Vise Yill visualizate should be 2. Please measurer measurer      No peel-2. No flip o 3. No loose 4. No wron	-off tape rut tape e tape g use of tape g dimension	easy s, but actual



			WORK INS	STRUCTION			Effectivity Date:		July 31, 2024	
		Process Name/Title:	TAPIN	Validity Date:	n/a					
		Model code/Part number:	750B / 7M0681-7020A	Customer: TRJ	Car Model:	TOYOTA HARRIER	Document No.:		WI-ENG-PDE-21	5B
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSE	PRO	Revision No.:	3	Page No.:	4 of 6
PARTS:	Black VM tube (Sunprene) ø9 L=112±3mm     Black tape						JIG:	JIG: N/A		
NO.	PROCESS NAME WORK PROCEDURE/ ILLUSTRATION					TOOLS/PPE	(	QUALITY POINT	TERS	
4	P2	Wire insertion to Black VM tube (Sunprene) ø9 L=112±3mm	L	1. Hold the wire tube (Sunprene	mm	l and insert the VM n using right hand.	N/A	1. No wrong use of parts		
5		Taping 3 Corrugated tube to VM tube (Sunprene)	1. Hold the COT using left hand and m the end of VM tube (Sunprene) up to t terminal tip 40±3mm.  25 ± 3mm	the   2. Hold t	t taping using rig	ing, check the taping nd terminal		5. No wron 6. No miss Importa 1. Pleas measuris measure Docum 1. Pleas	-off tape out tape ng dimension ng use of tape	erified ing the



NA	Proces	s Name/Title:		WORK INST	RUCTION  ASSEMBLY	PROCESS		Effectivity Date: Validity Date:		July 31, 2024 n/a		
	Model	Model code/Part number: <b>750B</b>		/ 7M0681-7020A	Customer: <b>T</b>	'RJ Car Mode	TOYOTA HARRIER	Document No.:		WI-ENG-PDE-215B		
	Purpos	e:	PROTO	DTYPE	PRE-LAUNCH	MAS	SPRO	Revision No.:	3	Page No.:	6 of 6	
PARTS:	1. Assy parts			√3 VISU	JAL INSPECTION	ON/ QUALITY CH	ECKPOINTS	JIG:	N/A			
P2					7M(	<mark>0681</mark> -	<b>7020A</b>		·			
			XX									
G	OOD	GO	עכ					G	OOD	GO	OD	
		XXX	1							Tag		
NO (	GOOD	NO GO	OD		1000		Market A.	NO	GOOD	NO G	OOD	
H	No Unic Halfloci on 2 con	ced Conn	<u> </u>	No Wrong Ir on 2 connecto		$\simeq$	Missing Tap			Termina king Out		