| | | | | TRUCTION | RUCTION | | | | | Effectivity Date: June 11, 2024 | | | |
|---|--------------|-------------------------|---|------------|----------------------|----------------------|---------------------------|--|--|--|----------------|-----------------|--|
| | | Process Name/Title: | | P ASSEMBI | LY PROC | ESS | | | Validity Date: | | n/a | | |
| | | Model code/Part number: | 550B / 7L0083-7023 | Customer: | TRQSS | Car Model: | TOYOTA- | HIGHLANDER | Document No.: | | WI-ENG-PDE-7 | 799 | |
| | | Purpose: | PROTOTYPE | PRE-LAUNCH | I | MASSE | PRO | | Revision No.: | 0 | Page No.: | 1 of 5 | |
| PARTS: 1. All parts: Assy parts; Black tape [5pcs]; Clamp 82711-52090 (W); Clamp 82711-48070 (GR); Clamp 82711-60640 (B); Clamp 8. NO. PROCESS NAME WORK PROCEDURE/ ILLUSTRATION | | | | | | p 82711-3A | 540 (W) | JIG: 1. Clamp Assembly jig TOOLS/PPE QUALITY POINTERS | | | | | |
| | | | | | | | | | | | | | |
| 1 | CLAMP | Table Lay-out | Clamp 82711-48070 (GR)/ Clamp tray Clamp 82711-60640 (B)/ Clamp tray | | 1-52090 (W)/ ip tray | | | | Safety Instruction Be sure to wear prescribed personal protective equipmer during operation (glov finger cots, etc.) Housekeeping 1. Maintain and alway practice 5's. 2. Personal things on t workplace is prohibite Keep it in your locker Alert level For any trouble, inforthe Assembly Assistar Supervisor or Line Lead for immediate correctiaction. | 2. No exc Docum 1. Refer to 7L0083-7 Process 6000 82711- | CLAMP ILLUSTRA | 82711-12A80 (W) | |
| | | | Revision History | | | | | | Prepared by | Reviewed by | Approved by | Noted by | |
| 06/11/24 0 Eff. Date Rev. No | Initial issu | ie. | Details of Change | | | D. Castillo Revised | C. Villanueva Reviewed | | n/a O. Castillo oted Est. Date: | L. Villanueva June 11, 2024 | A. Aranes | n/a | |
| | | | V | | | | | | | | | | |



| | | | WORK INS | Effectivity Date: | | | | | |
|--------------------------|--|-------------------------|---|---|---|-----------------------|--|--|---------------------------|
| | | Process Name/Title: | | P ASSEMBLY PRO | Validity Date: | n/a | | | |
| | | Model code/Part number: | 550B / 7L0083-7023 | Customer: TRQS | S Car Model: TOYOTA-HIGHLANDER | Document No.: | | WI-ENG-PDE-79 | 9 |
| | | Purpose: | PROTOTYPE | PRE-LAUNCH | MASSPRO | Revision No.: | 0 | Page No.: | 2 of 5 |
| 1. Clamp 82711-52090 (W) | | | | | | | | | |
| PARTS: | 2. Clamp 82711-32090 (W) 2. Clamp 82711-48070 (GR) [2pcs] 3. Clamp 82711-60640 (B) | | | Clamp 82711-3A540 Black tape [5pcs] | JIG: | 1. Clamp assembly jig | | | |
| NO. | ı | PROCESS NAME | WORK P | TOOLS/PPE | QUALITY POINTERS | | | | |
| 2 | CLAMF | Clamp Assembly setting | 1. Get 2pcs of clamp 82711-48070 (GR) hand and set to clamp location 1 and 4 hands. 2. Get 1pc of clamp 82711-52090 (W) thand and set to clamp location 2 using 3. Get 1pc of clamp 82711-3A540 (W) thand and set to clamp location 3 using hand and set to clamp location 3 using | ausing right using both 4. Get 15 hand and hands. Jusing right both hands. Jusing right both hands. | 82711-60640 (B) 82711-3A540 (W) Doc of clamp 82711-60640 (B) using right d set to clamp location 5 using both lack tape and initially attach black tape p location 1, 2, 3, 4 and 5. | | 2. No dama 3. No wron Importa 1. Please assembly | g use of clamp aged clamp g use of tape and reminders/N check the clamp be to avoid wrong use to avoid wrong use to avoid wrong use clamp litustration and the clamp litustration be seen to avoid wrong use to avoid wrong us | fore start of e of clamp. |



| | | | WORK INS | TRUCTION | | Effectivity Date: | <u> </u> | June 11, 202 | 4 | |
|--------|---------|-------------------------|---|---|--|--|--|------------------|------------|--|
| | | Process Name/Title: | | P ASSEMBLY PR | ROCESS | Validity Date: | | n/a | | |
| | | Model code/Part number: | 550B / 7L0083-7023 | | | Document No.: | | WI-ENG-PDE-7 | 99 | |
| | | Purpose: | PROTOTYPE | PRE-LAUNCH | MASSPRO | Revision No.: | 0 | Page No.: | 3 of 5 | |
| | | | | | | <u> </u> | 1 | | | |
| PARTS: | 1. Assy | parts | | | | JIG: | Clamp Assembly jig | | | |
| NO. | F | PROCESS NAME | WORK F | PROCEDURE/ ILLU | STRATION | TOOLS/PPE | TERS | | | |
| 3 | CLAMP | Clamp Assembly | Connector setting 1. Get the assy parts and set to jig using both setting) First, put the white connector to rece terminal to stopper jig and pull the toggle class WAIT for further instruction then continue the in location 1 is ON. Note: Sequence light of Location 1 will ON if the sequence light of Location 1 and star Press the switch button after taping. Continued to the sequence light of Location 1 and star Press the switch button after taping. Continued to the sequence light of Location 1 and star Press the switch button after taping. | N and COLOR SENSOR was ately CALL the attention of the process. Continue if the sensor detect the White the Sensor detect the | In put the location 2,3 and 4. Continue to location 2,3 and 4. | 5, and start ds. Press the ind will be | 1. Make stopper of 2. Make taping. 1. No flip-of 2. No peel-3. No loose 4. No miss 5. No wron | off tape tape | veen clamp | |



| | | | | K INSTRUCTION | | Effectivity Date: | June 11, 2024 | | |
|--------|---------|-------------------------|------------------|------------------------|------------------------------|---|---|--|-----------------------------|
| | | Process Name/Title: | <u> </u> | | | Validity Date: | n/a | | |
| | | Model code/Part number: | 550B / 7L0083-70 | Customer: TRQSS | Car Model: TOYOTA-HIGHLANDER | Document No.: | | WI-ENG-PDE-79 | 9 |
| | | Purpose: | PROTOTYPE | PRE-LAUNCH | MASSPRO | Revision No.: | 0 | Page No.: | 4 of 5 |
| | | | | | | | | | |
| PARTS: | 1. Assh | <u> </u> | | | | | n/a | | |
| NO. | F | ROCESS NAME | W | ORK PROCEDURE/ ILLUSTR | TOOLS/PPE | QUALITY POINTERS | | | |
| 4 | CLAMP | Measurement | NOTE: | V | ③ 116±3 | Measuring tape 7 8 9 10 1 2 3 4 5 6 7 8 9 10 145 ±5 10 0 0 White Vinyl tube (B) Ø5 | 1. Plea measur 2. For I Owarin Docum 1. Refer assembly Owaring | ant reminders and se use calibrated/ving tape when getterment. Hatsumono, Nakamono. nent reference/sto WI-PRO-ASY-0 by Hatsumono Nakamono Inspection | erified ing the nono and .: |



| | | WORK INSTRUCTION | | | | | | Effectivity Date: June 11, 2024 | | | 4 |
|--------|--------|--|--------------------|---------|--------|-------|------------------------------|---------------------------------|-----|--------------|--------|
| | | Process Name/Title: CLAMP ASSEMBLY PROCESS | | | | | | Validity Date: | | n/a | |
| | | Model code/Part number: | 550B / 7L0083-7023 | Custome | r: TRQ | QSS C | Car Model: TOYOTA-HIGHLANDER | Document No.: | | WI-ENG-PDE-7 | ′99 |
| | | Purpose: | PROTOTYPE | PRE-LAU | ICH | | MASSPRO | Revision No.: | 0 | Page No.: | 5 of 5 |
| | ı | | | | | | | | | | |
| PARTS: | 1. Ass | y parts | | | | | | JIG: | n/a | | |
| | | | | | | | ITV OUEOVOONITO | | | | |

VISUAL INSPECTION/ QUALITY CHECKPOINTS


7L0083-7023



GOOD



NO GOOD



- 1 No UNLOCKED/HALF LOCKED CONNECTOR
- (2) No Missing Clamp

- 3 No Missing tape
- **4** No Deformed Terminal

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

NBC (Philippines)
MASTER COPY