Process Name/ Title: Document No: WI-QAD-QAC-263 **PACKING INSTRUCTION** WORK INSTRUCTION Effective Date: June 27, 2024 Product Code/Name: Customer Code/ Customer Rev. No.: Page No.: 7R0124 **TRMX** Records/Remarks/ No. Work Procedure/ Illustration **Quality Pointers** 1 Qty/box Mat'l Put Vinyl Sheet name (1250 x 1250) TRMX inside TRMX box. box



50pcs*8 400 bdls Dim. Qty. 544*370* 1 228mm Vinyl 1250* 1 sheet 1250 **Partition** 343* 1 board 510 Vinyl 420* 8 bag 280

Page 1 of 1

Note:

Step 5 is applicable only in QC FG inspection.

For CSW process, use Oricon box instead of TRMX box.

1st LAYER



Put another bundles inside the box

2

3

4

(opposite direction per bundle) (50pcs* 4 bundles)

the box

bundle)

(50pcs* 4 bundles)

Layout partition board



2ND LAYER

(5) Fold the vinyl sheet. Put NBP Identification tag at the top and tape the flaps (two side and top portion).

Then Warehouse Identification tag at right side of the box.





Note: If need to attach 4M tag Put 4M tag at the left side of the box

							Prepared by	Checked by	Approved by	Noted by
06/27/24	2	Change vinyl size to 1250 x 1250. Transferred from WI-ENG-PDE-536	S.Malabuyoc	R. Pascua	O. Merin	-		. /		
08/12/22	1	Change work illustration on part no. 2.	M. Ariola	J. Loterte	C. Villanueva	A. Arañes	Cmarden		16	
06/2/22	0	Initial Issue	K. Doria	J. Loterte	C. Villanueva	A. Arañes	S.Malabuyoc	~ R. Pascua	O. Merlin	
Eff. Date	Rev. No.	Details of change	Revised	Reviewed	Approved	Noted	Establish Date:	June	2, 2022	