

		WORK INSTRUCTION						February 6, 2024		
			Process Name/Title:		CLAMP ASSEMBLY PROC	ESS	Validity Date:		n/a	
			Model code/Part number:	930B /	7N0203-7020A Customer: TRJ	Car Model: TOYOTA-4RUNNER	Document No.:		WI-ENG-PDE-8	26
ШШ			Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:	0	Page No.:	1 of 7
PARTS:			,	3); Clamp 82711-3A540(JIG:	2. Locking ji	ig	
N	Ο.	F	PROCESS NAME		WORK PROCEDURE/ ILLUSTR/	ATION	TOOLS/PPE	(QUALITY POIN	TERS
1		n/a	Table lay-out	Clamp 8271 33650 (B) Clamp tra	CLAMP ASSEMBLY PROCESS 7N0203-7020A Customer: TRJ Car Model: TOYOTA-4RUNNER Document No.: WI-ENG-PDE-826 No.: 1 o 7 Page No.: 1 o 7 Wischamp 82711-48210(B): Black tape [8pcs]: Light Green Work PROCEDURE/ ILLUSTRATION TABLE LAY-OUT Clamp 82711-3A540(W) Clamp 12711-3A540(W) Clamp 82711-48210(B): Black tape [8pcs]: Light Green TABLE LAY-OUT Clamp 82711-48210(B): Black tape [8pcs]: Light Green TABLE LAY-OUT Clamp 82711-48210(B): Black tape [8pcs]: Light Green TABLE LAY-OUT Clamp 82711-48210(B): Black tape [8pcs]: Light Green TABLE LAY-OUT Clamp 82711-48210(B): Black tape [8pcs]: Light Green TABLE LAY-OUT Clamp 82711-48210(B): Black tape [8pcs]: Light Green TABLE LAY-OUT Clamp 82711-48210(B): Black tape [8pcs]: Light Green TABLE LAY-OUT Clamp 82711-48210(B): Black tape [8pcs]: Light Green TABLE LAY-OUT Clamp 82711-48210(B): Black tape [8pcs]: Light Green TABLE LAY-OUT Clamp 82711-48210(B): Black tape [8pcs]: Light Green TABLE LAY-OUT Clamp 82711-48210(B): Black tape [8pcs]: Light Green TABLE LAY-OUT Clamp 82711-48210(B): Black tape [8pcs]: Light Green TABLE LAY-OUT Clamp 82711-48210(B): Black tape [8pcs]: Light Green TABLE LAY-OUT Clamp 82711-48210(B): Black tape [8pcs]: Light Green TABLE LAY-OUT Clamp 82711-48210(B): Black tape [8pcs]: Light Green TABLE LAY-OUT Clamp 82711-48210(B): Black tape [8pcs]: Light Green TABLE LAY-OUT Safety Instruction Bastery Instruction ToOLS/PPE QUALITY POINTERS 1. No missing parts/tools 2. No excess parts/tools 2. No exces					
					Revision History		Prepared by R	Reviewed by	Approved by	Noted by
)2/06/24	U	TAPING	form purpose form pre-launch to	MP ASSEMBLY PROCES	s from WI-ENG-PDE-773 . Change process name from S , Additional Table lay-out; Improve work clamp assembly jig		n/a M. Arioja 7c.	out for	A. Azenes	n/a
Eff. Date	Rev. No			Details of Cha	inge			uary 6, 2024		
						·				



	_			WORK INSTRUCTION		Effectivity Date:		February 6, 20	24
	AL	Process Name/Title:		CLAMP ASSEMBLY PR	ROCESS	Validity Date:	February 6, 2024 n/a WI-ENG-PDE-826 0 Page No.: 3 of 7 1. Clamp assembly jig 2. Locking jig QUALITY POINTERS 1. Use the provided locking per model 2. No unlock/half-locked connector		
		Model code/Part number:	930B /	7N0203-7020A Customer: TRJ		Document No.:		WI-ENG-PDE-8	26
		Purpose:	☐ PROTOTYPE	☐ PRE-LAUNCH	MASSPRO	Revision No.:	0	Page No.:	3 of 7
PARTS:	1. Assy parts				JIG:	Clamp assembly jig Locking jig			
NO.	NO. PROCESS NAME			WORK PROCEDURE/ ILLU	STRATION	TOOLS/PPE	(QUALITY POIN	TERS
3	n/a	Connector lock	1. Put the connect press to lock 2x. Clocked.	or into locking jig using right hand then theck the connector lock if properly	CONNECTOR CROSS SECONG NG NG Double Double Half Lock Condition Half Lock Condition Before lock	GOOD	1. Use the 2. No unloc	provided locking pck/half-locked con	per model nector

WORK INSTRUCTION Effectivity Date: February 6, 2024									
		Process Name/Title:	Validity Date:	n/a					
		Model code/Part number:	930B /	7N0203-7020A Customer: TRJ	Car Model: TOYOTA-4RUNNER	Document No.:		WI-ENG-PDE-8	326
		Purpose:	☐ PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:	0	Page No.:	4 of 7
PARTS: 1. Clamp 82711-48210 (B) 2. Clamp 82711-33650 (B)				3. Clamp 82711-3A5- 4. Black tape [3pcs] 5. Light green tape	40 (W)		. Clamp assembly jig Locking jig		
NO.	F	PROCESS NAME		WORK PROCEDURE/ ILLUSTRATION		TOOLS/PPE	(QUALITY POIN	TERS
4	n/a	Clamp setting	correct setting). Fir Receiver base 1 an. Last, set B/W-G wirr then press by toggle 2. Check if LED light ON. Check also the encountered abnorm attention of the lead continue the process. 3. Hold the tape on tape then cut the tage.	and set to jig. (See above picture for the st, set the connector 6189-0407 (W) to d lock. Continue to set the harness in jig. es with PCB end together within stopper clamp. Int for POWER ON and CLAMP ON was clamp location 1 sequence light is ON. If nality, STOP and immediately CALL the er, WAIT for further instruction then	4. Hold the tape on clamp location 2, then cut the tape using both hands. Pr taping. Continue if sequence on clamp 5. Hold the tape using both hands. Pr taping. Continue if sequence on clamp 6. Hold the tape using both hands. Pr taping. Continue if sequence on clamp 6. Hold the tape using both hands. Pr taping. Go sound will be heard. 7. Conduct POINT CHECKING before from jig.	make 3 windings of tape ess the SW button after location 3 was ON. make 3 windings of tape ess the SW button after location 4 was ON. make 3 windings of tape ess the SW button after location 4 was ON.	1. Pleas start of o wrong u 1. No wron 2. No wron 3. No dama	ortant reminders. e check the clamclamp assembly se of clamp. g use of parts g use of tape aged clamp g clamp position CLAMP ILLUSTRA 82711-48210 (I	p first before to avoid



				Effectivity Date:	February 6, 2024					
		Process Name/Title:		CLAMP A	SSEMBLY PROC	ESS	Validity Date:		n/a	
		Model code/Part number:	930B /	7N0203-7020A	Customer: TRJ	Car Model: TOYOTA-4RUNNER	Document No.:		WI-ENG-PDE-82	6
		Purpose:	PROTOTYPE		PRE-LAUNCH	MASSPRO	Revision No.:	0	Page No.:	6 of 7
PARTS:	n/a						JIG:	n/a		
NO.	P	ROCESS NAME		WORK PRO	CEDURE/ ILLUSTR	ATION	TOOLS/PPE	(QUALITY POINT	ERS
6	n/a	Measurement		Note: Measurement should be on END TAPE	77 ± 3mm		180 ± 3mm 0~5mm MEASURING TAPE	1. Please measuring measure 2. For He Owarimo	atsumono, Nakamo ono cument reference/ e refer to WI-PRO- Sub-Assy Hatsum ono and Owarimon	erified ng the ono and 's: -ASY- ono,

		Effectivity Date:	24					
	Process Name/Title:		CLAMP ASSEMBLY F	•	Validity Date:	-		
	Model code/Part number:	930B / 7N	0203-7020A Customer: TR	J Car Model: TOYOTA-4RUNNER	Document No.:		WI-ENG-PDE-8	26
	Purpose:	☐ PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:	0	Page No.:	7 of 7
PARTS: n/a					JIG:	n/a		
			QUALITY	CHECKPOINTS				
CLAMI ASSY			7N0	203-7020/	4			
GOO	BIACO	1 2 1 (VAMITE GREEN 2		2	2	3	4	
No	WRONG INS	SERT HALFLOCKE	No W	issing Clamp rong color of tap issing Tape			RMED AL/PCE	