_				WORK INSTRUCTION				Effectivity Date: July 3			
			Process Name/Title:	CLAMP ASSEMBLY PROCESS				1		n/a	
			Model code/Part number:	YKC / 7N0033-7020	Customer: TRJ	Car Model:	SUZUKI SOLIO	Document No.:		WI-ENG-PDE-96	61
			Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPR	o	Revision No.:	0	Page No.:	1 of 4
PARTS:		1. Assy	parts; White tape				JIG:	1. Assembly jig			
NO.		P	ROCESS NAME	WORK PROCEDURE/ ILLUSTRATION			TOOLS/PPE	(	QUALITY POINTERS		
					TABLE LAY-OUT			Safety Instruction  Be sure to wear prescribed personal protective equipment during operation (gloves, finger cots, etc.)	1. Refer	ent reference/s to WI-ENG-PDE-2: bly process	
1		Clamp Assy	Table Lay-out	SWITCH ASSEMBLY THOSAS I - 7020			Housekeeping  1. Maintain and always practice 5's.  2. Personal things on the workplace is prohibited. Keep it in your locker.	No missing parts/tools     no excess parts/tools     No wrong position of parts/tools			
				Assembly jig	White Ta	tape (10mm)/	020000123	Alert level For any trouble, inform the Assembly Assistant Supervisor or Line Leader for immediate corrective action.			
Revision History Prepared by Reviewed by Approved by Noted by											
Revision History Prepared by Reviewed by Approved by Noted by									Noted by		
07/31/24	0	Initial issue. Separate assembly process from Taping assembly process.  D. Castillo Villanueva A. Arañes N/a Castillo Villanueva A. Arañes A. Arañ						26			
Eff. Date	Rev. No	D. Castillo C. Villatiueva P. A.					A. MEDICS	n/a			


CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

NBC (Philippines)
MASTER COPY

			July 31, 2024							
		Process Name/Title:	WORK IN CLAI	Effectivity Date: Validity Date:	n/a					
		Model code/Part number:	YKC / 7N0033-7020	Customer: TRJ	Car Model: SUZUKI SO	LIO Document No.:	WI-ENG-PDE-96	61		
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:	0 Page No.:	2 of 4		
PARTS:	Assy part     White tape 10mm (No slit)					JIG:	1. Assembly jig			
NO.	PROCESS NAME		WORK PROCEDURE/ ILLUSTRATION			TOOLS/PPE	QUALITY POINTERS			
2	Clamp	Assembly (Spot Taping)	1. Get the assy parts and set to taping picture for correct setting). First, set 1 then lock. Continue to set the harne within the stopper jig then press by to light in location 1 was ON.  Note: Limit switch was applied for 2. Check if the Clamp is ON. Check is encountered abnormality, STOP and leader. WAIT for further instruction the and on location 1. Make 3 winding right index finger. Go sound will be he Note: Jig will alarm for excessive to the second of the same processive to the second of the same processive to the second of the same processive to the same proce	Spot taping guide wit switch  g jig using both hands. (See the 7282-1020 (W) to Receist, last set the B-B wires to regle clamp. Continue if the state the detection of clamp.  If location 1 sequence light we have a men continue the process.	above seiver base gether sequence as ON. If Intion of the luct spot taping using both ess the SW button using	Counter  Clamp: On  Clamp: Off  Clamp: Off	Important reminders/No.  1. Make sure no gap between terminals.  2. Counter will be the basis of harness per box. Only LEAD allowed to reset the counter.  1. No wrong insert  2. Make sure no gap between and stopper jig  3. No wrong jig of tape  4. No excess windings  5. No missed tape	on stopper and of quantity of DER are		

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.





CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.




			Effectivity Date:	July 31, 2024						
		Process Name/Title:	CLAMP ASSEMBLY PROCESS			Validity Date:	n/a			
		Model code/Part number:	YKC / 7N0033-7020	Customer: TRJ	Car Model: SUZUKI SOLIO	Document No.:		WI-ENG-PDE-9	61	
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:	0	Page No.:	4 of 4	
PARTS: 1. Ass		/ parts				JIG:	N/A			

**VISUAL INSPECTION/ QUALITY CHECKPOINTS** 

## **CLAMP ASSY**

7N0033-7020



GOOD



NO GOOD



- No Unlocked/ Half-locked Connector
- (3) No Missing Tape (Black Tape)
- 2 No Missing Spot Tape( White Tape)

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

NBC (Philippines)
MASTER COPY