
	WORK INSTRUCTION							Effectivity Date:		4		
		Proc	cess Name/Title:		E ASSEMBLY PROC			Validity Date:		n/a	-	
		Mod	lel code/Part number:	660B / 7R0110-7020B	Customer: TRMX	Car Model: TOYOT	A-SEQUOIA	Document No.:		WI-ENG-PDE-7	79	
		Purp	oose:	PROTOTYPE	PRE-LAUNCH	MASSPRO		Revision No.:	0	Page No.:	1 of 6	
PARTS:				X ROPE-LAY B L=467±2mm; Black Corrugated tube Ø5, L=401±3mm (no slit)				JIG:	2. Locking j	Insertion jig Locking jig		
NC).	PROCESS NAME WORK PROCEDURE/ ILLUSTRATION							•	QUALITY POIN	TERS	
1		Offline	Table Lay-out	Insertion jig	IRRAX ROPE	ck Corrugated tube & L=401±3mm (no slit)	R. C.	Safety Instruction Be sure to wear prescrib personal protective equipment during operati (gloves, finger cots, etc.) Housekeeping 1. Maintain and always practice 5's. 2. Personal things on th work place is prohibited Keep it in your locker. Alert level For any trouble, inform t Assembly Assistant Supervisor or Line Leade for immediate correctiv action.	ton) 1. No mis e 1. No exc	ssing parts/tools cess parts/tools		
				Revision History			1	Prepared by	Reviewed by	Approved by	Noted by	
06/11/24	0	Initial issue.				D. Castillo C.Villanueva	A. Arañes	n/a D. Castillo	South Thomas		n/a	
Eff. Date				Details of Change		Revised Reviewed			June 11, 2024	A. A HON CS	TI/ CI	
'	Index not Index and Index											



			WORK INS	Effectivity Date:	4				
		Process Name/Title: OFFLINE ASSEMBLY PROCESS				Validity Date: n/a			
		Model code/Part number:	660B / 7R0110-7020B	Customer: TRMX	Car Model: TOYOTA-SEQUOIA	Document No.:		WI-ENG-PDE-7	79
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:	0	Page No.:	2 of 6
PARTS: 1. Connector 6098-380		nector 6098-3803 (B)				JIG:	1. Insertion	n jig	
NO.	F	PROCESS NAME	WORK	PROCEDURE/ ILLUSTRA	ATION	TOOLS/PPE	QUALITY POINTERS		
2	Offline	Connector setting to insertion jig 6098-3803 (B)	Insertion Jig Holes Lock I-mark 1. Press the lock of insertion jig using left thumb.	hand and release the lock.	Connector lock Connector Orientation Lock Release	n/a	2. No wrong 3. No wrong 4. No dama Cor I-mails all GOOD	GOOD AIR IS ALL	entation on oles are open holes open

		WORK INSTRUCTION					Effectivity Date:	June 11, 2024			
		Process Name/Title: OFFLINE ASSEMBLY PROCESS					Validity Date:	n/a			
		Model code/Part number:	660B / 7R0110-7020B	Customer:	TRMX	Car Model:	TOYOTA-SEQUOIA	Document No.:		WI-ENG-PDE-7	79
		Purpose:	PROTOTYPE	PRE-LAUNCH		MASSPI	RO	Revision No.:	0	Page No.:	3 of 6
PARTS:	1. IRRAX ROPE-LAY B L=467mm [2pcs] 2. Black Corrugated tube Ø5, L=401±3mm (no slit)					JIG:	1. Insertion jig				
NO.	PROCESS NAME WORK PROCEDURE/ ILLUSTRATION					TOOLS/PPE		QUALITY POIN	TERS		
3		Wire insertion to Corrugated tube Ø5, L=401±3mm (no slit)		R	slit) using		be ø5 L=401±3mm (no sert RRAX ROPE-LAY B and.	n/a		g usage of parts med terminal	
4	Offline	Wire insertion to Connector 6098-3803 (B)	1. Get 1st black wire then insert to terminal using right hand. Press	R 3. A hold	2. Get 2nd using right	push the lock us	Black Black sing left thumb and then the connector from jig	n/a	Importa Importa In Please during ins Amkers Conduct insertion Do not ec Insertion Lead of the property	g insertion one insertion med terminal g wire facing ant reminders/N hold the wire near sertion. ure wires are prope Pull-Push-Pull-Pus cert extra force. on should be from I	terminal erly inserted. h after left to right. S 29 for Pull-

			WORK IN	ISTRUCTION	Effectivity Date:	June 11, 2024			
		Process Name/Title:	OFFLI	INE ASSEMBLY PRO	CESS	Validity Date:		n/a	
		Model code/Part number:	660B / 7R0110-7020B	Customer: TRMX	Car Model: TOYOTA-SEQUOIA	Document No.:		WI-ENG-PDE-	779
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:	0	Page No.:	4 of 6
PARTS:	1. Assy	parts				JIG:	1. Locking j	jig	
NO.	PROCESS NAME WORK PROCEDURE/ ILLUSTRATION					TOOLS/PPE		QUALITY POIN	ITERS
5	Offline	Connector lock	connector using right hand while left hand holding the		s the lower part of connector to fully not the locking jig. Right thumb-middle Left thumb-middle 5. Lift then press the connector in the middle using left and right hand. 6. Ensure that connector is in locked condition by touching the connector lock based on the sequence illustrated.	LOCKING JIG	Importa I. Manua damaged locking a lock. GC	ant reminders/ al locking may ca d connector. WI-PRO-KIT-001 and checking of ca Before pressing After pressing	/Note/s: nuse Proper connector





			WORK INS	Effectivity Date:	June 11, 2024				
		Process Name/Title:	OFFLIN	Validity Date:	n/a				
		Model code/Part number:	660B / 7R0110-7020B	Customer: TRMX	Car Model: TOYOTA-SEQUOIA	Document No.:		WI-ENG-PDE-7	779
		Purpose:	PROTOTYPE	☐ PRE-LAUNCH	MASSPRO	Revision No.:	0	Page No.:	6 of 6
PARTS:	1. Ass	parts				JIG:	n/a		
			VIS	UAL INSPECTION/ QUA	ALITY CHECKPOINTS				
OF	FI	INE INSER	RTION		7R0110-	7020B			
		IIIL IIIJLI	111011		7110110	70200			
$\ $ (1							(3	
				4					
	- 1								
	Ч						1		
	ESTATE.								
GO	30C							GOO	מכ
	JUL					F			
						(5		-	
			The state of the s						
	1				- Control of the Cont				
			(2)	Contraction of the Contraction o	The state of the s			17	
	4/17			9				JI F	
NO	G00	D						NO GO	anc I
	300							110 01	
	,								
	(1 No Unloc	ck connector (3 No Termi	nal Backing Out	_			
	'								
	/					(5) N o De	form	termin	al l
	(2)No Wron	g insert (4 Check th	e Alignment				
	'				- /B				