_						WORK INS	STRUCTION				Effecti	ivity Date:		April 4, 202	3		
			Process Name/Title:	TAPING ASSEMBLY PROCESS							Validit	y Date:		n/a			
			Model Code/Part Number:	895B	1	7N0092-7020	Customer:	er: TRJ			Document No.:			WI-ENG-PDE-500C			
			Purpose:	□Р	ROTOTYP	E	PRE-LAUNCH	MAS	SPRO		Revisi	on No.:	3	Page No.:	1 of 5		
														I			
PARTS:		1. Assy	parts; Black tape									JIG:	n/a				
N	0.	F	PROCESS NAME			WORK	PROCEDURE/ I	LLUSTRATION				TOOLS/PPE		QUALITY POI	NTERS		
	1	P3	Table lay-out	Ass	y parts		TABLE LA	Tape holder tape	1 17	Balane Assembly	pr dur	afety Instruction Be sure to wear orescribed personal otective equipme ing operation (glow finger cots, etc.)  Housekeeping Maintain and alward practice 5's. Personal things on orkplace is prohibitive in your locked and the property of th	1. No miss 2. No excellent ves, interest ves	sing parts/tools.			
	1	1				Revision History						Prepared by	Reviewed by	Approved by	Noted by		
04/04/23			of Quality checkpoints on page no.				eter from D1. V ter in a fee	M. Ariola	J. Loterte C	C. Villanueva A.	Arañes						
03/30/23	2	Tranfer p	om 3MP to 4 MP;Transfer process o rocess of clamp setting and Clamp	Assembly to P4	ng 1 Black I due to nev	w process distribution.	ctor from P1; Y-taping fro	om P2 to P3; M. Ariola	J. Loterte C	C. Villanueva A.	Arañes	00,00			0		

Reviewed Approved

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

11/18/23

Eff. Date Rev. No

NBC (Philippines)

MASTER COPY

Additional process, press the lock of connector to confirm if properly locked. Judgement will be NG once locked upon pressing

Details of Change


					WORK INST	RUCTIO	N				Effectivity Date:			April 4	, 2023
		Process Name/Title:			TAPING	ASSEN	IBLY PR	OCESS			Validity Date:			n/	a
		Model Code/Product Number:	895B	1	7N0092-702	<b>0</b> Cu	ustomer:	Т	RJ		Document No.:			WI-ENG-P	DE-500C
		Purpose:		PROTOTYP	E	☐ PR	RE-LAUNCH		MASSPRO		Revision No.:		3	Page No.:	2 of 5
												ı	1		
PARTS:	1. Assy 2. Black											JIG	n/a		
NO.	Р	ROCESS NAME			WORK PR	OCEDU	RE/ ILLUS	TRATION			TOOLS/	QUALITY POINTERS			
2	P3	Taping 1 Black SV tube (Vinyl) to Wire near connector	Start of	,,	25±3mm 4 1 2 3 4 0°5mm	2. Get the start taping	ector 25±3mm  Black tape using process using	ing, check the n	ds.	d	MEASURING 6 7 8 9 1 2 3 4	5,6789	1. No flip 2. No pe 3. No loc 4. No mi 5. No wr	se use calibro ring tape who rement. D-out tape rel-off tape	

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

NBC (Philippines)

MASTER COPY

_			Effectivity Date:		April 4, 2023					
	Process Name/Title:			Validity Date:		n/a				
	Model Code/Product Number:	895B	1	7N0092-7020	Customer:	TRJ	Document No.:		WI-ENG-PD	E-500C
	Purpose:	☐ PF	OTOTYF	'E	PRE-LAUNCH	MASSPRO	Revision No.:	3	Page No.:	3 of 5



CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

NBC (Philippines)

MASTER COPY

					WORK INSTRUC	CTION			Effectivity Date:			April 4, 2	023			
		Process Name/Title:	TAPING ASSEMBLY PROCESS								n/a					
		Model Code/Product Number:	895B	1	7N0092-7020	Customer:	TRJ	J	Document No.:		WI-ENG-PDE-500C					
		Purpose:	☐ PR	ОТОТУ	'E	PRE-LAUNCH		MASSPRO	Revision No.:		3	Page No.:	4 of 5			
PARTS:	1. Black 2. Assy									JIG	n/a					
NO.	ı	PROCESS NAME			WORK PROC	CEDURE/ ILLUS	TRATION		TOOLS/I	PPE	QUALITY POINTERS					
3	P3	Y-Taping (Continuation)	1/3 shiftii	4. \\ 25r	Wind the tape 1/3 shifting unnm)  Doing direction  5. Wind the	e tape backward 1/2 s	taping direct	R ust be	6 7 8 9 11 2 3 4	5 6 7 8 9	1. Use y visualizactual sactual sactua	cant reminders/ YELLOW TAPE; zation of shiftir should be BLAC se use calibrated ing tape when g rement.  p-out tape eel-off tape iose tape issing tape rong dimensior rong use of tap	for easy ng lines, but CK TAPE. d/verified netting the			

6. Wind the tape 1/2 shifting going up to other side of SV tube (Vinyl) 25±3mm then make 3 winds on the wire before cutting of tape. After taping, check the

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

NBC (Philippines)

MASTER COPY

condition of tape.

			WORK INSTRU	JCTION		Effectivity Date:			April 4,	, 2023				
	Process Name/Title:	Validity Date:		n/a										
	Model Code/Product Number:	895B	/ 7N0092-7020	Customer:	TRJ	Document No.:			WI-ENG-P	DE-500C				
	Purpose:	PRO	OTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:		3	Page No.:	5 of 5				
							ı	1						
PARTS: n/a							JIG	n/a						
	√3 QUALITY CHECKPOINTS													
Р3				<mark>7N00</mark>	92-7020									
	1 2 No Missing tape													

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

NBC (Philippines)

MASTER COPY