Process Name/ Title: Document No: WI-QAD-QAC-265 **PACKING INSTRUCTION** WORK INSTRUCTION June 27, 2024 Effective Date: Product Code/Name: Customer Code/ Customer Rev. No.: Page No.: Page 1 of 1 7R0126 TRMX Records/Remarks/ No. Work Procedure/ Illustration **Quality Pointers** Qty/bo 50pcs*4 200 bdls X Mat'l Dim. Qty. Put Vinyl Sheet name (1) (1250 x 1250) inside TRMX box. **TRMX** 544*370* 1 228mm box Vinyl 1250* 1 sheet 1250 343* Plastic vinyl bag of **Partition** 50pcs × 2bdls 1 CSW assv board 510 Vinyl 420* 4 Put the products inside 280 bag the box (2) (opposite direction per bundle) Note: (50pcs* 2 bundles) Step 5 is applicable only in QC FG inspection. For CSW process, use Oricon box 1st LAYER instead of TRMX box. Layout partition board (3) Put another bundles inside the box (4) (opposite direction per bundle) (50pcs* 2 bundles) **2ND LAYER** Fold the vinyl sheet. Put NBP Identification tag at the top and tape the flaps (two side and (5) top portion). Then Warehouse Identification tag at right side of the box. Note : If need to attach 4M tag
Put 4M tag at the left side of the box Prepared by Checked by Noted by Change vinyl size to 1250 x 1250. Transferred from WI-ENG-PDE-572 06/27/24 S. Malabuyoo R. Pascua O. Merin malder 07/29/22 0 M.Ariola C. Villanueva Initial Issue J. Loterte A. Arañes Malabuyoo Eff. Date Prepared Rev. No Approved Details of change

CONFIDENTIAL: ©2017 NBC; all rights reserved. Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

