					ISTRUCTION				Effect	ivity Date:			June 3, 2024	
			Process Name/Title:	TAPING ASSEMBLY PROCES				Validity Date		ty Date:	n/		n/a	
	-1		Model code/Part number:	700B / 7N0038-7020B	Customer: TRJ	Car Model:	TOYOTA L	LAND-CRUISEI	Docui	ment No.:			WI-ENG-PDE-8	86
			Purpose:	PROTOTYPE	PRE-LAUNCH	MASSP	PRO		Revis	ion No.:		1	Page No.:	1 of 7
PARTS:		1. Assy 2. Blacl	parts SV tube (vinyl) ø5 L=187	3. Black Corrugated tube ø5 L=491±4mm ±3mm 4. Black tape						JIG:	1	1. Terminal cover jig		
NO.		P	ROCESS NAME	WORK PROCEDURE/ ILLUSTRA					TOOLS/PPE			QUALITY POINTERS		
1		Black					e (vinyl) 3mm		1. N 2. pro	Safety Instruction Be sure to wear required personal protective equipment during operation (gloves, finger cots, etc.) Housekeeping 1. Maintain and always practice 5's. 2. Personal things on the workplace is prohibited. Keep it in your locker. Alert level For any trouble, inform the Assembly Assistant Supervisor or Line Leader for immediate corrective action.				
				Revision History					•	Prepared by	Revi	iewed by	Approved by	Noted by
		01										, , , , l	$\langle \langle \langle \langle \langle \rangle \rangle \rangle \rangle$	
06/03/24 05/09/24	0	Change p	re-launch to mass pro.			A.Hernandez A.Hernandez	C.Villanueva C.Villanueva	A. Arañes A. Arañes	n/a	Orline Children	Join	llanueva		,
Eff. Date Re	-	uai 1331		Details of Change		Revised	Reviewed		n/a Noted	A.Hernandez () Est. Date:	Æ.Ví Mav 09.		/ A. Nacables	n/a
Trevised Nevised Nevised Nevised Noted Lst. Date. Way 09, 2024														




			WORK INS	Effectivity Date:	June 3, 2024				
		Process Name/Title:	TAPIN	Validity Date:	n/a				
		Model code/Part number:	700B / 7N0038-7020B	Customer: TRJ	Car Model: TOYOTA LAND-CRUISER	Document No.:		WI-ENG-PDE-88	86
		Purpose:	□PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:	1	Page No.:	2 of 7
PARTS:	3. Black	k SV tube (Vinyl) Ø5 L=187 k tape				JIG:	n/a		
NO.	P	PROCESS NAME	WORK PROCEDURE/ ILLUSTRATION			TOOLS/PPE	C	QUALITY POINT	ERS
2		Wire insertion to Black SV tube (Vinyl) Ø5 L=187±3mm	1. Get the Black SV tube (Vinyl) Ø5 L=187±3mm using left hand then g B-V-G L=752±3mm wires and insert using the hand.	get the sing	n/a	n/a 1. No wrong use of parts. 2. No damaged terminal			
3	P1	Taping 1 Black SV tube (Vinyl) to Wire near connector	Start of taping 25±3mm 7 8 9 20 1 2 25±3mm	ne SV yl) using , get the se using d then taping th hands. 2. Hold thes measure the end of conne	25 ± 3mm 25 ± 3mm SV tube (Vinyl) using right hand and e end of the Corrugated tube up to ector 25mm. Taping, check the measurement and condition.	MEASURING TAPE 6 7 8 9 10 1 2 3 4 5 6 7 8 9 1	6. No wrong Importal 1. Please	off tape e tape ing tape g dimension g use of tape ont reminders/Note e use calibrated/ving tape when gett	erified

			WORK IN	Effectivity Date:	June 3, 2024						
		Process Name/Title:	TAPI	Validity Date:	n/a						
		Model code/Part number:	700B / 7N0038-7020B	Customer: TRJ	Car Model: TOYOTA LAND-CRUISER	Document No.:	WI-ENG-PDE-886				
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:	1 Page No.: 3 of 7				
PARTS:	1. Assy 2. Blac	parts k corrugated tube ø5 L=491	±4mm (No Slit)	3. Black tape		JIG:	n/a				
NO.	F	PROCESS NAME	WORK	PROCEDURE/ ILLUSTR	ATION	TOOLS/PPE	QUALITY POINTERS				
4	P1	Spot taping	1. Combine the assy parts then align all terminals. Start of taping 3. Get the Black tape using right hand then conduct 2 windings of spot taping using both hands.	2. Conduct measurement tip 120±3mm using both	nt from wires to terminal pointed hands. 100 ± 3mm 3 4 5 6 7 8 9 6 7 8 9 6 7 8 9 6 7 8 9 6 7 8 9 6 7 8 9 6 7 8 9 6 7 8 9 6 7 8 9 7 7 8 9	6 7 8 9 10 1 2 3 4 5 6 7 8 9 1	Important reminders/Note/s: 1. Please use calibrated/verified measuring tape when getting the measurement. 1. No flip-out tape 2. No peel-off tape 3. No loose tape 4. No missing tape 5. No wrong use of tape 6. No wrong dimension				
5		Wire insertion to Black corrugated tube	1. Hold the wires using left hand, get the terminal cover jig using right hand then insert the B-G-V wires	2. Get the corrugated tube (no slit) ø5 L=491±4mm (no slit) using right hand then insert the BG-V wires using left hand.	3. After insertion, remove the terminal cover iig using right	Terminal cover Jig	No wrong insertion No deformed terminal				


			WORK INS	Effectivity Date:	June 3, 2024 n/a				
		Process Name/Title:	TAPIN	Validity Date:					
		Model code/Part number:	700B / 7N0038-7020B Customer: TRJ Car Model: TOYOTA LAND-CRUIS		Document No.:	WI-ENG-PDE-886			
		Purpose:	□PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:	1	Page No.:	4 of 7
PARTS:	1. Assy 2. Blac					JIG:	n/a		
NO.	F	PROCESS NAME	WORK PROCEDURE/ ILLUSTRATION			TOOLS/PPE	(QUALITY POIN	TERS
6	P1	Taping 2 Black Corrugated tube (no slit) to Black SV tube (Vinyl)	Z.	Black tal pre-tapir	the COT using left hand, get the pe using right hand then start ng using both hands. 2. Hold the COT using right hand and measure the COT up to the SV tube (vinyl) 25mm. Note: Refer to WI-PRO-ASY-001 for taping procedure.		1. No loose 2. No flip-c 3. No peel 4. No wron	e tape out tape	verified tting the

			WORK INS	Effectivity Date:	June 3, 2024				
		Process Name/Title:	TAPIN	Validity Date:	n/a				
		Model code/Part number:	700B / 7N0038-7020B	Customer: TRJ	Car Model: TOYOTA LAND-CRUISER	Document No.:		WI-ENG-PDE-8	86
		Purpose:	PROTOTYPE	☐ PRE-LAUNCH	MASSPRO	Revision No.:	1	Page No.:	5 of 7
PARTS:	1. Assy					JIG: TOOLS/PPE	1. Locking		
NO.	P	ROCESS NAME	WORK F	WORK PROCEDURE/ ILLUSTRATION			QUALITY POINTERS		
7		Wire insertion to Black corrugated tube (no slit) ø5 L=491±4mm (Continuation)	4. Conduct measurement between end of COT up to pointed tip 39±3mm.			6 7 8 9 10 1 2 3 4 5 6 7 8 9	1. No wrong insertion 2. No deformed terminal Important reminders/Note/s: 1. Please use calibrated/verified measuring tape when getting the measurement.		
	P1								



			WORK INSTRUCTION				Effectivity Date:	June 3, 2024		
			Process Name/Title:	le: TAPING ASSEMBLY PROCESS Va				lity Date: n/a		
			Model code/Part number:	700B / 7N0038-7020B	Customer: TRJ	Car Model: TOYOTA LAND-CRUISER	Document No.:		WI-ENG-PDE-8	86
			Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:	1	Page No.:	7 of 7
Г										
!	PARTS:	n/a					JIG:	n/a		
VISUAL INSPECTION/QUALITY CHECKDOINTS										

7N0038-7020B



No Missing Tape (on SV tube (vinyl) to wire near connector and SV tube (vinyl) to COT

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.