			WORK INSTRUCTION							tivity Date:		June 11, 2024				
			Process Name/Title:		IG ASSEMB						ity Date:			n/a		
		5	Model code/Part number:	550B / 7L0083-7023	Customer:	TRQSS	Car Model:	TOYOTA-	HIGHLANDE	R Docu	ment No.:			WI-ENG-PDE-4	47B	
			Purpose:	PROTOTYPE	PRE-LAUNCH		MASS	PRO		Revis	sion No.:	()	Page No.:	1 of 5	
			parts; Black Tape							JIG:			n/a			
NO.			ROCESS NAME	WORK	PROCEDURE/	ILLUSTRA	TION				TOOLS/PPE		C	QUALITY POIN	ITERS	
1	1	P2	Table Lay-out	Assy parts Assy parts	Table La	71,001,7023		Tape Holder , Tape	/ Black	f pr dur 1. 2. F wo Kr	Alert level Alert level any trouble, infore example action.	nt ves, interest in the ves, interest in the ves, interest in the vestination in the vest		ing parts/tools ss parts/tools		
				Revision History							D	Davisous d		A d b	Nete d bu	
											Prepared by	Reviewed	υу	Approved by	Noted by	
06/11/24	0 1	Initial issue. D. Castillo C. Villanueva A. Arañes						n/a	n/a D. Castillo		Joseph John A. Arabes n/a					
Eff. Date	_			Details of Change			Revised	Reviewed		Noted	Est. Date:	June 11, 2024		A. W. WHERE	n/a	
			-									<u> </u>				



			WORK INSTRUCTION	Effectivity Date:	June 11, 2024				
		Process Name/Title:	TAPING ASSEMBLY PROCESS	Validity Date:		n/a			
		Model code/Part number:	550B / 7L0083-7023 Customer: TRQSS Car Model: TOYOTA-HIGHLANDER	Document No.:		WI-ENG-PDE-44	17B		
		Purpose:	□ PROTOTYPE □ PRE-LAUNCH ■ MASSPRO	Revision No.:	0	Page No.:	2 of 5		
PARTS:	1.Black tape 2.Assy parts			JIG:	n/a				
NO.	F	ROCESS NAME	WORK PROCEDURE/ ILLUSTRATION	TOOLS/PPE	QUALITY POINTERS				
2	P2	Taping 2 COT to VM tube (Sunprene)	No gap between COT and VM tube (Sunprene) 1. Fix the corrugated tube to VM tube (Sunprene) using left hand and start taping using right hand. R 20±3mm 20±3mm 20±3mm 2. Check the measurement and taping condition after taping.	6 7 8 9 10 1 2 3 4 5 6 7 8 9 1	1. Please measuris measure 2. Refer procedus 1. No loose 2. No peel 3. No flip-c 4. No word	to WI-PRO-ASY-0 re. e tape -off tape but tape g dimension g use of tape	verified tting the		



	_		WORK INSTRUCTION	Effectivity Date:	June 11, 2024					
		Process Name/Title:	TAPING ASSEMBLY PROCESS	Validity Date:	n/a					
	H	Model code/Part number:		Document No.:	WI-ENG-PDE-447B					
		Purpose:	□ PROTOTYPE □ PRE-LAUNCH ■ MASSPRO	Revision No.:	0	Page No.:	3 of 5			
PARTS:	1. Black 2. Assy			JIG:	n/a					
NO.	F	ROCESS NAME	WORK PROCEDURE/ ILLUSTRATION	TOOLS/PPE	QUALITY POINTERS					
3	P2	Taping 3 Corrugated tube to SV tube (Vinyl)	1. Fix the corrugated tube to SV tube (Vinyl) using left hand and start taping using right hand. 20±3mm 20±3mm 20±3mm 2. Check the measurement and taping condition after taping.		1. Please measurin measurer 2. Refer t procedur 1. No looss 2. No peel 3. No flip-c 4. No wron	e tape -off tape out tape g dimension g use of tape	erified ting the			




		June 11, 2024								
		Process Name/Title:	TAPIN	Validity Date:		n/a				
		Model code/Part number:	550B / 7L0083-7023	Customer: TRQSS	Car Model: TOYOTA-HIGHLANDER	Document No.:	WI-ENG-PDE-447B			
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:	0	Page No.:	4 of 5	
PARTS:	1.Assy ր	art				JIG:	N/A			
NO.	F	ROCESS NAME	WORK F	PROCEDURE/ ILLUSTR	RATION	TOOLS/PPE	(QUALITY POINT	ERS	
NO.	P2	Measurement	(4) 185 ± 3 (3) 35 ±3 (A) (B)	PROCEDURE/ ILLUSTE		MEASURING TAPE 6 7 8 9 10 1 2 3 4 5 6 7 8 9 1 2	Importal 1. Pleas measuri measure 2. For Ho Owarime Docum 1. Refer assembly Owarimo	nt reminders and r e use calibrated/ve ing tape when gett ement. atsumono, Nakam	note/s: erified ing the ono and	



			Effectivity Date:	June 11, 2024							
		Process Name/Title:	Process Name/Title: TAPING ASSEMBLY PROCESS						n/a		
		Model code/Part number:	550B / 7L0083-7023	Cu	stomer:	TRQSS	Car Model: TOYOTA-HIGHLANDER	Document No.:		WI-ENG-PDE-4	47B
		Purpose:	PROTOTYPE	PRI	E-LAUNCH		MASSPRO	Revision No.:	0	Page No.:	5 of 5
PARTS:	1. Assy	parts						JIG:	n/a		
	VISUAL INSPECTION/ QUALITY CHECKPOINTS										

P2

7L0083-7023



- **1** No Unlock/Halflock connector
- **2** No Terminal Backing Out
- **3 No Wrong Insert**

- 45 No Missing Tape
 - **6** No Wrong use of Tape (white)
 - **7** No Deform Terminal

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

NBC (Philippines)

MASTER COPY