									Effec	ctivity Date:		June 21, 2024			
			Process Name/Title: TAPING ASSEMBLY PROCESS							lity Date:		n/a			
			Model code/Part number:	373D / 7N0174-7020B	Customer: TRJ	Car Model:	TOYO	TA-RAV4	Docu	ıment No.:		WI-ENG-PDE-9	24B		
			Purpose:	PROTOTYPE	PRE-LAUNCH	MASSP	PRO		Revi	sion No.:	1	Page No.:	1 of 5		
PARTS:		1. Assy parts: Black SV tube (Vinyl) s		ð5 L=108±3mm;Blue tape (19mm)					JIG:	n/a					
NO.		PROCESS NAME		WORK PROCEDURE/ ILLUSTRATION					TOOLS/PPE		QUALITY POIN	ITERS			
1		Table Lay-out Black SV tube (Vinyl) Ø5 L=108±3mm Assy parts Blue Tape/ Tape Holder Revision History								afety Instruction Be sure to wear required personal rotective equipment of during operation (gloves, finger costs etc.) Housekeeping Maintain and alway practice 5's. Personal things the workplace is prohibited. Keep it your locker. Alert level or any trouble, inforce Assembly Assist Supervisor or Lines eader for immedia corrective action.	ent I ent I ays I No missi I No excess I no excess	No missing parts/tools No excess parts/tools			
Revision History				1		, ,		Prepared by	Reviewed by	Approved by	Noted by				
										4					
06/21/24	1	Change from Pre-launch to Masspro. Add Spot taping and change color from Gray tape to Blue tape. Split Clamp Assembly process. Improved the Visual Inspection/Quality Checkpoint					C. Villanueva	A. Arañes	n/a	- O'Rim Chi Ji A. Hernandez	Month House				
06/18/24	0	Pt-1					C. Villanueva	A. Arañes	n/a		C. Villanueva	A. Arañes	n/a		
Eff. Date	Rev. No	l		Details of Change		Revised	Reviewed	Approved	Noted	Est. Date:	June 18, 2024				

			Effectivity Date: June 21, 2024							
		WORK INSTRUCTION Process Name/Title: TAPING ASSEMBLY PROCESS					Validity Date:	n/a		
		Model code/Part number:	373D / 7N0174-7020B Customer: TRJ Car Model: TOYOTA-RAV4		OTA-RAV4	Document No.:	WI-ENG-PDE-924B			
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO		Revision No.:	1	Page No.:	2 of 5
PARTS:	1. Assy parts 2. Blue tape (19mm)					JIG:	n/a			
NO.	ı	PROCESS NAME	WORK PROCEDURE/ ILLUSTRATION				TOOLS/PPE	(QUALITY POIN	TERS
2	P2	Spot taping 1	1 2 3 4	2. Get the Black tap the Black wires. Con tape before cutting u	duct 2x windings of	check the	6789 1123456789	1. No flip-ou 2. No peel-d 3. No loose 4. No missi 5. No wrong 6. No wrong 1. Use E 2. Pleas	at tape off tape tape g dimension g use of tape and reminders/Not BLACK TAPE only e use calibrated/ ing tape when ge	1 mm

			WORK IN	Effectivity Date:	June 21, 2024						
		Process Name/Title:	Validity Date:	n/a							
		Model code/Part number:	373D / 7N0174-7020B	Customer: TRJ	Car Model:	TOYOTA-RAV4	Document No.:		WI-ENG-PDE-92	4B	
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPE	RO	Revision No.:	1	Page No.:	3 of 5	
PARTS:	Assy parts Blue tape (19mm)		3. Black SV tube (Vinyl) Ø5 L=108±3mm				JIG:	n/a			
NO.	. PROCESS NAME		WORK	TOOLS/PPE	(QUALITY POINT	ΓERS				
2		Wire insertion to Black SV tube (Vinyl) Ø5 L=108±3mm		L=10	et the Black SV <mark>08±3mm</mark> using ri rt the B-B wire u	ght hand then	n/a	1. No wron	g use of parts		
3	P2	Y-taping	1. Fix the COT and SV tube gap in between. Pre-taping R 3. Get the tape and fix the COT to SV tube (Vinyl). Make 1 wind pre-taping before shifting.	e (Vinyl). Make sure no 4. Make 1 shifting to the le 2x.	tube (Vinyl) up Must be 40±3r	0~22mm R	6 7 8 9 10 1 2 3 4 5 6 7 8 9 1	1. Use Y visualiza actual si 2. Please measurin measurei 1. No flip-c 2. No peel-3. No loose 4. No miss 5. No wron	out tape -off tape e tape	easy nes, but <u>FAPE.</u> ified	



