

PACKING INSTRUCTION

Document No:

Effective Date:

5

WI-ENG-PDE-152

November 10, 2020

WORK INSTRUCTION Product Code/Name:

Z03-81090-R740A


Customer Code/ Customer:

Rev. No.: 740A/NBC Hayashi

Page No.:

Page 1 of 2

No.	Work Procedure/ Illustration	Records/Remarks/ Quality Pointers		
	Spread Vinyl sheet inside	Qty/box	<u>5</u> 1200	100pcs* 12bdls
	folding box.	Mat'l name	Dim.	Qty.
		Vinyl sheet	750*1500	<u>/</u> 5\ 2
		Vinyl bag	280*420	<u>/</u> 5\ 12
	<u>S</u>	Partition board	343*510	1





Get vinyl (plastic) bag then put 4 bundles inside. (3) Note: Directions should be alternate for each bundle. Put the ID tag inside then

fold the plastic bag.



Arrange the packed harness in box as shown **(4)** in the illustration. (100pcs*2plastics with I.D tag inside) on both side.

1st layer: 2 plastics 2nd layer: 2 plastics 3rd layer: 2 plastics

Total of 6 plastics



Fold the vinyl sheet. (5)

> Put NBP Identification tag at the top.

Add the partition board at <u></u> the top.





				The street of the latest the late	100			
11/10/20	5	> Change quantity from 600 to 1,200pcs, change quantity of vinyl sheet from 1 to 2pcs and vinyl bag from 6 to 12pcs > Change from taping of plastic bag to folding for every 100pcs. > Add partition board	R. Peñaloza	A. Shimamura	A. Arañes	Prepared	Checked	Approved
10/21/20	4	> Change quantity from 1200 to 600pcs, change quantity of vinyl sheet from 2 to 1 pc and vinyl bag from 12 to 6pcs > Change from folding to taping of plastic bag for every 100pcs.	R. Peñaloza	A. Shimamura	A. Arañes			
10/20/20	3	> Change Part number from 201-81090-R740A to 203-81090-R740A > Change quantity from 600 to 1,200pcs, change quantity of vinyl sheet from 1 to 2pcs and vinyl bag from 6 to 12pcs > Change from taping of plastic bag to folding for every 100pcs.	R. Peñaloza	A. Shimamura	A. Arañes	20	(a b	
8/24/20	2	Change vinyl bag size from 275*405 to 280*420 Change sequence of process 1 to 3	R. Peñaloza	A. Shimamura	A. Arañes	Mayor	Shirk	1
7/24/20	1	Change Part number from Z01-81090-G740A to Z01-81090-R740A	R. Peñaloza	A. Shimamura	A. Arañes	R. Peñaloza	A. Shimamura	A. Arañes
Eff. Date	Rev. No.	Details of change	Prepared	Checked	Approved	Established D	ate: July 16, 20	020



Process Name/ Title: **PACKING INSTRUCTION**

Document No:

WI-ENG-PDE-152

WORK INSTRUCTION Product Code/Name:

Customer Code/ Customer

Effective Date: November 10, 2020

5


Z03-81090-R740A

740A/NBC Hayashi

Rev. No.:


Page No.: Page 2 of 2

Records/Remarks/ No. Work Procedure/ Illustration **Quality Pointers**






Bundle the 25 pcs harness using 1pc. black (7)vinyl tie



Get vinyl (plastic) bag then put 4 bundles inside. (8) Note: Directions should be alternate for each bundle. Put the ID tag inside then fold the plastic bag.





Arrange the packed harness in box as shown 9 in the illustration. (100pcs*2plastics with I.D tag inside) on both side.

1st layer: 2 plastics 2nd layer: 2 plastics 3rd layer: 2 plastics

Total of 6 plastics



(10)

Fold the vinyl sheet.

Put NBP Identification tag at the top then warehouse Identification tag at front side of the box.





Note: If need to attach 4M tag Put 4M tag at the right side