			WORK INSTRUCTION										Effectivity Date:		April 16, 2024			
			Process Name/Title: TAPING ASSEMBLY PROCESS												n/a			
			Model code/Part number:	240B	1	7M0494-7020C	Customer:	TRJ	Car Model:	LEX	(US ES	Doc	ument No.:			WI-ENG-PDE-2	276	
			Purpose:	PRO	TOTYPE	. [PRE-LAUNCH	I	MASS	PRO		Rev	ision No.:		3	Page No.:	1 of 5	
PARTS: 3		tube (Vi	nyl) ø5 L=40±3mm; Black								slit); Black S	JIG.			1. Measuring jig			
N	0.	Р	ROCESS NAME	WORK PROCEDURE/ ILLUSTRATION								TOOLS/PPE		n/a WI-ENG-PDE-276 3 Page No.: 1 of 5 Measuring jig QUALITY POINTERS No missing parts/tools No excess parts/tools No excess parts/tools				
	1	P1	Table Lay-out	Mea		Black SV tube (Vinyl) ø5 L=40±3mm	Black tape hold	e/Tape	The second second	sky Blue tap Tape holde		1 1 1 Ft	Bafety Instructi Be sure to wear prescribed person protective equipme during operation (gloves, finger cot etc.) Housekeeping Maintain and alw practice 5's. Personal things the workplace is prohibited. Keep it your locker. Alert level or any trouble, infe e Assembly Assis Supervisor or Lin eader for immedia corrective action	al ent s,				
	I I					Revision History							Prepared by	Revie	ewed by	Approved by	Noted by	
04/16/24	3	Change term from Vinyl tube to SV tube (Vinyl). Remove By two's inspection and change Quality checkpoints to Visual inspection. Inclusion of car model "LEXUS ES". Change tape width to 20±3mm.							D.Castillo	C. Villanueva	A. Arañes	n/a						
06/05/23	2	lnclusion of quality checkpoints; improve table lay-out, important reminders/note/s and document references, by two's inspection and work procedure/illustrations; standardize term of SV tube (vinyl)						J. Loterte	C. Villanueva	A. Arañes	n/a	Jestus	1/-	1) illum	SHOW!			
09/09/21		Change s	ange status from Pre-launch to Masspro.							C. Villanueva	A. Shimamura	A. Arañes	Arañes D. Castillo		. Villanueva A. Aranes n/a			
Eff. Date	Rev. No	No Details of Change							Revised	Reviewed	Approved	Noted	Est. Date:	May 24, 2	2021			




				WORK INST	Effectivity Date:	April 16, 2024								
		Process Name/Title:			G ASSEMBL	Validity Date:	n/a							
		Model code/Part number:	240B /	7M0494-7020C	Customer:		Car Model:	LEXUS ES	Document No.:		WI-ENG-PDE-2	76		
		Purpose:	PROTOTY	PE	PRE-LAUNCH		MASSPR	0	Revision No.:	3	Page No.:	2 of 5		
PARTS: 3	1. Black 2. Assy	k SV tube (Vinyl) ø5 L=40± parts	3mm	JIG:										
NO.	P	PROCESS NAME		WORK P	ROCEDURE/	ILLUSTR	ATION		TOOLS/PPE	QUALITY POINTERS				
2	/3	Wire Insertion to Black SV tube (Vinyl) ø5 L=40±3mm	L	: 		1.Get the Black SV tube (Vinyl) ø5 L=40±3mm using right hand then insert the Black wires.			n/a	No deformed terminal No wrong usage of parts				
3	P1	Taping 1 SV tube (Vinyl) to wire near terminal	1. Measure from 55±3mm using b	55±3mm 9 (10) 1 2 3 4 SV tube (Vinyl) to term ooth hands.	Bmm June 1	get Black t taping prod	rape using righ cess.	R It is a state of the state o		Importa 1. Please measure Docum 1. Please for tapine 2. No peel- 3. No loose 4. No miss 5. No wron	ant reminders/e use calibrated/ing tape when gement. ment references e refer to WI-PRO g procedure. but tape off tape e tape	- 1 mm Inote/s: verified ditting the		

NBC (Philippines)
MASTER COPY

				WORK INST	Effectivity Date:	April 16, 2024					
		Process Name/Title:		TAPING	Validity Date:		n/a WI-ENG-PDE-276 3 Page No.: 3 of 5				
	H	Model code/Part number:	240B / 7N	//0494-7020C	Customer: T		LEXUS ES	Document No.:		WI-ENG-PDE-2	76
		Purpose:	PROTOTYPE		PRE-LAUNCH	MASSPR	0	Revision No.:	3	Page No.:	3 of 5
		Blue tape parts				JIG:	n/a				
NO.	F	PROCESS NAME		WORK PF	ROCEDURE/ IL	LUSTRATION		TOOLS/PPE	QUALITY POINTERS		
4	P1	Taping 2 Corrugated tube to SV tube (Vinyl)	1. Fix the Corrugated left hand, measure from 95mm. 2. Get the Sky Blue to the taping process.	d tube and SV tube rom COT to termina	d and begin	No gap between and Vinyl 5±3mm bing condition.	R	Measuring tape 6 7 8 9 10 1 2 3 4 5 6 7 8 9 10 1 2 3 4 5 6 7 8 9 10 1 2 3 4 5 6 7 8 9 10 1 2 3 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	1. Please measurismeasure Docum 1. Pleas taping p 1. No flip-1 2. No peel 3. No loos 4. No miss 5. No wron	e use calibrated/wing tape when geterment. Internet references we refer to WI-PRO procedure. South tape l-off tape we tape sing tape ng use of tape	erified ting the







					WORK INSTRU	Effectivity Date:		April 16, 202	4				
		Process Name/Title:			TAPING A	Validity Date:	n/a						
		Model code/Part number:	240B	1	7M0494-7020C	Customer:	TRJ	Car Model:	LEXUS ES	Document No.:		WI-ENG-PDE-2	276
		Purpose:	PRO	TOTYF	žE 🗆	PRE-LAUNCH	l	MASSPRO		Revision No.:	3	Page No.:	5 of 5
												,	
PARTS:	ARTS: 1. Assy parts									JIG:	n/a		
'	3 QUALITY CHECKPOINTS												

TAPING - P1

7M0494-7020C



1 No Missing Tape (Sky Blue and black tape)

2 No Wrong color of tape

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

NBC (Philippines)
MASTER COPY