				STRUCTION				Effect	ivity Date:			June 11, 202	4
		Process Name/Title:		NG ASSEMBLY PROC				_	y Date:			n/a	
		Model code/Part number:	102D / 7L0121-7024		Car Model:		TA-RAV4	-	ment No.:			WI-ENG-PDE-4	
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPE	RO		Revis	ion No.:		0	Page No.:	1 of 5
PARTS:		Assy parts: Yellow tape [1pc.];							JIG:		/a		
N	0.	PROCESS NAME	WORK	PROCEDURE/ ILLUSTR	ATION				TOOLS/PPE		(	QUALITY POIN	TERS
1	I P	P2 Table Lay-out	Orange tape with tapeholder	Pre assy part  Yellow tape tapeholder	0			Be ope	afety Instruction sure to wear requipersonal protective equipment during eration (gloves, fin cots, etc.)  Housekeeping Maintain and alway practice 5's. Personal things on rkplace is prohibite ep it in your locked and the experiment of the experi	ired de la composition della c	. Refer to Vire and	ment reference o WI-PRO-CNC-0 Strip Length Tole ing parts/tools ss parts/tools	17 for
			Revision History						Prepared by	Revie	ewed by	Approved by	Noted by
	-				+ +				1	1/	<i>L:</i>	and I	
06/11/24	-	al issue.			D. Castillo C	C. Villanueva	A. Arañes	n/a	D. Castillo	C. Vill	llanueva	A. Asailes	n/a
Eff. Date	Rev. No		Details of Change		Revised	Reviewed	Approved N	loted	Est. Date:	June 11,	2024		




			WORK INS	STRUCTION			Effectivity Date:		June 11, 2024	1
		Process Name/Title:	TAPIN	NG ASSEMBLY PROC			Validity Date:		n/a	
		Model code/Part number:	102D / 7L0121-7024	Customer: TRQSS	Car Model:	TOYOTA-RAV4	Document No.:		WI-ENG-PDE-42	24B
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPE	RO	Revision No.:	0	Page No.:	2 of 5
PARTS:		ige tape					JIG:	n/a		
NO.	F	PROCESS NAME	WORK	PROCEDURE/ ILLUSTRA	ATION		TOOLS/PPE	(	QUALITY POIN	TERS
2	P2	Taping 1 Black VM tube (Sunprene) to wire near terminal	1. Measure from terminal pointed  Start of taping  R  tape wid	8 9 <b>G</b> D 1	prene) using leaping process of	eft hand, get the using both hands.	MEASURING TAPE  6 7 8 9 10 1 2 3 4 5 6 7 8 9 10 10 10 10 10 10 10 10 10 10 10 10 10	6. No wron  Importa  1. Use O  2. Please measuri measure  Docume 1. Refer	out tape -off tape -off tape -off tape -off tape -off tape g use of tape g dimension	Note/s:  y.  verified tting the



			WORK IN	STRUCTION			Effectivity Date:		June 11, 2024	4
		Process Name/Title:		NG ASSEMBLY PROC	ESS		Validity Date:		n/a	
		Model code/Part number:	102D / 7L0121-7024	Customer: TRQSS	Car Model:	TOYOTA-RAV4	Document No.:		WI-ENG-PDE-42	24B
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPE	RO	Revision No.:	0	Page No.:	3 of 5
PARTS:	1. Assy 2. Yello						JIG:	n/a		
NO.	F	PROCESS NAME	WORK	PROCEDURE/ ILLUSTRA	ATION		TOOLS/PPE	<u> </u>	QUALITY POIN	TERS
3	P2	Taping 2 Black corrugated tube to Black VM tube (Sunprene) near terminal	Must be no gap  2. Fix the corrugated tube and sunprene tube using both hands.  tape width tape width	MINION BU	3. tu (S ha ta pr ha	. Hold the corrugated libe and VM tube Sunprene) using left and, get the Yellow lipe then start taping rocess using both ands.	todorforjo je fosto koje propovje degla koji nje dosla Kuhuruh je i da la koje	1. Use YE 2. Please measurii measure  Docume 1. Refer taping p  1. No flip-c 2. No peel 3. No loose 4. No miss 5. No wron	ent reference/s: to WI-PRO-ASY-orocedure. out tape -off tape e tape	verified tting the





NBC (Philippines)
MASTER COPY

		WORK IN	STRUCTION			Effectivity Date:		June 11, 202	0.4
	Process Name/Title:		NG ASSEMBL	Y PROCESS		Validity Date:		n/a	· <del>·</del>
	Model code/Part number:	102D / 7L0121-7024		TRQSS Car Mod	el: TOYOTA-RAV4	Document No.:		WI-ENG-PDE-4	24B
	Purpose:	PROTOTYPE	PRE-LAUNCH	MA:		Revision No.:	0	Page No.:	5 of 5
RTS: 1. As	ssy parts				I CAN CONTROL	JIG:	n/a		
		VI	SUAL INSPECTI	ION/ QUALITY CI	HECKPOINTS				
P	2	7L	.012	21-7	024				
				W.					
		The second second			The same of the sa				
		NAME OF THE OWNER, WHEN PORTOR OF THE OWNER, WHEN PERSON OF THE OWNER,				3			
						3			
						3		4	
	2					3		4	5
1	2					3		4	5
1	No Unlock/Halt			pe (COT to minal) (Y) pe ( Sunpr	Sunprene ene tube	3 No Deform	ned terr	4 minal	5

NBC (Philippines)
MASTER COPY