
					WORK INS		Effectivity Date:	September 8, 2023				
			Process Name/Title:		TAPIN	Validity Date:	n/a					
		7	Model code/Part number:	700B /	7N0039-7020A	Customer: TRJ	Car Model: TOYOTA-LAN	ND CRUISER	Document No.:		WI-ENG-PDE-7	15B
			Purpose:	☐ PROTOTYP	E	PRE-LAUNCH	MASSPRO		Revision No.:	1	Page No.:	1 of 5
PARTS:		1. Assy	parts; Black corrugated tul	pe (no slit) ø5 L=490	6±4mm; Black tape			JIG:				
NO	Ο.	P	PROCESS NAME			ROCEDURE/ ILLUSTR	ATION		TOOLS/PPE	(QUALITY POIN	TERS
1		P2	Table lay-out	Assy	parts Tape hold tap		Black corrugat tube (no slit) & L=496±4mm	ø5	Safety Instruction Be sure to wear prescribed personal protective equipment during operation (gloves, finger cots, etc.) Housekeeping 1. Maintain and always practice 5's. 2. Personal things on the workplace is prohibited. Keep it in your locker. Alert level For any trouble, inform the Assembly Assistant Supervisor or Line Leader for immediate corrective action.		ing parts/tools ss parts/tools	
	1				Revision History				Prepared by R	Reviewed by	Approved by	Noted by
09/08/23	0	Change p	ourpose from pre-launch to Massprue.	o. Additional table lay-ou	t; Update Quality checkpoin	ts			rañes M.Arjola	J. Loterte	forf) for C. Villanueva	A. Aranes
Eff. Date	Rev. No			Details of 0	Change		Revised Reviewed Ap	pproved No	oted Est. Date: Augus	st 08, 2023		
	Potential Providence Reviewed Appliance Rate Est. Date. Program of 2012											

MASTER COPY

				WORK INS	Effectivity Date:	September 8, 2023				
		Process Name/Title:	TAPING ASSEMBLY PROCESS				Validity Date:	n/a		
		Model code/Part number:	700B /	7N0039-7020A	Customer: TRJ	Car Model: TOYOTA-LAND CRUISER	Document No.:		WI-ENG-PDE-71	5B
		Purpose:	PROTOTYPE	Ē	PRE-LAUNCH	MASSPRO	Revision No.:	1	Page No.:	2 of 5
PARTS:	Assy parts Black corrugated tube ø5 L=49		3. Black tape			JIG:	1. Terminal cover jig			
NO.	F	PROCESS NAME	WORK PROCEDURE/ ILLUSTRATION				TOOLS/PPE	G	QUALITY POINT	ERS
2	P2	Spot taping	1. Combine the a align all terminals L Start of taping 3. Get the Black to then conduct 2 wire taping using both	ape using right hand	2. Conduct measureme tip 100±3mm using both	ant from wires to terminal pointed h hands. 80±3mm 3 4 5 6 7 8 9 6 R e measurement and taping	MEASURING TAPE 6 7 8 9 10 1 2 3 4 \$ 6 7 8 9	Impor	rtant reminders/Notes use calibrated uring tape when gurement. It tape off tape tape use of tape use of tape	1 mm ote/s:
3		Wire insertion to Black corrugated tube (no slit) ø5 L=496±4mm	Hold the wires using the terminal cover jigh hand then insert the using left hand.	g using right slit B-G-V wires usi	Get the corrugated tube (no by \$5 L=496±3mm (no slit) and right hand then insert the B-V wires using left hand.	3. After insertion, remove the	Terminal cover Jig	1. No wrong 2. No deforn		

				WORK INS	Effectivity Date:	September 08, 2023					
		Process Name/Title:		TAPIN	IG ASSEMBLY	PROC	ESS	Validity Date:	n/a		
		Model code/Part number:	700B /	7N0039-7020	Customer:	TRJ	Car Model: TOYOTA-LAND CRUISER	Document No.:		WI-ENG-PDE-71	5B
		Purpose:	PROTOTYPE		PRE-LAUNCH		MASSPRO	Revision No.:	1	Page No.:	3 of 5
	1. Assy 2. Black							JIG:	n/a		
NO.	Р	PROCESS NAME		TOOLS/PPE	(QUALITY POINTERS					
4		Wire insertion to Black corrugated tube (no slit) ø5 L=496±4mm (Continuation)	6.7	8 9 GU	39±3mm	b	. Conduct measurement setween end of COT up to sointed tip 39±3mm.		Importa	rmed terminal ant reminders/Not a use calibrated/v ng tape when get	erified
5	P2	Y-Taping	Note: Do not exert excess during pulling & witape.		tape sh 1/2 be	nifting elow	Fix the two SV tubes (Vinyl) and DT using both hands. e illustration for correct facing of nnector. 2. Hold two SV tubes (Vinyl) using left hand and fix to COT. Make 1 winding for pre-tape before shifting then wind the tape down to SV tube (Vinyl) until tape width.		Importation 1. Use Y visualizate actual si	off tape e tape ing tape g dimension g use of tape out reminders/Note ELLOW tape to e etion of shiftiing l hoould be BLACH e use calibrated/ ing tape when get	asy ines, but (TAPE. verified



			WORK INSTI	Effectivity Date:	September 08, 2023					
	Process Name/Title:		TAPING	ASSEMBLY	PROC	ESS	Validity Date:		n/a	
	Model code/Part number:	700B /	7N0039-7020A	Customer:	TRJ	Car Model: TOYOTA-LAND CRUISER	Document No.:		WI-ENG-PDE-7	15B
	Purpose:	PROTOTYPE		PRE-LAUNCH		MASSPRO	Revision No.:	1	Page No.:	4 of 5
PARTS: n/a							JIG:	n/a		
				1 QUALIT	Y CHEC	CKPOINTS				
P2			·	7NC	003	39-7020A				
			2			1	1 2 3 4	5 6		
										10
	2	on wire	sing Tape							