

Put the products inside the box (opposite direction per bundle) (50pcs* 4 bundles)



CSW assy

Note:

Vinyl

bag

Step 5 is applicable only in QC FG inspection.

420*

280

8

For CSW process, use Oricon box instead of TRMX box.

3

Layout partition board



4

Put another bundles inside the box (opposite direction per bundle) (50pcs* 4 bundles)



2ND LAYER

(5)

Fold the vinyl sheet. Put NBP Identification tag at the top and tape the flaps (two side and top portion). Then Warehouse Identification tag at right side of the box.





Note: If need to attach 4M tag Put 4M tag at the left side of the box

Prepared by Checked by Approved by Noted by Change vinyl sheet size from 1520x1500mm to 1250 x 1250mm.Change control no. from WI-ENG-PDE-991 12/03/24 S. Malabuyoo D. Dadulla R. Pascua 07/17/24 A.Hernandez C. Villanueva A. Arañes n/a nitial Issue Prepared July 17, 202 Details of change Establish Date