			WORK INSTRUCTION									July 31, 2024		
			Process Name/Title:	TAPING ASSEMBLY PROCESS				_	Validity Date:		n/a			
			Model code/Part number:	900B/ 910B / 7N0072	2-7020C Customer: TRJ	Car Model:	LEXU	IS-NX/RX	Doci	ument No.:		WI-ENG-PDI	-461D	
			Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPI	RO		Revi	sion No.:	С	Page No.:	1 of 5	
		1.Assy	Part; Black Tape; Black V	VI tube(Sunprene) Ø9 L=112±3mm				JIG:	n/a	n/a				
N	0.	D. PROCESS NAME		WORK PROCEDURE/ ILLUSTRATION				TOOLS/PPE		QUALITY POINTERS				
				TABLE LAY-OUT			Black VM tube(Sunprene) Ø9 L=112±3mm			Safety Instruction Be sure to wear prescribed person rotective equipment during operation gloves, finger cote etc.)	al ent			
1		P4	Table-Layout	Assy Parts						Housekeeping 1. Maintain and always practice 5's . Personal things the workplace is prohibited. Keep it your locker.	on   1. No   2. No	No missing parts/tools.     No excess parts/tools.		
				1 (1) (1) (1) (1) (1) (1) (1) (1) (1) (1			Black Tape / Tape Holder		1	Alert level For any trouble, nform the Assemb Assistant Supervis or Line Leader fo mmediate correcti action.	oly or r	r		
	I			Revision	n History	, ,				Prepared by	Reviewed I	y Approved by	Noted by	
										1				
07/31/24					461B) and transfer Y-taping 2 from P3 (WI-	D.Castillo C	C.Villanueva	A. Arañes	N/A	Jatulo B. Castillo	four	for A. Arades	) N/A	
Eff. Date	Rev. No			Details of Change		Revised	Reviewed	Approved	Noted	Est. Date:	July 31, 2024			




			WORK INST	Effectivity Date:	July 31, 2024					
		Process Name/Title:	TAPINO	Validity Date:	n/a					
		Model code/Part number:	900B/ 910B / 7N0072-7020C	Customer: <b>T</b>	RJ Car Model:	LEXUS-NX/RX	Document No.:		WI-ENG-PDE-46	1D
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPR	0	Revision No.:	0	Page No.:	2 of 5
PARTS:	1. Assy 2.Black	parts Tape		3. Black VM tu	ube (Sunprene) Ø9 L=1	12±3mm	JIG:	n/a		
NO.	P	ROCESS NAME	WORK PI	TOOLS/PPE	QUALITY POINTERS					
2		Wire insertion to Black VM tube (Sunprene) Ø9 L=112±3mm		L=112:	the Black VM tube (Sur ±3mm using right hand s( Assy Part ).		n/a		g use of parts rmed terminal	
3	P4	Taping 4 Black corrugated tube to VM tube (Sunprene)	1. Measure from end of VM tube (Sunprene) up to terminal pointed 40±3mm using both hands.  25 ± 3mm  3. Confirm measurement of 25±3 of tape up to end of tube then contaping process using both hands.	R d tip  R mm from end tinue the	R left tap the	Hold the COT using hand, get the Black e using right hand in start pre-taping ing both hands.  The cof 25±3mm and of tape then less using both		1. Pleas measur measur measur Docume 1. Refer taping p  1. No flip-ou 2. No peel-o 3. No loose 4. No missir 5. No wrong	ent reference/s: r to WI-PRO-ASY-Corocedure.  ut tape iff tape tape ing tape	rerified ting the



			WORK INS	Effectivity Date:	July 31, 2024					
		Process Name/Title:	Validity Date:	n/a						
		Model code/Part number:	900B/ 910B / 7N0072-7020C	Customer: TRJ	Car Model:	LEXUS-NX/RX	Document No.:		WI-ENG-PDE-4	61D
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPR	RO	Revision No.:	0	Page No.:	3 of 5
		Assy parts lack Tape				JIG: n/a				
NO.	PROCESS NAME		WORK P	TOOLS/PPE	TOOLS/PPE QUALITY POINTER					
4	P4	Y-Taping 2	Y-Taping orientation  No Gap  1. Fix the corrugated tube .  taping direction  tape shifting 1/3 below  tape shifting 1/2  4. Winding the tape backward 1/2 shifting.	Corrugated tut 2 corrugated tut 2 corrugated tut 3. Winding th other side of 25±3mm.  Tape	e tape 1/3 shiftir corrugated tube  e shifting 9mm b  5±3mm  1/2 shifting goin n cut the tape. A	ting until it reach the e, width must be  25±3mm  25±3mm	Measuring tape  6789 1234 56789	1. Use visuali actual 2. Plea measu measu 1. No flip 2. No pe 3. No loc 4. No mi 5. No wro	rtant reminders  2 YELLOW TAPE for zation of shifting lir should BLACK TA ase use calibrated/ uring tape when get urement.  2-out tape el-off tape ose tape sssing tape ong use of tape ong dimension  Y-Taping 2	or easy nes, But APE. Verified

NBC (Philippines)

MASTER COPY





WORK INSTRUCTION Effectivity Date: July 31, 2024										4
		Process Name/Title: TAPING ASSEMBLY PROCESS					Validity Date:	n/a		
		Model code/Part number:	900B/ 910B / 7N0072-7020C	Customer: TRJ	Car Model:	LEXUS-NX/RX	Document No.:	WI-ENG-PDE-461D		
		Purpose:	☐ PROTOTYPE	PRE-LAUNCH	MASSPR	)	Revision No.:	0	Page No.:	5 of 5
PARTS:	1. Ass	sy parts					JIG:	n/a		
	VISUAL INSPECTION/ QUALITY CHECKPOINTS									
P	P4 7N0072-7020C									
1 2 No Missing Tape										

NBC (Philippines)

MASTER COPY