

Process Name/ Title:

## PACKING INSTRUCTION WORK INSTRUCTION

Document No:

WI-ENG-PDE-496

April 27, 2022

Product Code/Name: 7H0338W7020A

Customer Code: NBS Effective Date: Rev. No.:

0

Page No.:

Page 1 of 1

		7H0338W7020A	NBS					
No.	Work Procedure/ Illustration				Records/Remarks/ Quality Pointers			
					Qty/ Box	600 pcs	10pcs* 60bdls	
1	(15	Put Vinyl Sheet				Mat'l name	Dim. 544*370*	Qty
		(1520 x 1500)				TRMX Box	228 mm	1
	inside the box.				Vinyl Sheet Partition	1520*1500	1	
						Board Plastic	343*510	2
2		dls of products. (10pcs/bdl) n opposite direction.	CT MANAGEMENT AND			Vinyl Bag  Note:  1. For CSW use Oricon box instead of DC box.  2. Step number 7 is applicable only in QC FG Inspection.		
3	Put 20 b	partition board on layer 2 dls of products.(10 pcs/bdl) n opposite direction.						
4	Put 20 b	partition board on layer 3 dls of products.(10 pcs/bdl) n opposite direction.	pcs/bdl)			Make sure that the inner tag indicates the correct terminal expiration date.  One bundle has NBS inner tag inside the vinyl bag		
(5)	Fold the vinyl sheet.					SAMPLE INNER TAG  WITH THE TO BE (ARGED) WITH THE TOWN TH		
6	Clip NBP Identification tag and NBS Tag at the left side of the box							
7	box. If nec		Note: If need to att: Put 4M tag at		Outgoing Inspectors are the person-in- charge in the attachment of NBP tag (warehouse tag) and NBS tag (outer tag) to its proper location.			
						Prepare	Check	Approve
04/27/2022	0		Initial Issue	J. Loterte (	C, Villanueva A. Arañes	J. Loterte	C. Villanueva	A. Aranes
Eff./Rev. Date	Rev. No.		Details of change	Revise	Check Approve	Est. date	April 27	

CONFIDENTIAL: ©2017 NBC; all rights reserved. Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

NBC (Philippines)

MASTER COPY