

No.

1

Process Name/ Title: **PACKING INSTRUCTION**

Document No:

WI-QAD-QAC-260

Records/Remarks/

Quality Pointers

WORK INSTRUCTION Product Code/Name:

Customer Code/ Customer

Effective Date:

June 27, 2024

Page 1 of 1

7R0110

TRMX

Rev. No.:

Page No.:

Put Vinyl Sheet (1250 x 1250)

inside TRMX box.



Work Procedure/ Illustration

50pcs*8 Qty/box 400 bdls Mat'l Dim. Qty. name TRMX 544*370* 1 box 228mm Vinyl 1250* 1 1250 sheet **Partition** 343* 1 board 510 Vinyl 420*280 8 bag

2

Put the products inside the box alternately (50pcs* 4 bundles)



Note: Step 4 is applicable only in QC FG Plastic vinvl bag of inspection.

CSW assy

For CSW process, use Oricon box instead of TRMX box.

1ST LAYER

(3)

Layout partition board Put the products (50pcs* 4 bundles) on the 2nd layer in opposite direction





2ND LAYER

4

Fold the vinyl sheet. Put NBP Identification tag at the top and tape the flaps (two side and top portion). Then Warehouse Identification tag at right side of the box.





Note : If need to attach 4M tag
Put 4M tag at the left side of the box

		•					Prepared	Checked	Approved	Noted
								1. /	(/ .	
06/27/24	1	Change vinyl sheet to 1250 x 1250. Transferred from WI-ENG-PDE-329	S. Malabuyoc	R. Pascua	O. Merin		Cmarden	Mc/	146	
08/21/21	0	Initial Issue	J. Loterte	C. Villanueva	A. Shimamura	A. Arañes	S Malabuyoc	R. Pakcua	O. Merin	
Eff. Date	Rev. No.	Details of change	Prepared	Checked	Approved	Noted	Establish Date:	August	21, 2021	