

Process Name/ Title: **PACKING INSTRUCTION**

Document No:

Effective Date:

WI-QAD-QAC-231

February 28, 2024

WORK INSTRUCTION Product Code/Name:

Customer Code/ Customer:

		75S184	TRJ	Rev. No.:	2	Page No.:	Pag	je 1 of 1	
No.	Work Procedure/ Illustration					Records/Remarks/ Quality Pointers			
						Qty/box	400	100pcs* 4bdls	
2						Mat'l name	Dim.	Qty.	
1	Prepare empty oricon box					Oricon box	386*55* 243	1	
	in the "after inspection area	a"				Partition board	343* 510	3	
						Vinyl bag	545* 450	4	
<u></u>	Get the vinyl (plastic) b then put the 100pcs	ag							
(2)	harness. Insert product	ts .	755184-0281						

in same direction. Put the ID tag inside then fold the plastic bag.







3

Put products in vertical position and partition board vertically and alternately with the products. (100pcs*4 bundles with ID tag inside)



White connectors must be on top position.



Put NBP Identification tag at the top.Then warehouse Identification tag at lower right side of the box.







Note: If need to attach 4M tag
Put 4M tag at the left side
of the box

							Prepared by	Reviewed by	Approved by
2/28/2024	2	Change document control number from WI-ENG-PDE-635 to WI-QAD-QAC-231 -Remove Vinyl Sheet	M. Garcia	D.Dadulla	R.Pascua	n/a			M./
2/20/2023	1	Change customer to TRJ; change TRMX box to Oricon box	J. Loterte	C. Villanueva	A. Arañes	n/a	Mehrsfuter	(Max	1111
2/2/2023	0	Initial Issuance	M. Ariola	J.Loterte	C.Villanueva	A. Arañes	M. Gardia	D.Dadulla	R.Pascua
Eff. Date	Rev. No.	Details of change	Prepare	Review	Approve	Noted	Establish Date:	February 2,	2023