				Effectivity Date:	September 12, 2024							
			Process Name/Title:	CLAI	MP ASSEMBLY PROC	ESS		Validity Date:		n/a		
			Model code/Part number:	010B / 7L0030-7024A	Customer: TRQSS	Car Model: To	OYOTA CAMRY	Document No.:		WI-ENG-PDE-103	32	
			Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO		Revision No.:	1	Page No.:	1 of 8	
PARTS:		1.Assy	parts; Label 7V1070-0020	(73230-06750); Clamp 82711-34490 (B		JIG:	Assembly Jig					
N	0.	F	PROCESS NAME	WORK	PROCEDURE/ ILLUSTR	ATION		TOOLS/PPE	QUALITY POINTERS			
1		Clamp Assy	Table Lay-out	Clamp 82711-52090(W)/ Clamp tray Clamp 82711-34490(B)/ Clamp tray Assy parts Clamp assembly jig Black tape/ Tape holder	Bando gun Black tape	Labe	7V2080-0020)/ If dispenser	Safety Instruction Be sure to wear prescribed personal protective equipment during operation (gloves, finger cots, etc.) Housekeeping 1. Maintain and always practice 5's. 2. Personal things on the workplace is prohibited. Keep it in your locker. Alert level For any trouble, inform the Assembly Assistant Supervisor or Line Leader for immediate corrective action. Bando Gun	1. No miss 2. No exce	ing parts/tools ss parts/tools CLAMP ILLUSTRATION NG 090(W) 827 BAND CLAMP ILLUSTR. NG 14490 (B) 822	11-12A80 (W) ATION	
	1			Revision history		<u> </u>		Prepared by F	Reviewed by	Approved by	Noted by	
09/12/24		Change p	ore-launch to mass pro.			A.Hernandez C.Vil		n/a Olum Cm du A.Hernandez C	/ouf_)://ou-	A	n/a	
Eff. Date	Rev. No			Details of Change		Revised Rev	riewed Approved No		ember 09, 2024	A. ARHCO	TW CL	



WORK INSTRUCTION Effectivity Date: September 12,												
		Process Name/Title:		CLAMP ASSEM				Validity Date:		n/a		
		Model code/Part number:		0-7024A Custome	TRQSS	Car Model:	TOYOTA CAMRY	Document No.:		WI-ENG-PDE-10	132	
		Purpose:	PROTOTYPE	☐ PRE-LAUN	СН	MASSPI	RO	Revision No.:	1	Page No.:	2 of 8	
PARTS:	1. Clai 2. Clai	mp 82711-34490 (B) mp 82711-52090 (W) [2pcs]	3.	Black tape [2pcs]				JIG: 1. Clamp assembly jig				
NO.		PROCESS NAME		WORK PROCEDUR	E/ ILLUSTR	NOITA		TOOLS/PPE	QUALITY POINTERS			
2	Clamp Assy		1. Get 1 pc of band clam using right hand and set using both hands. 3. Get the Black tape us hands.	82711-34 3	82711-52090 2. Get 2 pcs both hands a using both ha	(W) of clamp 827 nd set to clar inds.	11-52090 (W) using np location 3 and 2		1. No dama 2. No wron 3. No miss	aged clamp g use of clamp ing clamp CLAMP ILLUSTRATION BAND CLAMP ILLUSTR	2711-12A80 (W)	


			WORK INSTRUC	Effectivity Date:	September 12, 2024			
		Process Name/Title:	CLAMP AS	SEMBLY PROCESS	Validity Date:		n/a	
		Model code/Part number:	010B / 7L0030-7024A Cu	ustomer: TRQSS Car Model: TOYOTA CAMRY	Document No.:		WI-ENG-PDE-1	032
		Purpose:	□ PROTOTYPE □ PR	E-LAUNCH MASSPRO	Revision No.:	1	Page No.:	3 of 8
PARTS:	1. Assy	parts			JIG:	1. Locking	Jig	
NO.	F	PROCESS NAME	WORK PROCE	EDURE/ ILLUSTRATION	TOOLS/PPE	C	QUALITY POIN	TERS
3	Clamp Assy	Connector Lock	1. Put the connector into locking jig using right hand then press 2x to lock using both hands. Check the lock if properly locked.	Coupler Cross Sectional View NG NG Obuble Double Do	4	1. Wanua DAMAGE	nt reminders/NAL LOCKING MAY D CONNECTOR. provided locking j ck/half-locked con of locking process	Y CAUSE ig per model nector

WORK INSTRUCTION Effectivity Date: September												
		Process Name/Title:	CL	AMP ASSE	MBLY PROC	ESS		Validity Date:	n/a			
		Model code/Part number:	010B / 7L0030-702	A Custo	mer: TRQSS	Car Model:	TOYOTA CAMRY	Document No.:		WI-ENG-PDE-1	032	
		Purpose:	PROTOTYPE	☐ PRE-L	AUNCH	MASSP	RO	Revision No.:	1	Page No.:	4 of 8	
PARTS:	1. Assy	parts						JIG:	1. Clamp assembly jig			
NO.	F	PROCESS NAME	WOF	K PROCED	URE/ ILLUSTRA	ATION		TOOLS/PPE	(QUALITY POIN	TERS	
4	Clamp Assy	Clamp Assembly	Stopper jig Tape holder/ Black tape 1. Put the assy parts into jig using I first put the connector to receiver I left hand and lock using right hand the terminal into stopper jig usig left pull down the toggle clamp using right refer to above illustration for the cosetting. 3. Initially tighten the band clamp 8 on clamp location 1 using right hard. 4. Get the bando gun using right hard. 4. Get the bando gun using right hard. 4. Get the bando gun using right hard.	ooth hands. ase using Second, put thand and ght hand. correct	Sequence light 2. Check if the Land SEQUENC abnormality, ST attention of the linstruction.	OP the proce	Connector setting Tape holder/ POWER, CLAMP N. If encountered ess, CALL the	BANDO GUN	1. No wron 2. No wron 3. No Loos 4. No wron	ng setting of clamp ng use of clamp se attachment of c ng setting of Bando ng use of tape off tape ing tape Fixed band cl	een terminal and	

					WORK INST	Effectivity Date:	September 12, 2024							
		Process Name/Title:			CLAMP	ASSEMB	LY PROC	ESS		Validity Date:	n/a			
		Model code/Part number:	010B	1	7L0030-7024A	Customer:	TRQSS	Car Model:	TOYOTA CAMRY	Document No.:		WI-ENG-PDE-10	32	
		Purpose:	□PR	ОТОТУРІ	E	PRE-LAUNCH	1	MASSPR	RO	Revision No.:	1	Page No.:	5 of 8	
PARTS:	1. Assy parts; Clamp 82711-52090; Clamp 82711-34490; Black tape									JIG:	ssembly jig			
NO.	F	PROCESS NAME			WORK PF	ROCEDURE	/ ILLUSTR	ATION		TOOLS/PPE	(QUALITY POINT	ERS	
4	Clamp	Clamp assembly (Continuation)		Tape hos Black to the tape light on 6. Hold to 6. Hold to 6.		tion 2 using boss the SW button.	uence light oth hands. Ma	ing.Continue it	Connector Tape holder/ gs then cut if sequence	n/a	1. No wron 2. No wron 3. No Loos 4. No wron	g setting of clamp g use of clamp se attachment of cla g setting of Bando g use of tape off tape	een terminal and	

			W	Effectivity Date:	September 12, 2024						
		Process Name/Title:		CLAMP ASSE	MBLY PROC	ESS		Validity Date:		n/a	
		Model code/Part number:	010B / 7L0030)-7024A Custon	mer: TRQSS	Car Model:	TOYOTA CAMRY	Document No.:		WI-ENG-PDE-	1032
		Purpose:	PROTOTYPE	☐ PRE-LA	AUNCH	MASSPE	RO	Revision No.:	1	Page No.:	6 of 8
PARTS:		parts; Label (7V1070-0020))		JIG:		. Clamp assembly jig				
NO.	F	PROCESS NAME		TOOLS/PPE	(QUALITY POI	NTERS				
5	Clamp Assy	Clamp assembly Label Attachment	73230-007700 PUSWHINIA NAANIAL	4. Align both end pa	2. Align the end	5. Aftr the la	el in the jig. Iter alignment , Press abel with both fingers.	Label Dispenser	5. No miss	age off g use of label	Item name Passenger Manual Driver Manual Passenger Power Driver Power





			WORK II	Effectivity Date:	September 12, 2024						
		Process Name/Title:	CLF	MP ASSEMBLY	/ PROCESS		Validity Date:		n/a		
		Model code/Part number:	010B / 7L0030-7024	A Customer: T	TRQSS Car Model:	TOYOTA CAMRY	Document No.:		WI-ENG-PDE-1	032	
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSP	PRO	Revision No.:	1	Page No.:	8 of 8	
								1			
PARTS:	1. Assy	parts					JIG:	n/a			

VISUAL INSPECTION

CLAMP ASSY

7L0030-7024A



1 No Wrong Facing of Clamp



CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.