			WORK INSTRUCTION						September 13, 2024			
			Process Name/Title:		NG ASSEMBLY PI		. =	Validity Date:		n/a		
		7	Model code/Part number:	922B / 7L0124-7022A		Car Model:	LEXUS NX	Document No.:		WI-ENG-PDE-10		
			Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO		Revision No.:	1	Page No.:	1 of 4	
PARTS:		1. Assy parts; Red tape; Black tap		е				JIG:	n/a			
N	0.	PROCESS NAME WORK PROCEDURE/ ILLUSTR					ATION TOOLS/PPE			QUALITY POINTERS		
				TABLE LAY-OUT				Safety Instruction  Be sure to wear prescribed personal protective equipment during operation (gloves, finger cots, etc.)	No missing parts in assy parts     No excess tape/tape holder     No wrong position of tape holder			
1		P3	Table Lay-out	Assy parts  1 2  1014 1702				Housekeeping  1. Maintain and always practice 5's.  2. Personal things on the workplace is prohibited. Keep it in your locker.			er	
				Black tape/ Tape Holder	681mm 1886/92 11 2 3 4 4 4 5	Но	pe/ Tape Ider	Alert level For any trouble, inform the Assembly Assistant Supervisor or Line Leader for immediate corrective action.				
	t			Revision History				Prepared by R	leviewed by	Approved by	Noted by	
09/13/24	1	Change for	rom Pre-launch to Masspro.			D.Castillo C.V	Illanuev A. Arañes	n/a		(ALAS)		
09/10/24	0	0 Initial issue. D				D.Castillo C.V	rillanuev a A. Arañes	n/a D.Castillo C.Villanueva A Acces n				
Eff. Date	Rev. No			Details of Change		Revised Re	eviewed Approved N		neber 10, 2024			

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.



			WORK INST	Effectivity Date:	September 13, 2024					
		Process Name/Title:		G ASSEMBLY PROC	Validity Date:	n/a				
		Model code/Part number:	922B / 7L0124-7022A	Customer: TRQSS		XUS NX	Document No.:		WI-ENG-PDE-104	14C
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO		Revision No.:	1	Page No.:	2 of 4
PARTS:	Assy parts     Red tape						JIG:	n/a		
NO.	O. PROCESS NAME WORK PROCEDURE/ ILLUSTRATION						TOOLS/PPE	(	QUALITY POINT	ΓERS
2	P3	Taping 4 VM tube (Sunprene) to wire near terminal and hotmelted wire	1. Hold VM tube (Sunprene) using left hand. Measure from VM tube (Sunprene) to end of hotmelted wire 80±3mm and Sunprene tube to terminal tip 88±3mm.	2. Get Red tape using right (Sunprene) (ø5 L=96±3mr (Sunprene) and start tapin 60±3mm	n) using left hand. Fol g using right hand.	tube old the VM tube		5. No wron 6. No miss  Wire  Importa 1. Please measuring measuren  Docume	off tape but tape gut tape gut tape gus of tape ing use of tape ing tape alignment to alignment to gus calibrated/verig tape when getting ment.	ote/s:

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.



			WORK INSTE	Effectivity Date:	September 13, 2024					
		Process Name/Title:		ASSEMBLY PROC	Validity Date:	n/a				
		Model code/Part number:	922B / 7L0124-7022A	Customer: TRQSS	1	LEXUS NX	Document No.:		WI-ENG-PDE-10	44C
		Purpose:	☐ PROTOTYPE [	PRE-LAUNCH	MASSPRO		Revision No.:	1	Page No.:	3 of 4
	1									
PARTS:	Assy parts     Black tape [1pc]						JIG:	n/a		
NO.	F	PROCESS NAME		TOOLS/PPE	QUALITY POINTERS					
2	P3	Half-wrap taping	1.Attach the tape, then make 2 windings.  4.Make 2 windings before cut the tape.  6. Conduct 3x pressing at the end of Tape using left thumb.	2. Pull the tape aroun 150mm-200mm.  5. After taping, che condition of tape. BE NO EXPOSED BETWEEN HALF TAPING.	eck the THERE MUST O COT WRAP	the table and a tape to make h cover the COT  ternal tolerance 0~14mm	er side of the harness on pply force to rotate the alfwrap shifting until with slit.s	1. Refetaping Importa 1. Use visualizactual: 2. Intertaping only.  1. No loose 2. No flip-o 3. No peel-	ut tape	ial).  te/s: asy fting, but (TAPE. halfwarp e 0~14mm

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

NBC (Philippines)


MASTER COPY

			WORK INSTRUCTION E						Effectivity Date:	September 13, 2024		
			Process Name/Title:	TAPING ASSEMBLY PROCESS					Validity Date:	n/a		
l			Model code/Part number:	922B / 7L0124-7022A	Customer:	TRQSS	Car Model:	LEXUS NX	Document No.:		WI-ENG-PDE-10	44C
			Purpose:	PROTOTYPE	PRE-LAUNCH	Н	MASSPRO		Revision No.:	1	Page No.:	4 of 4
										I		
	PARTS: 1. Assy		y parts						JIG:	n/a		

**VISUAL INSPECTION/ QUALITY CHECKPOINTS** 

## **TAPING - P3**

## 7L0124-7022A



FULL TAPING MUST BE HALF WRAP (NO EXPOSE COT)

No Missing Tape
No wrong use tape (Red)

Proper alignment of B-B wires and hotmelt

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

NBC (Philippines)
MASTER COPY