
				Effectivity Date:	24							
			Process Name/Title:		Validity Date:		-					
		H	Model code/Part number:	900B/910B /	7N0070-7020C Customer: TRJ	Car Model:	LEXUS-NX/RX	Document No.:		WI-ENG-PDE-4	60D	
			Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO)	Revision No.:	0	Page No.:	1 of 5	
PARTS:		1. Assy	1. Assy parts; Black VM tube (Sunprene) Ø9, L=112±3mm; Black tape						n/a			
NO.		PROCESS NAME			TOOLS/PPE	(QUALITY POIN	TERS				
1		P4	Table Lay-out		Assy part	Q Blace	k tape/ Tape Holder	Safety Instruction Be sure to wear prescribed personal protective equipment during operation (glove finger cots, etc.) Housekeeping 1. Maintain and alway practice 5's. 2. Personal things on the workplace is prohibited. Keep it in your locker. Alert level For any trouble, inform the Assembly Assistant Supervisor or Line Lead for immediate corrective action.	t t.s.,	ng parts/tools. s parts/tools.		
					Revision History			Prepared by	Reviewed by	Approved by	Noted by	
									•		•	
06/11/24	0	Initial Issue. Excluded process from P2 and P3 due to process improvement. Improved Measurement and Visual Inspection/ Quality checkpoint. M. Ariola C. Villanueva A. Arañes n/a							of only form.	A. Areanes	n/a	
Eff. Date	Rev. No			Details of Ch	ange	Revised R	eviewed Approved N	oted Est. Date: J	lune 11, 2024			








	WORK INSTRUCTION							Effectivity Date:	June 11, 2024			
		Process Name/Title:		TAPING A	ASSEMBLY PRO	CESS		Validity Date:		-		
		Model code/Part number:	900B/910B / 7N0070)-7020C	Customer: TRJ	Car Model:	Validity Date: LEXUS-NX/RX Document No.: Revision No.: JIG: TOOLS/PPE QUALITY POINTERS Note: Do not exert excessive force during pulling & winding of tape 1. No flip-out tape 2. No peel-of tape 3. No loose tape 4. No missing tape 5. No wrong use of tape 6. No wrong dimension MEASURING TAPE Important reminders/Note/s: 1. Use YELLOW TAPE for easy visualization of shifting lines, But actual should BLACK TAPE. 2. Please use calibrated/verified measuring tape when getting the measurement. Wellow Other side of corrugated					
		Purpose:	PROTOTYPE		PRE-LAUNCH	MASSPE	RO	Revision No.:	0	Page No.:	3 of 5	
PARTS:								JIG:	n/a			
NO.	F	Process Name/Title: TAPING ASSEMBLY PROCESS Model code/Part number: 900B/910B / TN0070-7020C Oustomer: TRJ Car Model: LEXUS-NX/RX Document No.: WI-ENG-PDE-460D Wi-ENG-PDE-460D Revision No.: 0 Page No.: 3 of P			TERS							
4		Y-Taping orientation	No Gap between COT 1. Fix the corrugated tube taping direction tape shifting 1/3	25±3mm	2. Start taping at the tubes, then winding t width must be 25±3m 3. Winding the tape 1 of corrugated tube, w	middle of combir he tape going to m. //3 shifting until in width must be 25mm hifting 9mm below ting going to oth	not exert excessive force during pulling & winding of tape 5±3mm and Corrugated 2 corrugated tubes, t reach the other side m. 25±3mm er side of corrugated	MEASURING TAPE	1. No flip-or 2. No peel-or 3. No loose 4. No missi 5. No wrong 6. No wrong Import 1. Use visualia actual 2. Plea measu	ut tape off tape tape ng tape g use of tape g dimension ant reminders/Note YELLOW TAPE for zation of shifting li should BLACK TAP se use calibrated/ring tape when ge rement.	s/s: easy ines, But <u>E</u> . verified	

NBC (Philippines)
MASTER COPY



NBC (Philippines)
MASTER COPY

		RK INSTRUCTION			Effectivity Date:		June 11, 202	4
Process Name/Title:	110.	Validity Date:			e 11, 2024 -			
Model code/Part number:	900B/910B / 7N0070-	Document No.:	WI-ENG-PDE-460D					
Purpose:	PROTOTYPE	-7020C Customer: TRJ	MASSPRO		Revision No.:	0	Page No.:	5 of 5
RTS: 1. Assy parts					JIG:	n/a		
		QUALITY CH	IECKPOINTS					
P4 (1)(2)	No Missing tape			-/ U	200	2		

NBC (Philippines)

MASTER COPY