

**PACKING INSTRUCTION** 

Document No:

WI-ENG-PDE-600

November 24, 2022

WORK INSTRUCTION

Effective Date:

Page 1 of 1

250pcs 4bdls

Qty.

			Product Code/Name: 723A Corrugate Tube	Customer Code: TRQSS	Rev. No.:	0	Page No	o.: Pag	e 1 of
Ī	No.			Records/Remarks/ Quality Pointers					
		Put Vinyl		A CALL	40		Qty/box	1000	250pc 4bdls
	1	Sheet (1520 x 1500)					Mat'l name	Dim.	Qty
		inside carton box.		TO THE REAL PROPERTY.			DC carton	1131*781	1
				Service of the			Vinyl sheet	1520*150 0	1
					1		Vinyl bag	420*280	4
	2	Put first 2 bundles of products on first layer (250pcs/bundle)							
Ī	3	Put another 2 bundles of products on 2nd layer (250pcs/bundle)							

4 Fold the vinyl sheet then close the flaps and put ID tag (Inner tag at the top of the plastic and Outer tag at the right side of the front of the box).







Note: If need to attach 4M tag Put 4M tag at the left side

		•				Prepared by	Reviewed by	Approved by
						(		
						( Show	Month tillow	Alban
11/24/22	0	Initial issue	J. Loterte	C. Villanueva	A. Arañes	J. Loterte	C. Villanueva	A. Arañes
Eff./Rev. Date	Rev. no.	Details of change	Revised	Reviewed	Approved	Established. date:	Novembe	er 24,2022

CONFIDENTIAL: ©2017 NBC; all rights reserved. Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited. NBC (Philippines) **MASTER COPY**