

Process Name/ Title:

PACKING INSTRUCTION WORK INSTRUCTION

Document No:

WI-QAD-QAC-072

July 2, 2024

Product Code/Name: **7N0001**

Customer Code: TRMX

Effective Date: Rev. No.:

3

Page No.:

Page 1 of 1

| | ı | /N0001 | IRMX | | T | | |
|----------------|--|---|--|--------------------------------------|---|-----------------|------------------|
| No. | Work Procedure/ Illustration | | | Records/Remarks/ Quality Pointers | | | |
| 1) | | ٨ | | | Qty/ Box Mat'l name | 700 pcs | 25pcs* 28bdls |
| | | Put Vinyl Sheet | | | | 544*370* 228 | Qty 1 |
| | | (1250 x 1250) inside TRMX box. | | | | mm 1250*1250 | - |
| | Iliside i Rivix box. | | <u></u> | | Sneet | mm | 1 |
| | | | 11/1/1/1/1/1/1/1/1/1/1/1/1/1/1/1/1/1/1/1 | | Partition Board | 343*510 mm | 1 |
| | | | | | Plastic Vinyl Bag | 300*200mm | 28 |
| 2 | Put 16 bo | dle of products (25pcs/bdl) | | | Note: 1. For CSW use Oricon box instead of DC box. 2. Step number 5 is applicable only in QC FG Inspection. | | |
| 3 | ı | Put partition board | | | | | |
| 4 | Put 12bdls of products. (25pcs/bdl) in opposite direction. | | | | | | |
| (5) | Fold the vinyl sheet. Put NBP Identification tag at the top and tape the flaps (two side and top portion). Then Warehouse Identification tag at the right side of the box. | | Note: If need to attach 4M tag Put 4M tag at the left side | | | | |
| 07/02/2024 | 3 | | size from 1520 x1500mm to 1250 x1250mm. | S. Malabuyoc R. Pascua O .Merin | Prepared | Checked | Approved |
| 02/15/2023 | 2 | -Change box dimension from 610*381*178 mm to 544*370*228 mm -Change size of vinyl bag from 420*280 mm to 300 * 200 mm 2 -Change quantity per bundle from 14pcs to 25 pcs | | | M/ | (6/ | |
| 11/15/2018 | 0 | change qu | Initial Issue | C. Dimailig M.Lumbres E. Mendoza | S. Malabuyde | R. Paseua | O Merin |
| Eff./Rev. Date | Rev. No. | | Details of change | Revise Check Approve | Est. date | 11/15/ | 2018 |