

Process Name/ Title:

PACKING INSTRUCTION

WORK INSTRUCTION

Product Code/Name: C WI-QAD-QAC-176 Document No: Effective Date: October 11, 2024 Customer Code:

	<b>D</b>	roduct Code/Name: 7L0085	Customer Code: TRQSS	Rev. No.:	4	Page No.	: Page	e 1 of 1	
No.			Records/Remarks/ Quality Pointers						
	Put Vinyl					Qty/box	120/4	60pcs *2bdls	
1	Sheet (1250 x 1250)				Mat'l name	Dim.	Qty.		
	inside carton box.				DC carton	1131*781	1		
					Vinyl sheet	1250*1250	1		
					Vinyl bag	420*280	2		
2	Put first bdl of products. (60pcs/bdl)					Note: Step number 5 is applicable only in <b>QC FG Inspection.</b>			
3	Put second bdl on the other side with opposite direction (60pcs/bdl)								
4	Fold the vinyl sheet								
5	Close the flaps and put ID tag (Inner tag at the top of the plastic and Outer tag at the left side of the front of the box) .		Note: If need Put 4M	to attach 4M tag	sside				

		·				Prepare	Check	Approve
10/11/2024	4	Change quantity per bundle from 50 pcs to 60 pcs Change total packing quantity from 100 pcs to 120 pcs	A. De Chavez	D.Dadulla	R.Pascua			
6/4/2024	3	Change Vinyl Sheet Size from 1520x1500 to 1250x1250; Change picture of no. 1; Modify no. 4 and Addition of no. 5; Add note.	J. De La Cruz	D.Dadulla	R.Pascua			
8/24/2022	2	Remove "Note: For CSW process disregard step 4 and use Oricon box instead of DC box"	M. Garcia	R. Alcantara	A.Arañes	10-		1, /
07/30/2020	1	Change color of connector from White to Black	C.Dimailig	M.Lumbres	E Mendoza	Alex	( Ma	MH
7/21/2020	0	Initial Issue	C.Dimailig	M.Lumbres	E Mendoza	A. De Chavez	D.Dadulla	R.Pascua
Eff./Rev. Date	Rev. no.	Details of change	Prepared	Checked	Approved	Established. date:	7/2	1/2020

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

**NBC** (Philippines) **MASTER COPY**