

Process Name/ Title:

PACKING INSTRUCTION

Document No:

WI-ENG-PDE-522

May 23, 2022

WORK INSTRUCTION
Product Code/Name: Custom 7H0320W7020C

Customer Code:

Effective Date: Rev. No.:

2

Page No.:

Page 1 of 1

7H0320W7020C NBS						rage No rage rorr		
No.	Work Procedure/ Illustration				Records/Remarks/ Quality Pointers			
1						Qty/ Box Mat'l name	240	10pcs* 24bdls
	Put Vinyl : (1520 x 1				<u>/2</u>	Master	Dim. 535*360* 150 mm	Qty 1
	inside the box.					Vinyl Sheet	1520*1500	1
					<u>/3</u>	Partition Board	343*510	1
				nice and the		Plastic Vinyl Bag	300*200mm	24
2	Put 12 bdls of products. (10pcs/bdl) in opposite direction.					Note: 1. For CSW use Oricon box instead of DC box. 2. Step number 6 is applicable only in QC FG Inspection.		
3	Put partition board on 2nd layer Put 12 bdls of products. (10pcs/bdl) in opposite direction.					One bundle has NBS inner tag inside the vinyl bag SAMPLE INNER TAG SPP Note (是他の)		
4	Fold the vinyl sheet.					Make sure that the inner tag indicates the correct terminal expiration date.		
(5)	Clip NBP Identi and NBS Tag at the box	e left side of the						
6	Attach NBS Identification tag at the left side of the box and NBP warehouse tag in the right side of the box.		7H0320W7020C THE DELIVER FOR THE SECOND SEC			Outgoing Inspectors are the person-in- charge in the attachment of NBP tag (warehouse tag) and NBS tag (outer tag) to its proper location.		
				Ī		Dresses	Ch. d.	Angeres
05/23/2022			ox; change qty. from 360pcs to 240pcs; reduce partit ; reduce vinyl bag from 36pcs to 24pcs	ion board from J. Loterte		_	Check	Approve
05/17/2022 05/05/2022	1 Change		box from Master box to TRMX box	J. Loterte J. Loterte		(An)		A. Aranes
05/05/2022 Eff./Rev. Date	Rev. No.		Initial Issue Details of change	J. Loterte Revise	C. Vilianueva A. Aranes Check Approve	J. Loverte Est. date	C. Villanueva May 5	
	<u> </u>		-	<u> </u>		1		