

No.

Process Name/ Title:

1. Set wire bobbin cart. Then held with bobbin cart.

2. Bobbin stopper must be fixed solidly.

How to set-up civus wire on wire guide roller

Note: If is not solid, it may cause injuries due to falling down.

3+. The wire rod is let through the pulley in-order, from right and front side.

If it is loose, it can't be synchronized with processing machine

Document No:

WI-PRO-CNC-056

Page 1 of 1

Records/Remarks/


Quality Pointers

WORK INSTRUCTION Effective Date: September 1, 2018 Product Code/Name: **Customer Code:** Rev. No.: 0 Page No.: ALL ALL

Work Procedure/ Illustration

\sim	3 2
(A)	5
4	
	(0)
	Rotation

5. Turn bobbin with your hand in order the accumulator pulley be adjusted at the position of the arrow. See picture below.



6. After set-up of wire, check again the wire alignment prior proceeding to mass production.

* If any abnormality STOP-CALL-WAIT.

W.Valdez Eff./Rev. Date Rev. No. Details of change Check Est. date

CONFIDENTIAL: ©2017 NBC; all rights reserved. Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly