
								Effectivity Date:	April 8, 2025				
		Process Name/Title: Model code/Part number:	736D /	CLAMF 7R0119-7022	P ASSEMBLY PROC Customer: TRMX	Car Model: TOYO1	TA TACONA	Validity Date: A Document No.: W		n/a	n/a WI-ENG-PDE-1247		
		Purpose:	□ PROTOTYPE		Customer: TRMX PRE-LAUNCH	MASSPRO	IA-TACOWIA	Revision No.:	0	Page No.:	1 of 8		
		т агроос.			- THE EXERTER				<u> </u>	. ago			
PARTS:	1. Assy parts: Clamp 82711-3A640 (B); Clamp 82711-26380 (BR); Black tape; Red tape; QR Code label 7V3240-0020							JIG:		1. Clamp assembly jig 2. Bando Gun			
NO.	F	PROCESS NAME		WORK P	ROCEDURE/ ILLUSTR	ATION		TOOLS/PPE	(QUALITY POINTERS			
1	Clamp	Table Lay-out	QR Codel Label 7V3240-0020	Clamp 82711-3A640 (B)	Assy Part Bando	Band Clamp 82711-26380 (B		Safety Instruction Be sure to wear required personal protective equipment during operation (gloves, finger cots, etc.) Housekeeping 1. Maintain and always practice 5's. 2. Personal things on the workplace is prohibited. Keep it in your locker. Alert level For any trouble, inform the Assembly Assistant Supervisor or Line Leader for immediate corrective action.		ing parts/tools ss parts/tools			
			<u></u>	Revision History				Prepared by	Checked by	Reviewed by	Approved by		
04/08/25 0	Initial iss	ue.				A.Hernandez H.Loterte	C. Villanueva A. A	Olimon du A. Hernandez	J.Lorente	C. Villanueva	A Association		
Eff. Date Rev. No	0		Details of Ch	hange		Revised Checked	1 1	 	8, 2025	p. vinaridova	7 t. Phiantoo		







			WORK INS		Effectivity Date:	April 8, 2025					
		Process Name/Title:	CLAMI	P ASSEMBL	Y PROCES	SS		Validity Date:		n/a	
		Model code/Part number:	736D / 7R0119-7022	Customer:	TRMX C	ar Model: TOYOTA-TA	ACOMA	Document No.:		WI-ENG-PDE-12	47
		Purpose:	□РКОТОТУРЕ	PRE-LAUNCH		MASSPRO		Revision No.:	0	Page No.:	3 of 8
PARTS:	1. Assy	parts						JIG:	1. Clamp a	ssembly jig	
NO.	PROCESS NAME		WORK PROCEDURE/ ILLUSTRATION				TOOLS/PPE	C	QUALITY POINTERS		
3	Clamp	Connector lock	Counds	pler Cross Se NG Double Half Lock Cond	ectional Vi	ponnector into locking jig us ress 2x to lock using both ock if properly locked.	sing right h hands.	Y .	2. No unloc 3. No skip o	provided locking jick/half-locked conn of locking process reminders/Note/s: LLOCKING MAY CAUS	ector

WORK INSTRUCTION Effectivity Date: April 8, 2025											
		Process Name/Title:		CLAMP A	ASSEMBLY PROC	ESS	Validity Date:		n/a		
		Model code/Part number:	736D / 7	7R0119-7022	Customer: TRMX	Car Model: TOYOTA-TACOMA	Document No.:		WI-ENG-PDE-1	247	
		Purpose:	PROTOTYPE		PRE-LAUNCH	MASSPRO	Revision No.:	0	Page No.:	4 of 8	
PARTS:	1. Assy parts 2. Red tape										
NO.	F	ROCESS NAME		WORK PRO	CEDURE/ ILLUSTR	ATION	TOOLS/PPE	QUALITY POINTERS			
4	Clamp	Clamp assembly	YELL	OR SENSOR LOW TAPE ASSEMBLY 119-7021 BC 1	82711-3A640 (B)	PECEIVED	1. No flip-out tape 2. No peel-off tape 3. No loose tape 4. No missing tape 5. No wrong use of tape 6. No wrong dimension				
			harness). First, set the cor Continue to set the harned detects Yellow tape. Last, press by Toggle clamp. 3. Initially tighten the ban using both hands. 4. Get the bando gun usin band clamp on location 1	ng right hand then cut the Lusing both hands. Press Continue if the sequence was ON.	Receiver base 1 then lock. will beep/buzz if sensor her within the stopper then BANDO GUN LO GOOD of band clamp cutter depends o	2. Check if all LED light for Power On, Claencountered abnormality, STOP and imm the leader. WAIT for further instruction the POSITION ON CLAMP CATION 1	ediately CALL the attention of	FLAT N	BANDO GUN ILLUSTRA GOOD OSEPIECE EXTE	ATION NG NG NDED NOSEPIECE	

			WORK I	Effectivity Date:	April 8, 2025					
			Process Name/Title:	CLA	AMP ASSEMBLY PROC	ESS	Validity Date:		n/a	
		Model code/Part number:	736D / 7R0119-702	2 Customer: TRMX	Car Model: TOYOTA-TACOMA	Document No.:		WI-ENG-PDE-12	47	
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:	0	Page No.:	5 of 8	
PARTS:	1. Assy 2. Red	r Parts tape		JIG:	Clamp assembly jig Bando Gun					
NO.	PROCESS NAME WORK PROCEDURE/ ILLUSTRATION TOOLS/PPE					TOOLS/PPE	QUALITY POINTERS			
4	Clamp	Clamp assembly (Continuation)	COLOR SENSOR YELLOW TAPE SWITCH A SEMBLY TRANS-7-021 NBC TRANS-7-021 NBC TRANS-7-021 TRANS-7-021 TRANS-7-021	SOR 82711-3A640 (B) 82711-26380 (BR)		CONNECTOR SETTING	 No wrong No dama 	g use of parts g use of tape ged clamp g clamp position		
					n 2. Make 3 windings of tape then cut the SW button after taping. Go sound			reminders/Note/s: ire no gap in stoppe	r and	






NE			WORK INSTR	Effectivity Date:	April 8, 2025	April 8, 2025			
		Process Name/Title:	CLAMP	Validity Date:	n/a				
		Model code/Part number:	736D / 7R0119-7022	Customer: TRMX	Car Model: TOYOTA-TACOMA	Document No.:		WI-ENG-PDE-1	247
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:	0	Page No.:	8 of 8
PARTS:	n/a					JIG:	n/a		

VISUAL INSPECTION/QUALITY CHECKPOINTS

CLAMP

7R0119-7022



- 1 No Unlock/ Halflocked Connector
- 2 No Wrong use to Clamp taping (red)
- (3) Check the Clamp
 Alignment
- **4** No Missing Clamp
- 5 No Wrong use of QR Code label
- 6 No Wrong Facing of Clamp

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.