

Process Name/ Title:

PACKING INSTRUCTION

Document No:

WI-ENG-PDE-1218

WORK INSTRUCTION Product Code/Name:

Customer Code:

February 26, 2025

75V117

TRJ

Rev. No.: 0

Effective Date:

Page No.:

Page 1 of 1

100pcs*4bdls

4

No.		Work Procedure/ Illustration		Records/Remarks/ Quality Pointers		
1)	Prepare empty oricon box in the "after inspection area"		Qty/box	400	100pcs	
			Mat'l name	Dim.	Qt	
			Partition board	343*510	3	
			Vinyl bag	545*450	4	
1			ı			

Get the vinyl (plastic) bag then put the 100 pcs harness. Insert products (2) in same direction. Put the ID tag inside then fold the plastic bag.



Put products on standing position and partition board vertically & alternately with the 3 products. (100pcs* 4 Bundles with I.D tag inside)





PBVP connectors must be on top position.

Put NBP Identification tag at the top.Then warehouse Identification **(4)** tag at lower right side of the box

Eff. Date





Note: If need to attach 4M tag Put 4M tag at the left side of the box

Approved Establish Date:

Prepared by Checked by Reviewed by Approved by 02/26/2025 D.Castillo J. Loterte C. Villanueva A. Arañe Initial Issue

Checked

Details of change

February 26, 2025