			WORK INS	STRUCTION					Effect	tivity Date:		January 5, 20	24
		Process Name/Title:	TAPIN	IG ASSEMBL	Y PROC	CESS			Validi	ty Date:		n/a	
		Model code/Part number:	ES1 / 7M0510-7020C	Customer:	TRJ	Car Model:	SUBARU	J-FORESTER	Docu	ment No.:		WI-ENG-PDE-3	66C
		Purpose:	PROTOTYPE	PRE-LAUNCH		MASSI	PRO		Revis	ion No.:	0	Page No.:	1 of 5
PARTS:	1.Assy	Part;Black SV tube (Vinyl)	ø5 L=58±2mm; Clip Attachment (POP-70	067-0); Balck tape)					JIG:	n/a		
NO.	F	PROCESS NAME	WORK	PROCEDURE/	ILLUSTR	ATION				TOOLS/PPE		QUALITY POIN	ITERS
1	P3	Table Lay-out	Black SV tube (Vinyl) ø5 L=58±2mm	Table Lay	/-out	or/ Black	Clip Attacl (POP-700	nment 67-0)	p pr ((Be sure to wear rescribed persons otective equipme during operation gloves, finger cots etc.) Housekeeping Maintain and alwa practice 5's. Personal things the workplace is rohibited. Keep it your locker. Alert level r any trouble, infor Assembly Assist Supervisor or Line eader for immedia corrective action.	al al ant	sing parts/tools ess parts/tools	
			Revision History							Prepared by	Reviewed by	Approved by	Noted by
										o. Castillo	South tillan		
01/05/24 0		ue. Transfer process from WI-EN	NG-PDE-366B to WI-ENG-PDE-366C due to Prod	cess improvement		D. Castillo	C.Villanueva	A. Arañes	n/a	D. Castillo	C. Villanueva	A. Arañes	n/a
Eff. Date Rev. No			Details of Change			Revised	Reviewed	Approved N	oted	Est. Date:	January 5, 2024		



			WORK INS	STRUCTION		Effectivity Date:		January 5, 202	24
		Process Name/Title:		NG ASSEMBLY PRO	CESS	Validity Date:		n/a	
		Model code/Part number:	ES1 / 7M0510-7020C	Customer: TRJ	Car Model: SUBARU-FORESTER	Document No.:		WI-ENG-PDE-36	66C
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:	0	Page No.:	2 of 5
PARTS:		tachment (POP-7067-0) Corrugated tube ø7 L=30±3r	nm (with slit)			JIG:	n/a		
NO.	P	ROCESS NAME	WORK	PROCEDURE/ ILLUST	RATION	TOOLS/PPE	(QUALITY POIN	TERS
2		Clip Attachment (POP-7067-0)		1. Hold the connector using POP-7067-0 (W) then insert	left hand and get the Clip clamp to using right hand.		2. No dam	e clamp attached age clamp ng use of clamp	
3	P3	Half wrap taping to Black Corrugated tube Ø7 L=30±3mm (with slit)	1. Hold the assy parts using left hand, or Black tape using right hand then make windings of tape before shifting.	_ 2. IVIAKE 1/3	shifting until it covers the slit of 2 windings of tape before cutting.	n/a	6. No wron 7. No exportance Importal 1. Please	-off tape e tape sing tape ng use of tape ng dimension used COT, It must output outp	ote/s:

			WORK IN:	STRUCTION		Effectivity Date:		January 5, 202	24
		Process Name/Title:		NG ASSEMBLY PRO	CESS	Validity Date:		n/a	
		Model code/Part number:	ES1 / 7M0510-7020C	Customer: TRJ		Document No.:		WI-ENG-PDE-36	66C
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:	0	Page No.:	3 of 5
PARTS:	1. Assy 2. Black					JIG:	n/a		
NO.	F	PROCESS NAME	WORK	PROCEDURE/ ILLUSTR	RATION	TOOLS/PPE	(QUALITY POIN	TERS
4	P3	Spot Taping	L R	2. Get the other corpre-taping with the tube and vinyl tube	rrugated tube and start combined corrugated tube and start combined corrugated . Make 2 windings. Note: If the Black SV tube ø5 L=60±2mm was used, the Black wires will be stressed/stretched while Y-taping. It must be the Black SV tube ø5 L=58±3mm	Measuring tape 6789 1123456789	1. Please measuring measure 2. Used Y visualiza actual shift. No flip-12. No peel 3. No loos 4. No miss 5. No wron	cellow tape for of tion of shifting line tould be BLACK to the bout tape confirmed tape ing tape ing use of tape ing dimension	erified ting the easy nes , but

			WORK INST			Effectivity Date:		January 5, 202	24
		Process Name/Title:		G ASSEMBLY PRO		Validity Date:		n/a	
		Model code/Part number:	ES1 / 7M0510-7020C	Customer: TRJ	Car Model: SUBARU-FORESTER	Document No.:		WI-ENG-PDE-36	66C
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:	0	Page No.:	4 of 5
PARTS:	1. Assy _l 2. Black	parts SV tube (Vinyl) ø5 L=58±3m	m			JIG:	n/a		
NO.	Р	ROCESS NAME	WORK P	ROCEDURE/ ILLUSTR	ATION	TOOLS/PPE	(QUALITY POIN	TERS
5		n/a	1. Get the Black SV tube (Vinyl) ø5 L=58±3mm using right hand and ins BR-BR wires using left hand.	R sert to				rmed terminal ig usage of parts	
	P3								

Model code/Part number: ES1 / 7M0510-7020C Customer: TRJ Car Model: SUBARU-FORESTER	Validity Date: Document No.: Revision No.: JIG:	n/a WI-ENG-PDE- 0 Page No.:	5 of 5
PARTS: n/a Parts: n/a QUALITY CHECKPOINTS TM0510-7020C	Revision No.:	0 Page No.:	
PARTS: n/a QUALITY CHECKPOINTS 7M0510-7020C			5 of 5
P3	JIG:	n/a	
P3 7M0510-7020C			
No Missing Clip Clamp (2) (3) No Missing Tape (4) No Deform Terr	5	No Deform Termin	