
				WORK INSTRUCTION		Effectivity Date:	July 04, 2024
			Process Name/Title:	TAPING ASSEMBLY PROC	Validity Date:	n/a	
			Model code/Part number:	TM3 / 7L0145-7020A Customer: TRQSS	Car Model: SUBARU-ASCENT	Document No.:	WI-ENG-PDE-714C
<u> </u>			Purpose:	PROTOTYPE PRE-LAUNCH	MASSPRO	Revision No.:	0 Page No.: 1 of 5
PARTS:		1. Assy	parts; Black tape; Light g	JIG:	n/a		
N	Ο.	P	ROCESS NAME	WORK PROCEDURE/ ILLUSTR	TOOLS/PPE	QUALITY POINTERS	
	1		Table lay-out	Table Lay-out  Assy parts	Safety Instruction Be sure to wear prescribed personal protective equipment during operation (gloves, finger cots, etc.)  Housekeeping 1. Maintain and always practice 5's.		
		P3		Tape holder/ Light green tape  Tape holder/ Black tape		2. Personal things on the work place is prohibited. Keep it in your locker.  Alert level For any trouble, inform the Assembly Assistant Supervisor or Line Leader for immediate corrective action.	No deformed terminal     No wrong usage of parts
	Revision History					Prepared by R	eviewed by Approved by Noted by
07/04/24		Initial iss	ue.		a		/orlf ) flee- Villanueva A. Arades n/a
Eff. Date	Rev. No	L		Details of Change	Revised Reviewed Approved N	oted Est. Date: July 0	14, 2024

			WORK INSTRUCTION	Effectivity Date: July 04, 2024		04, 2024	
		Process Name/Title:	TAPING ASSEMBLY PROCESS	Validity Date: n/a		n/a	
		Model code/Part number:	TM3 / 7L0145-7020A Customer: TRQSS Car Model: SUBARU-ASCENT	Document No.:	WI-EN	G-PDE-714C	
		Purpose:	□ PROTOTYPE □ PRE-LAUNCH ■ MASSPRO	Revision No.:	0 Page	No.: 2 of 5	
PARTS: 1. Light green ta 2. Assy parts					n/a		
NO.	PROCESS NAME WORK PROCEDURE/ ILLUSTRATION		TOOLS/PPE	QUALITY POINTERS			
2	P3	Y-Taping	Note: Do not exert excessive force during pulling & winding of tape  2. Start taping at the middle of combined Corrugated tubes, then wind the tape to left side, measurement from end of connector up to end of tape must be 79±3mm.  Tape shifting 1/3 below  3. Wind the tape 1/3 shifting until it reach the other side of corrugated tube (must be tape width)  4. Wind the tape backward 1/2 shifting.  79±3mm  5. Wind the tape 1/2 shifting going to other side of corrugated tube then cut the tape. After taping, check the condition of tape.	MEASURING TAPEA 6 7 8 9 10 1 2 3 4 5 6 7 8 9	Important remin  1. Please use cal measuring tape of measurement. 2. Used Yellow ta	easurement  D FACING  FACING  Inders/Note/s:  Inders/Note/single-single-single-single-single-single-single-single-single-single-single-single-single-single-single-single-single-single-single-single-single-single-single-single-single-single-single-single-single-single-si	

		WORK INSTRUCTION			Effectivity Date:	July 04, 2024					
		Process Name/Title: TAPING ASSEMBLY PROCESS			Validity Date: n/a						
		Model code/Part number:	TM3 /	7L0145-7020A	Customer:	TRQSS Car Model:	SUBARU-ASCENT	Document No.:		WI-ENG-PDE-7	14C
		Purpose:	PROTOTY	PE [	PRE-LAUNCH	MASSE	PRO	Revision No.:	0	Page No.:	3 of 5
PARTS: 1. Black to 2. Assy pa					JIG:	n/a					
NO.	PROCESS NAME WORK PROCEDURE/ ILLUSTRATION		TOOLS/PPE	QUALITY POINTERS							
3	P3	Taping 3 COT to wire near terminal	Start of taping  1. Hold the COT Black tape using pre-taping using  L  20±3mm	using left hand, get the right hand then start both hands.  35 +3mm  0 1 2 8 R	3. Con tape up taping	e from end of COT up to terminent continue the taping production of the second of the	minal pointed tip cess using both hands.  W-1mmfrom end of en continue the		6. No wron	ortant reminders/ ase use calibratecuring tape when gurement.	d/verified letting the



	VORK INSTRUCTION TAPING ASSEMBLY PROCESS	Effectivity Date:	July 04, 2024
Process Name/Title:	Validity Date:	n/a	
	45-7020A Customer: TRQSS Car Model: SUBARU-	J-ASCENT Document No.:	WI-ENG-PDE-714C
Purpose: PROTOTYPE	PRE-LAUNCH MASSPRO	Revision No.:	0 Page No.: 5 of 5
PARTS: 1. Assy parts		JIG:	n/a
	VISUAL INSPECTION/ QUALITY CHECKPOINTS	S	
P3	7L0145-7020	A	
NO GOOD		4	GOOD  NO GOOD
1 No Unlocked/Halfle Connector NO GOOD 2 No Wrong Insert	No Missing / Wrong of Tape ( Light green Ta  4 No Missing Tape	ine)	formed Terminal