

			WORK INSTRUCTION						ffectivity Date:		May 14, 2025		
			Process Name/Title: CLAMP ASSEMBLY PROCESS						alidity Date:		n/a		
			Model code/Part number:	177D / 7L0127-702	0B Customer: TRQSS	Car Model:	TOYOTA-COF	OLLA	Oocument No.:		WI-ENG-PDE-1	1047	
			Purpose:	PROTOTYPE	☐ PRE-LAUNCH	MASSP	RO	R	Revision No.:	2	Page No.:	1 of 7	
PARTS:		1. Assy parts; Clamp 82711-48210 (B); Clamp 82711-3A640 (B); Clamp 82711-35730 (B); Clamp 82711-52090 (W); Black tape [4pcs.]; Gray tape WORK PROCEDURE/ ILLUSTRATION					JIG:	· .	Clamp assembly jig QUALITY POINTERS		
- 140	<i>)</i> .	-	ROCESS IVAIVIL	WORK PROCEDURE/ ILLUSTRATION					TOOLS/FFL	<u> </u>	QUALITI FOIL	TIERO	
		Clamp Assy		Clamp 82711-3A640 (B)/ Clamp tray Clamp 82711-48210 (B)/ Clamp tray					Safety Instruction Be sure to wear prescribed person protective equipment during operation (gloves, finger cottect.)	al ent 1. Refe	1. Refer to WI-ENG-PDE-351A-B for Taping assembly process 1. No missing parts/tools		
1				Assy parts	Clamp 82711-52090 (W)/ Clamp tray			Housekeeping 1. Maintain and alway practice 5's. 2. Personal things the workplace is prohibited. Keep it your locker.	ays on in	82711-52090 (W) CLAMP ILLUSTRATION GOOD			
								Alert level For any trouble, info the Assembly Assist Supervisor or Line Leader for immedia corrective action.	orm cant e eate				
				Clamp assembly jig	Black tape/Tape holder	Gray tape	e/Tape holder				82711-3F290 (В)	
1	1	1		Revision His	story	 	T		Prepared by	Checked by	Reviewed by	Approved by	
05/14/25	2	Update v	vork procedure of clamp assemb	oly process page 3 no.2;page 5 no. 8		A.Buban	n/a C.Villar	ueva A. Araŕ	ies /				
09/25/24		· · · · · ·	rom pre-launch to Masspro.	7 1 F2		M. Ariola	n/a C.Villar		- 61 m/c h.m.		1/out Dillow	7	
09/11/24	0	Initial iss	ue. Seperate clamp assy proces	s from Taping assembly process.		M. Ariola	n/a C.Villar	ueva A. Araŕ		n/a	C. Villanueva	A. Arañes	
Eff. Date	Rev. No			Details of Change		Prepared	Checked Revie	wed Approv	ved Est. Date:	September 11, 2024			








			Effectivity Date:	May 14, 2025					
		Process Name/Title:		MP ASSEMBLY PR		Validity Date:	n/a		
		Model code/Part number:	177D / 7L0127-7020B	Customer: TRQ	SS Car Model: TOYOTA-COROLLA	Document No.:		WI-ENG-PDE-1	047
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:	2	Page No.:	4 of 7
PARTS:	1. Assy	parts				JIG:	1. Clamp a	ssembly jig	
NO.	F	PROCESS NAME	WORK	TOOLS/PPE	(QUALITY POINTERS			
4	Clamp Assy	Clamp assembly (Continuation)	COT 1	OT 2	SW button 3. Remove the assy parts with Black connections the conth hands. 4. Check LED light for POWER, CLAMP, SEQUENCE LIGHT on location 1 was ON abnormality, STOP the process, CALL the instruction. 5. Combine the COT 1 and COT 2 on Side both hands then make 3 windings of tape both hands. Press the SW button using both controls are set to the set of the set of the controls and cott	WIRE1&WIRE2, If encountered leader and WAIT for A' Location 1 using then cut the tape using	1. Make terminals 2. Make 1. No wron 2. No dams 3. No miss	2-3 windings for of graph of clamp aged clamp ing clamp ing use of tape	een stopper and

WORK INSTRUCTION Effectivity Date:								May 14, 2025			
		Process Name/Title:	CLAM	Validity Date:	n/a						
		Model code/Part number:	177D / 7L0127-7020B	Customer: TRQSS	Car Model: TOYOTA-COROLLA	Document No.:	WI-ENG-PDE-1047				
		Purpose:	□PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:	2	Page No.:	5 of 7		
PARTS:	1. Assy	parts				JIG:	1. Clamp a	ssembly jig			
NO.	F	PROCESS NAME	WORK F	TOOLS/PPE	(QUALITY POINT	ERS				
5	PROCESS NAME Clamp Assy Clamp assembly (Continuation) Clamp Assy Clamp assembly (Continuation) Compassembly (Continuation) Com		COT 2 Side B Side B/ Location 2 ags of tape then cut the button using both make 3 windings of tape tress the SW button after	CHECKER 2 3 CHECKER 2	ds press the SW button. ter pressing of SW button. nake 3 windings of tape less the SW button after	1. Make a terminals 2. Make 2 1. No wron 2. No dama 3. No miss	2-3 windings for cla g use of clamp aged clamp ing clamp g use of tape	en stopper and			



		WORK INSTRUCTION E						Effectivity Date:	May 14, 2025		
		Process Name/Title:	CLAMP ASSEMBLY PROCESS					Validity Date:	n/a		
		Model code/Part number:	177D / 7L0127-7020B	Custo	ner: TRQS	Car Model:	TOYOTA-COROLLA	Document No.:		WI-ENG-PDE-10)47
		Purpose:	PROTOTYPE	☐ PRE-LA	JNCH	MASSPI	RO	Revision No.:	2	Page No.:	7 of 7
PARTS: 1. Assy parts						JIG:	n/a				
	VISUAL INSPECTION/ QUALITY CHECKPOINTS										

CLAMP ASSY

7L0127-7020B



1 No Wrong facing of clamp

2 3 No Missing Tape (Black tape)

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.