
			WORK INS	Effectivity Date: February 2			125			
		Process Name/Title:		IG ASSEMBLY PRO			Validity Date:		n/a	
		Model code/Part number:	559D / 7N0242-7020A	Customer: TRJ	Car Model:	TOYOTA HI-ACE	Document No.:		WI-ENG-PDE-118	82B
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSP	PRO	Revision No.:	0	Page No.:	1 of 6
PARTS:		parts; Clamp 82711-1E360 (V	V); Black SV tube (Vlnyl) ø5 L=535±2mm ; S		JIG:	QUALITY POIN	TERS			
NO.	Г	ROCESS NAME	WORK	PROCEDURE/ ILLUSTF	ATION		100L3/FFE	1	QUALITIFOIN	IENO
1	P2	Table lay-out	Clamp 82711- 1E360 (W) Tray Assy parts	TABLE LAY-OU	Black S	V tube (Vinyl) ø5 =535±2mm	Safety Instruction Be sure to wear required personal protective equipment during operation (gloves, finger cots, etc.) Housekeeping 1. Maintain and always practice 5's. 2. Personal things on the workplace is prohibited. Keep it in your locker. Alert level For any trouble, inform the Assembly Assistant Supervisor or Line Leader for immediate corrective action.		ing parts/tools ss parts/tools	
				Sky Blue tape/ Tap	e holder					
	I		Revision History				Prepared by (Checked by	Reviewed by	Approved by
02/26/25 0	Initial issu	ue.			D.Castillo	a	rañes Castillo	J. Leterte	Sort House	A. Aranes
Eff. Date Rev. No			Details of Change		Revised	Checked Reviewed App	proved Est. Date: Febru	uary 26, 2025		



			WORK INSTR	Effectivity Date:	February 26, 2025							
		Process Name/Title:	TAPING	LY PROC	Validity Date:	n/a						
		Model code/Part number:	559D / 7N0242-7020A	Customer:	TRJ	Car Model:	TOYOTA HI-ACE	Document No.:		WI-ENG-PDE-11	82B	
		Purpose:	☐ PROTOTYPE ☐	PRE-LAUNCH	1	■ MASSP	RO	Revision No.:	0	Page No.:	2 of 6	
	1. Clamp 82711-1E360 (W) 2. Assy parts								n/a			
NO.	F	ROCESS NAME	WORK PRO	OCEDURE	/ ILLUSTR	ATION		TOOLS/PPE	(QUALITY POIN	TERS	
2	P2	Clip attachment (Clip type clamp)	1. Hold the Connector using left hand, get using right hand. Note: Follow the illustration. Sound will.		Clamp 8271		then insert the clamp		2. No dama 3. No missi	CLIP CLAMP ILLUST	2360 (W)	

NB			WORK INSTR	Effectivity Date:	February 26, 2025				
		Process Name/Title:	TAPING	ASSEMBLY PROC	Validity Date:	n/a			
		Model code/Part number:	559D / 7N0242-7020A	Customer: TRJ	Car Model: TOYOTA HI-ACE	Document No.:		WI-ENG-PDE-118	32B
		Purpose:	PROTOTYPE	PRE-LAUNCH	■ MASSPRO	Revision No.:	0	Page No.:	3 of 6
PARTS:	1. Assy 2. Sky E			JIG:	n/a				
NO.	F	PROCESS NAME	WORK PR	TOOLS/PPE		QUALITY POIN	ΓERS		
			42042,000		Stort toning				



			Effectivity Date:	February 26, 2025							
		Process Name/Title:	TAPIN	G ASSEN	IBLY PRO	Validity Date: n/a					
		Model code/Part number:	559D / 7N0242-7020A	Custome	er: TRJ	Car Model:	TOYOTA HI-ACE	Document No.:		WI-ENG-PDE-118	82B
		Purpose:	☐ PROTOTYPE	PRE-LAU	NCH	MASSF	PRO	Revision No.:	0	Page No.:	4 of 6
PARTS:	1. Assy 2. Sky B		WORK PROCEDURE/ ILLUSTRATION					JIG: TOOLS/PPE	n/a QUALITY POINTERS		
5		Taping 2 Black corrugated tube to Black SV tube (Vinyl)	Start taping 1. Get the Sky blue tape using right hand then start taping process using both hands. 25±3mm 25±3mm 25±3mm 3. After taping, check the measurements	3	2. Hold the as measure from 25±3mm. The hands.	25±3m 3 0 1 ssy part using a end of tape en continue ta	2 3 4 I left hand and up to end of COT aping using both		Import 1. Plea measu Docum 1. Refe taping 1. No flip-o 2.No peel-c 3. No loose 4. No wron 5. No wron 6. No missi	tant reminders are use use calibrated uring tape when gurement. ment reference/s: er to WI-PRO-AS's procedure. The procedure of tape is tape in tape	nd Note/s: d/verified getting the

			WORK INS					Effectivity Date:	February 26, 2025		
		Process Name/Title:	TAPIN	Validity Date:	n/a						
		Model code/Part number:	559D / 7N0242-7020A	Customer:	TRJ	Car Model:	TOYOTA HI-ACE	Document No.:		WI-ENG-PDE-118	32B
		Purpose:	☐ PROTOTYPE	☐ PRE-LAUNCH	l	■ MASSF	PRO	Revision No.:	0	Page No.:	5 of 6
PARTS:	1. Assy	parts ROCESS NAME	WORK F	PROCEDURE/	'ILLUSTR	ATION		JIG: TOOLS/PPE	n/a	QUALITY POIN	TERS
6	P2	Measurement	3 575 ±3 2 35 ±3 SV Tube (B) Ø5 O NOTE: A - Taping (Sky Blue) B - Taping (B) C - Clamp (W) *Unit of measurement is in millimeter (r	4	±3 25 ±3		<u>СОТ(В) Ø7</u>		1. Pleas measuri measuri 2. For H Docum 1. Refer assembl Owarimo	ant reminders and se use calibrated/ving tape when genement. Idatsumono and Original reference/vito WI-PRO-ASY-City Hatsumono Nakono Inspection and dimension	verified tting the warimono. S: 056 for Sub-


		WORK INS	Effectivity Date:	February 26, 2025				
	Process Name/Title:	TAPIN	Validity Date:	n/a				
	Model code/Part number:	559D / 7N0242-7020A	Customer: TRJ	Car Model: TOYOTA HI-ACE	Document No.:		WI-ENG-PDE-11	82B
	Purpose:	☐ PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:	0	Page No.:	6 of 6

PARTS:1. Assy partsJIG:n/a

VISUAL INSPECTION/ QUALITY CHECKPOINTS

TAPING - P2

7N0242-7020A



- 1 No Missing Clip Clamp
- 2 No Missing tape

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.