
I					WORK INSTRUCTION			T=#					
			Process Name/Title:	<u>\</u>		tivity Date: ity Date:		October 22, 2024 n/a					
			Model code/Part number:	800B/900B/910B / /N	10101-7020D Customer: TRJ	Car Model:	LEXUS-NX/RX	Docu	ment No.:		WI-ENG-PDE-1	143	
			Purpose:	PROTOTYPE	☐ PRE-LAUNCH	MASSPE	RO	Revis	sion No.:	1	Page No.:	1 of 5	
PARTS:			nector 6098-3810 (W) SV tube (Vinyl) ø5 L=69±3m	3. AVSSf 0.3 B-B m		JIG:	1. Inserti	Insertion jig 2. Locking jig					
N	0.	Р	PROCESS NAME WORK PROCEDURE/ ILLUSTRATION						TOOLS/PPE		QUALITY POINTERS		
		Offline	Table Lay-out	Connector 6098-3810 (W)/ Connector bin box Insertion	AVSS 0 L=67	Black SV tub (Vinyl) ø5 L=69±3mm	NA	for price of the Sur	Be sure to wear prescribed persona rotective equipmenting operation (glow finger cots, etc.) Housekeeping Maintain and alwa practice 5's. Personal things on the properties of the provided and provided in the provided and prov	Docum 1. Refe and St ys the ed. 1. No i 2. No i mn nt der	nent reference/s: er to WI-PRO-CNC- rip Length Toleran missing parts/tools excess parts/tools	ce	
				Revi	ision History				Prepared by	Reviewed by	Approved by	Noted by	
									-				
10/22/24 1 Change Pre-launch to Masspro A. A. Arañes n/a A. A. Arañes n/a							AND THE REST OF THE PERSON OF						
10/17/24	0	Initial Iss	ue.			A. Hernandez	C. Villanueva A. Arañes	n/a	A. Hernandez	C. Villanueva	A. Aranes	n/a	
Eff. Date	f. Date Rev. No Details of Change Revised Reviewed Approved Noted Est. Date: October 17, 2024												



			WORK INSTRUCTION	Effectivity Date:	October 22, 2024				
		Process Name/Title:	OFFLINE ASSE	Validity Date:	n/a				
		Model code/Part number:	800B/900B/910B / 7N0101-7020D Custom	er: TRJ Car Model:	TRJ Car Model: LEXUS-NX/RX		WI-ENG-PDE-1143		
		Purpose:	□PROTOTYPE □ PRE-LAU	NCH MASSPRO)	Revision No.:	1	Page No.:	3 of 5
PARTS:	1. Black	SV tube (Vinyl) ø5 L=69±3n	nm 2. AVSSf 0.3 B-B wires L=679±3mm 3. C	connector 6098-3810 (W)	JIG:	1. Inserton jig			
NO.	Р	ROCESS NAME	WORK PROCEDU	RE/ ILLUSTRATION	TOOLS/PPE	C	QUALITY POINT	ERS	
3		Wire insertion to Black SV tube (Vinyl) ø5 L=69±3mm	L	1. Get the Black SV tube L=69±3mm using right h B-B wires using left han	and then insert the	n/a	1. No wrong 2. No deforn	ned terminal	
4	Offline	Wire insertion to connector 6098-3810 (W)	1. Get 1st black wire then insert to terminal slot 1 using right hand.		2 Black R to terminal slot 2 using	n/a	 No loose insertion No wrong insertion One by one insertion No deformed terminal No wrong wire facing Important reminders/Note/s: Please hold the wire near terminal. Make sure wires are properly inserted. Conduct Pull-Push-Pull-Push after 		
				Note: Conduct Pull-Push-Pull-Push rtion, push the lock using left thumb es and gently pull out the connector	and then		Document 1. Refer to Push proc 2. Refer to	ert extra force. t references: o GL-PRO-ASY-02 cedure. o WI-PRO-CNC-01 Length Tolerance	17 for Wire


			V	Effectivity Date:	October 22, 2024						
		Process Name/Title:		OFFLINE ASSEM		CESS		Validity Date:	n/a		
		Model code/Part number:	800B/900B/910B / 7N0101-7020D Customer: TRJ Car Model: LEXUS-NX/RX				Document No.:	WI-ENG-PDE-1143			
		Purpose:	PROTOTYPE	☐ PRE-LAUN	ICH	MASSPF	RO	Revision No.:	1	Page No.:	4 of 5
PARTS:	1. Assy parts				1. Locking jig						
NO.	F	PROCESS NAME		TOOLS/PPE	QUALITY POINTERS						
5	Offline	Connector Lock	2. Ensure that connects sequence illustrated.	R R R R R R R R R R R R R R R R R R R	using right h both hands. to confirm if	onnector into locionand then press 2 Touch the connector properly locked R 2 Pressing	Lx using ector lock	LOCKING JIG	Important 1. MANU DAMAGI Docume 1. Please for the wlock.	e provided jig peock/half-locked of the reminders/No DAL LOCKING MARIED CONNECTOR Interest of the refer to GL-PROPERTY (CONNECTOR LOCK CONNECTOR LOCK CONNEC	onnector ote/s: AY CAUSE O-ASY-017 nnector

	6		Effectivity Date: October 22, 2024			24					
		Process Name/Title:		Validity Date: n/a							
		Model code/Part number: 800B/900B/910B / 7N0101-7020D Customer: TRJ Car Model: LEXUS-NX/RX				Document No.:	WI-ENG-PDE-1143				
		Purpose:	PROTOTYPE		PRE-LAUNCH	l	MASSPR	0	Revision No.:	1	Page No.:
PARTS: 1. Assy part							JIG:	n/a			
VISUAL INSPECTION / OUALITY CHECKPOINTS											

OFFLINE INSERTION

7N0101-7020D





- 1 No Unlocked / Halflocked Connector
- 2 No Wrong Insert

- 3 No Terminal Backing Out
- 4) No Deformed Terminal

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.