

					ISTRUCTION				Effectivity Da	ate:		September 19, 2	2024
			Process Name/Title:		NG ASSEMBLY PROC	1			Validity Date			n/a	
			Model code/Part number:	920B / 7R0122-7022	Customer: TRMX	Car Model:	TOYOTA	-TACOMA	Document N	0.:		WI-ENG-PDE-72	21C
			Purpose:	☐ PROTOTYPE	☐ PRE-LAUNCH	■ MASS	PRO		Revision No.	:	2	Page No.:	1 of 6
PARTS:			parts: White tape							JIG:	n/a		
NO	Ο.	Р	ROCESS NAME	WORK	PROCEDURE/ ILLUSTRA	ATION			TOC	LS/PPE	(QUALITY POIN	TERS
					Table Lay-out				Be su prescrib protectiv during (gloves	Instruction ire to wear bed persona e equipmer g operation , finger cots, etc.)	nt		
1		Р3	Table lay-out	Assy parts					1. Mainta prac 2. Perso the we prohibite	ekeeping in and alway ctice 5's. nal things or orkplace is ed. Keep it ir r locker.	n 1. No missii	ng parts/tools s parts/tools	
						hite tape/ pe holder			For any t the Asser Superv Leader f	ert level rouble, infor mbly Assista risor or Line or immediat- tive action.	nt		
				Revision History									
				Revision History					Pre	pared by	Reviewed by	Approved by	Noted by
09/19/24	2	Inclusion	of Measuement and improved Vis	ual inspection/Quality checkpoint.		D.Castillo	C. Villanueva		ı/a				
09/06/23	1	Change p	ourpose from pre-launch to mass p	oro.		M. Manalac	J. Lotere V	/ilianueva	rañes	7	1/1-11	Alm	
09/01/23	0	Inititial iss	sue.			M. Manalac	 	/illanueva	/ D.	Castillo	C. Villanueva	A. Aranes	n/a
Eff. Date	Rev. No			Details of Change		Revised	Reviewed A	Approved No	oted Est. Da	te: S	September 01, 2023		



			WORK IN	STRUCTION		Effectivity Date:	1	September 19, 2	024
		Process Name/Title:		NG ASSEMBLY PROC	ESS	Validity Date:		n/a	
		Model code/Part number:	920B / 7R0122-7022	Customer: TRMX	Car Model: TOYOTA-TACOMA	Document No.:		WI-ENG-PDE-72	21C
		Purpose:	☐ PROTOTYPE	PRE-LAUNCH	■ MASSPRO	Revision No.:	2	Page No.:	2 of 6
PARTS:	1. Assy 2. White					JIG:	n/a		
NO.	F	PROCESS NAME	WORK	PROCEDURE/ ILLUSTRA	ATION	TOOLS/PPE	(QUALITY POIN	TERS
NO. 2	P3	Spot taping 4		1. Fix the C Note: Align beside the illustration.	Connector and the twisted tube. Inment of twisted tube must be Connector. Follow the	MEASURING TAPE 6 7 8 9 10 1 2 3 4 5 6 7 8 9 10 10 10 10 10 10 10 10 10 10 10 10 10	Importa 1. Plea: measui measui 1. No flip-c 2. No peel 3. No loose 4. No miss 5. No wor	ant reminders/Nose use calibrated, ring tape when gerement. but tape off tape e tape	te/s: /verified
			R	3. Get the White tape windings of tape using	using right hand then conduct 2 both hands.				

				STRUCTION		Effectivity Date:		September 19, 2	024
		Process Name/Title:	TAPIN	NG ASSEMBLY PR		Validity Date:		n/a	
		Model code/Part number:	920B / 7R0122-7022	Customer: TRN	MX Car Model: TOYOTA-TACOMA	Document No.:		WI-ENG-PDE-72	21C
		Purpose:	☐ PROTOTYPE	☐ PRE-LAUNCH	■ MASSPRO	Revision No.:	2	Page No.:	3 of 6
PARTS:	1. Assy 2. White					JIG:	n/a		
NO.	F	PROCESS NAME	WORK	PROCEDURE/ ILLUS	STRATION	TOOLS/PPE	(QUALITY POIN	TERS
3	P3	Y-taping	taping direction 1/3 shifting	2. M 11± and 1/3 R 3. V their rear	1. Fix the Twisted tube to the side of the Connector. Note: Follow the correct facing. Measure from Connector to tape 1mm. Then, start taping the connector I twisted tube, make 2 windings before shifting upward. Winding the tape upward 1/3 shifting, n conduct 1/2 shifting upward until it ch the SV tube (Vinyl). Make 2 indings, width must be 20±3mm.	MEASURING TAPE 6 7 8 9 10 1 2 3 4 5 6 7 8 9 10 10 10 10 10 10 10 10 10 10 10 10 10	Importa 1. Use visualiz actual s 2. Pleas measur measur 1. No flip-or 2. No peel-or 3. No loose 4. No missi 5. No wrong 6. No wrong	ant reminders/Not YELLOW TAPE for vation of shifting is should be <u>WHITE</u> se use calibrated/ ring tape when ge ement.	e/s: or easy lines, but TAPE. (verified





Pro	ocess Name/Title:		STRUCTION NG ASSEMBLY PRO	CESS.	Effectivity Date: Validity Date:		September 19,	2024
	odel code/Part number:	920B / 7R0122-7022	Customer: TRMX	Car Model: TOYOTA-TACOMA	,		WI-ENG-PDE-72	1C
	ırpose:	☐ PROTOTYPE	☐ PRE-LAUNCH	■ MASSPRO	Revision No.:	2	Page No.:	6 (
: 1. Assy part	rts				JIG:	n/a		
			SUAL INSPECTION/ QU					
TA	PING	2 vis		7R0122	-702	22		
TA	PING				-702	22		
TA	PING				-702	22		

1 No Missing tape (Y-taping)

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.