
	WORK INSTRUCTION							June 27, 2024		
			Process Name/Title:		TAPING ASSEMBLY PROC	Effectivity Date: Validity Date:	n/a			
			Model code/Part number:	311D /	7N0195-7020Ea Customer: TRJ	Car Model: TOYOTA-RAV4	Document No.:		WI-ENG-PDE-9	19C
			Purpose:	PROTOTYPE		MASSPRO	Revision No.:	0	Page No.:	1 of 5
PARTS:	2	3. Black	VM tube (Sunprene) ø9, L= tape	97±3mm			JIG:	n/a		
NO.		F	PROCESS NAME		WORK PROCEDURE/ ILLUSTR	ATION	TOOLS/PPE	(QUALITY POIN	TERS
1		P3	Table lay-out		TABLE LAY-OU Assy parts Tape holder/Black tape	Black VM tube (Sunprene) ø9, L=97±3mm	Safety Instruction Be sure to wear prescribed personal protective equipment during operation (gloves, finger cots, etc.) Housekeeping 1. Maintain and always practice 5's. 2. Personal things on the workplace is prohibited. Keep it in your locker. Alert level For any trouble, inform the Assembly Assistant Supervisor or Line Leader for immediate corrective action.	1. No missi 2. No exce	ing part/tools. ss parts/tools	
-	Revision History						Prepared by F	Reviewed by	Approved by	Noted by
6/27/24 Eff. Date Re		Initial Issu	ie.	Details of Ch	range	M. Ariola C. Villanueva A. Arañes Revised Reviewed Approved		S. Villanueva	A.	n/a
•				· -						

		Effectivity Date: June 27, 2024								
	Process Name/Title:	Validity Date:	n/a							
	Model code/Part number:	311D /	7N0195-7020Ea Custome	r: TRJ	Car Model:	TOYOTA-RAV4	Document No.:		WI-ENG-PDE-91	9C
	Purpose:	PROTOTYPE	PRE-LAUN	ICH	MASSPR	RO	Revision No.:	0	Page No.:	2 of 5
		JIG:	JIG: n/a							
PROCESS NAME WORK PROCEDURE/ ILLUSTRATION							TOOLS/PPE	G	QUALITY POIN	TERS
	Wire insertion to Black VM tube (Sunprene) ø9, L=97±3mm	1		L=97±3mm usi	ing right hand	then insert the	n/a	1. No wrong	use of parts.	
P3	Taping 3 Black Corrugated tube to VM tube (Sunprene)	1. Measure the up to hotmelted	e end of VM tube (Sunprene) d wires L=31±3mm.	2. Hold th hand, get using righ	ne VM tube (See the Black tagent hand.	pe then start taping	## MEASURING TAPE 6 7 8 9 10 1 2 3 4 \$ 6 7 8 9 1	1. Please measurin measure 1. No peel- 2. No flip of 3. No loose 4. No wrong 5. No wrong	e use calibrated/v. ng tape when fetti ment. off tape ut tape tape g use of tape g dimension	erified
	2. Black	Model code/Part number: Purpose: 1. Assy parts 2. Black VM tube (Sunprene) Ø9, L=9 PROCESS NAME Wire insertion to Black VM tube (Sunprene) Ø9, L=97±3mm P3 Taping 3 Black Corrugated tube to	Model code/Part number: 311D / Purpose:	Process Name/Title: TAPING ASSEM Model code/Part number: 311D / 7N0195-7020Ea Custome Purpose: PRE-LAUN 1. Assy parts 2. Black VM tube (Sunprene) ø9, L=97±3mm PROCESS NAME Wire insertion to Black VM tube (Sunprene) ø9, L=97±3mm Wire insertion to Black VM tube (Sunprene) ø9, L=97±3mm R 1. Measure the end of VM tube (Sunprene) up to hotmelted wires L=31±3mm. Taping 3 Black Corrugated tube to VM tube (Sunprene) Up to hotmelted wires L=31±3mm. 25±3mm 31±3mm 31±3mm 31±3mm 31±3mm 31±3mm	Model code/Part number: 311D / 7N0195-7020Ea Customer: TRJ Purpose: PROTOTYPE PRE-LAUNCH 1. Assy parts 2. Black VM tube (Sunprene) e9, L=97±3mm PROCESS NAME WORK PROCEDURE/ ILLUSTR. Wire insertion to Black VM tube (Sunprene) e9, L=97±3mm us not melted wires not melted wires not melted wires not melted wires labeled wire	Process Name/Title: TAPING ASSEMBLY PROCESS Model code/Part number: 311D	Process Name/Title: TAPING ASSEMBLY PROCESS Model code/Part number: 311D	Purposes Namer/Itle: TAPING ASSEMBLY PROCESS Model code/Part number: 311D / 7N0195-7020Ea Customer: TRJ Car Model: TOYOTA-RAV4 Document No.: Purpose: 1. Assy parts 2. Black VM tube (Sunprene) e9, L=97-25mm Wire insertion to Black VM tube (Sunprene) e9, L=97-23mm Wire insertion to Black VM tube (Sunprene) e9, L=97-23mm I. Get the Black VM tube (Sunprene) e9, L=97-23mm I. Get the Black VM tube (Sunprene) e9, L=97-23mm I. Measure the end of VM tube (Sunprene) I. Measure the end of	Process Name/Title: TAPING ASSEMBLY PROCESS Validity Date: Model code/Part number: 311D	Piocess NamerTitle: TAPING ASSEMBLY PROCESS Validity Date: Na Witer Investigation to Black VM Tube (Surprene) ed. Le97.3mm Page Moci. 1. Measure the end of VM tube (surprene) Taping 3 Black Corrugated tube to VM tube (Surprene) Taping 3 Black Corrugated tube to VM tube (Surprene) 1. Measure the end of VM tube (surprene) Taping 3 Black Corrugated tube to VM tube (Surprene) Taping 3 Black Corrugated tube to VM tube (Surprene) Taping 3 Black Corrugated tube to VM tube (Surprene) Taping 3 Black Corrugated tube to VM tube (Surprene) Taping 3 Black Corrugated tube to VM tube (Surprene) Taping 3 Black Corrugated tube to VM tube (Surprene) Taping 3 Taping 3 Taping 3 Black Corrugated tube to VM tube (Surprene) Taping 3 Taping 4 Tapi





			Effectivity Date:	June 27, 2024								
		Process Name/Title:		WORK INST	G ASSEMBLY	PROCES	SS		Validity Date:	n/a		
		Model code/Part number:	311D /	7N0195-7020E	a Customer: TF	SJ Ca	ar Model:	TOYOTA-RAV4	Document No.:		WI-ENG-PDE-9	19C
		Purpose:	PROTOTYPE		PRE-LAUNCH		MASSPRO	0	Revision No.:	0	Page No.:	4 of 5
PARTS:	n/a								JIG:	n/a		
NO.	F	ROCESS NAME		WORK P	ROCEDURE/ ILL	USTRAT	ION		TOOLS/PPE	(QUALITY POIN	TERS
5	P3	Measurement	© 108±3 NOTE: (A) - Taping (B) (S) - dimension of overlapped St	25±5	©25±5	® 25 @ 25 # 25 # 25 # 25 # 25 # 25 # 25 #	5 +5	No. Co	TYPE TABLE Plor Wire Type G TVSS 0.3 f TVSS 0.3 f WEASURING TAPE	1. Pleas measuri measuri 2. For H Owarim Docum 1. Pleas Sub-Ass	tant reminders/No e use calibrated/ ing tape when fet ement. atsumono, Nakar	verified ting the nono and

		Effectivity Date:	Effectivity Date: June 27, 2024						
		Process Name/Title:		WORK INSTRUCTION TAPING ASSEMBLY PR	Validity Date:	n/a			
		Model code/Part number:	Document No.:	WI-ENG-PDE-919C					
		Purpose:	311D / □ PROTOTYPE	7N0195-7020Ea Customer: TRJ ☐ PRE-LAUNCH	Car Model: TOYOTA-RAV4 MASSPRO	Revision No.:	0	Page No.:	5 of 5
							1		
PARTS:	n/a					JIG:	n/a		
				QUALITY C	HECKPOINTS				
P3				7N010	95-7020Ea				
				714013	70				
									ľ
500						1			
								_	
						and the same of th	-		
							108		
	-				1000000000				The second

								2	
						3			THE STATE OF
		NI- NAICCI							
	(1) No MISSI	ING VIVI t	ube 2 3	No MISSING TAPI	E			
		Sunpren							
		(Sumpren							