

Process Name/ Title:
PACKING INSTRUCTION
WORK INSTRUCTION

NSTRUCTION Effective Date:

**TRMX** 

Document No:

2

WI-QAD-QAC-185

July 2, 2024

Product Code/Name: **7R0102** 

Customer Code:

Rev. No.:

Page No.:

Page 1 of 1

No.	Work Procedure/ Illustration					Records/Remarks/ Quality Pointers			
				1		Qty/box	100pcs.		25pcs* 4bdls.
1	Put Vinyl Sheet (1250 x 1250)				Mat'l name	Dim.		Qty.	
					TRMX box	544*370° 228mm		1	
	inside TRMX box.				<u></u>	Vinyl sheet	1250*125	0	1
			15			Partition board	343*510	,	1
				Plant	vinyl bag of	Plastic Vinyl bag	420*280		4
2	Put 2bdls of products. (25pcs/bdl) in opposite direction.			MR	Vinyi bag or SW assy	Note: 1. Step numbe	er 5 is applicabl	e only in	FG Inspection
3	Put partition board								
4	Put 2bdls of products. (25pcs/bdl) in opposite direction.								
(5)	Fold the vinyl sheet. Put NBP Identification tag at the top and tape the flaps (two side and top portion). Then Warehouse Identification tag at the right side of the box.		Note	: If need to attach Put 4M tag at the le	4M tag eft side				
07/02/2024	0 0 0	<u> </u>	S. Malabuyoc	R. Pascua	O. Merin	Prepared	Checked	Approve	d Noted
08/16/2021	2 Change vinyl sheet size to 1250 x 1250  Transfer document from WI-ENG-PDI 1 610*381*178mm to 544*370*228m	E-211 to WI-QAD-QAC-185. Change dimension of the box from m and change size of partition board from 343*580 to 343*510	C. Dimailig	M. Lumbres	E. Mendoza	Cmaldeyu	MJ 1	184	
12/01/2020 Eff./Rev. Date	0 Rev. No.	Initial Issue	R. Peñaloza Prepared	A. Shimamura Checked	A. Arañes Approved	5. Malabuyou Est. date:	Pascua December 1, 2020	O. Merin	N/A
tot. Date		Details of change			. <del></del>	_01. 0016.			

CONFIDENTIAL: ©2017 NBC; all rights reserved. Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

NBC (Philippines)
MASTER COPY