


Process Name/ Title: HOTMELT-Set of Molding				WI-PRO-SHM-038			
			lo:				
WORK INSTRUCTION		Effective Da	ite:	May 7, 2025			
Product Code/Name:	Customer Code:	Rev. No.:	4	Page No.:	1 of 1		
A 1 1	A I I	INEV. NO		Page No	1 01 1		

ALL

No. Work Procedure/ Illustration Records/Remarks/ Quality Pointers



ALL



Shut area sensor down by left hand (Pic.1), and hold PCB in order ① ~ ④ (Pic. 2).
 →If area sensor repeats [ON] and [OFF], it becomes [defect of area sensor], and equipment is stopped.


## ■ What is defect of area sensor?

 $\bullet$  As safety function, there are area sensors on molding machine. (left and right) (Ref: Photo 1)

If area sensor repeats [O N] and [O F F], [Defect of area sensor] will be apeared. (Ref: Photo ②)

Defect of area sensor (Servo amplifier side) is [Prevent entering resistance heating] defect, so this defect is appeared by tempareture of resistance component which is in amplifier.

Therefore, it needs time to cool after defect appears due to component's heating.



## Color and condition of area sensor

 Condition when it is not shuting down by hand.
 →Light in Green.  Condition when it is shuting down by hand.
 →Light in Red.







- When defect of area sensor is appeared
  - Stop line and report to immediate superior (Stop/Call/Wait)

						Prepa	re	Check	Approve
						د ار لار		$\circ$ $'$	0.01
5/7/2025	1	General revision , change customer code	L.Famodulan	A. Ayop	W. Carbillon	2 pmg d	100	( Smot	Squam
8/15/2017	0	Initial issue.	A. Yocor	O. Merin	T. Sugiyama	L.Famoo	lulan	A. Ay60	W. Carbillon
Eff./Rev. Date	Rev. No.	Details of change	Revise	Check	Approve	Est. da	te:	August	15, 2015

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

NBC (Philippines)
MASTER COPY