

No.

(1)

2

Process Name/ Title:							
PACKING INSTRUCTION							

Work Procedure/ Illustration

Document No:

Effective Date:

2

WI-QAD-QAC-137

July 5, 2024

Records/Remarks/

WORK INSTRUCTION
Product Code/Name:
7L0083

Customer Code: TRQSS

Rev. No.:

Page No.:

Page 1 of 1

Put Vinyl Sheet (1250 x 1250) inside carton box.



 Quality Pointers

 Qty/box
 90
 45pcs *2bdls

 Mat'l name
 Dim.
 Qty.

 DC carton
 1131*781
 1

 Vinyl sheet
 1250*1250
 1

 Vinyl bag
 420*280
 2

Put first bdl of products. (45pcs/bdl)



Note: /2\
Step number 5 is applicable only in **QC FG Inspection.**

Put second bdl on upper with opposite direction (45pcs/bdl)



Fold the vinyl sheet.



Close the flaps and put NBP Identification tag at the top of the plastic and Warehouse Identification tag at the right side of the front of the box .





Note: If need to attach 4M tag Put 4M tag at the left side

						Prepare	Check	Approve	
7/05/2024	2	Change Vinyl Sheet Size from 1520x1500 to 1250x1250; Change picture of no. 1; Modify no. 4 and Addition of no. 5; Add note.	J. De La Cruz	D.Dadulla	R.Pascua	2/		M	
8/27/2022	1	Update step no. 4 regarding 4M tag location	M. Garcia	R.Alcantara	A.Arañes		(Max		
08/29/2019	0	Initial issue	C.Dimailig	M.Lumbres	E.Mendoza	J. De La Cruz	D.Dadulla	R.Pascua	
Eff./Rev. Date	Rev. no.	Details of change	Prepared	Checked	Approved	Established. date:	August 29, 2019		

CONFIDENTIAL: ©2017 NBC; all rights reserved. Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited. NBC (Philippines)

MASTER COPY