				WORK INST				ffectivity Date:		June 11, 20	24
			Process Name/Title:		E ASSEMBLY PROC			/alidity Date:		n/a	
		7	Model code/Part number:	ES1 / 7M0503-7020A	Customer: TRJ	Car Model: SUBARU-FORES				WI-ENG-PDE-	
			Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO	F	Revision No.:	2	Page No.:	1 of 5
PARTS:	<u></u>	L=798±	5mm	(W)-((With clip clamp 82711-1E360 (W)); /				JIG:	1. Locking		
N	0.	Р	ROCESS NAME	WORK PI	ROCEDURE/ ILLUSTRA	ATION		TOOLS/PPE		QUALITY POIN	ITERS
1		Offline	Table Lay-out	Locking jig		2-1026 (W)/ Connector Tray clamp 82711-1E360 (W))  Black SV tube (Vinyl) ø5 L=798±5mm  AVSSf 0.3 B wires L=884±3mm		Safety Instruction Be sure to wear prescribed persons protective equipmed during operation (gloves, finger cots etc.)  Housekeeping 1. Maintain and alway practice 5's. 2. Personal things of the workplace is prohibited. Keep it your locker.  Alert level For any trouble, inforthe Assembly Assist Supervisor or Line Leader for immedia corrective action.	Docum  1. Refer and Strip 2. Refer Clip Clai  1. No mis 2. No except in	ent reference/s to WI-PRO-CNC Length Tolerand to WI-PRO-KIT-Omp Attachment sing parts/tools ess parts/tools	<b>-017</b> for Wire ce.
	Revision History							Prepared by	Reviewed by	Approved by	Noted by
06/11/24	2	Inclusion of Car model "SUBARU-FORESTER", Measurement and Visual inspection/Quality checkpoints. Standardize term of SV tube (Vinyl).				D.Castillo C.Villanueva A. Arañes	N/A	\			
11/04/22	1	Improve i	notes/references and quality poi	nters in process no.1,2 and 3 as document improve	ment.	M. C. Catapang J. Loterte Villanueva	A. Arai	ies Jestivo	1/1-14		
07/08/22	0	Initial issu	ue. Excluded from WI-ENG-PDE			M. C. Catapang Villanueva A. Arañes	n/a	D. Castillo	C.Villanueva	A. Arades	N/A
Eff. Date	Rev. No			Details of Change		Revised Reviewed Approved	Note	d Est. Date:	July 08, 2022		


NBC (Philippines)
MASTER COPY

			Effectivity Date:	June 11. 202	June 11, 2024					
		WORK INSTRUCTION Process Name/Title: OFFLINE ASSEMBLY PROCESS					Validity Date: n/a			
		Model code/Part number:	ES1 / 7M0503-7020A			Car Model: SUBARU-FORESTER		WI-ENG-PDE-558		
		Purpose:	PROTOTYPE	PRE-LAUNCH	I	MASSPRO	Revision No.:	2	Page No.:	2 of 5
PARTS:	1. Conr 2. AVS	nector 7282-1026 (W)-((With clip clamp 82711-1E360 (W)) Sf 0.3 B wires L=884±3mm [2pcs.]				JIG:	n/a			
NO.	Р	ROCESS NAME	WORK P	PROCEDURE/	/ ILLUSTR	ATION	TOOLS/PPE	(	QUALITY POIN	ΓERS
2	Offline	Wire insertion to connector 7282-1026 (W)	Connector Orientation  1. Hold the connector 7282-1026 (W) the 1st Black wire and insert to termin of connector using right hand. Conduct push pull after wire insertion.  Note: Insertion must be from the bottop.	nal slot 1 t 2x	2. Hold the the 2nd Bla of connecto push pull af	Wire facing  2 Black  connector 7282-1026 (W) then get ack wire and insert to terminal slot or using right hand. Conduct 2x fiter wire insertion.	N/A	1. Please 2. Make : inserted. Conduct insertion. Do not e:  1. No wror 2. No wror 3. No dam 4. No wror 5. No loose 6. No wror 7. One by 8. No defo 9. No wror  Docume 1. Refer t Push proc	ag orientation of congues of connector aged connector age insertion of wires e insertion one insertion one insertion rmed terminal ag wire facing	ar terminal.  roperly  -Push after  nnector r s  029 for Pull-

NBC (Philippines)
MASTER COPY

			WORK INS	Effectivity Date:	June 11, 2024				
		Process Name/Title: OFFLINE ASSEMBLY PROCESS				Validity Date:			
	5	Model code/Part number:	ES1 / 7M0503-7020A	Customer: TRJ	stomer: TRJ Car Model: SUBARU-FORESTER		WI-ENG-PDE-558		
		Purpose:	PROTOTYPE	☐ PRE-LAUNCH	MASSPRO	Revision No.:	2	Page No.:	3 of 5
PARTS: 2	1. Assy 2. Black	parts s SV tube (Vinyl) ø5 L=798	±5mm			JIG:	1. Locking	jig	
NO.	F	ROCESS NAME	WORK F	PROCEDURE/ ILLUSTR	ATION	TOOLS/PPE	(	QUALITY POINT	ERS
3		Connector lock	Put the connector into locking jig using press 2x using both hands. Check by to connector lock if properly lock.	right hand then ouching the	BEFORE PRESSING  AFTER PRESSING	LOCKING JIG	1. M DAN 1. Use the	ortant reminders/No MANUAL LOCKING MAY MAGED CONNECTOR provided jig per co ck/half-locked conr	r CAUSE
4	Offline /2	Black SV tube (Vinyl) ø5 L=798±5mm	1. Get the SV tube (Vinyl) ø5 L=79t hand.	8±5mm using right hand. Ins	R sert the 2 Black wires using left	N/A	1. No wron	ng use of parts	

NBC (Philippines)
MASTER COPY





	WORK INSTRUCTION Process Name/Title: OFFLINE ASSEMBLY PROCESS					June 11, 2024 n/a		
	Model code/Part number: ES1 / 7M0503-7		Customer: TRJ Car Model: SUBARU-FORESTE		Document No.:	WI-ENG-PDE-558		
	Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:	2	Page No.:	5 of 5
1. Ass	sy parts	^			JIG:	n/a		
		√2 VI	SUAL INSPECTION/ QU	JALITY CHECKPOINTS	ı	<b>!</b>		
OFFL	INE INSEF	RTION		7M0503	- <mark>7020</mark> /	١		
				THE RESERVE THE PARTY OF THE PA			123	The same



**Connector** 

Unlocked/Halflocked

2 No Missing clip clamp

3 No Terminal Backing Out

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

NBC (Philippines)
MASTER COPY

**NO GOOD**