
NO. PROCESS NAME WORK PROCEDURE/ ILLUSTRATION TOOLS/PPE QUALITY POINTERS Safety Instruction Be sure to wear prescribed personal protective equipment during operation. (Green equipment dur					WORK INST	RUCTION			Effectivity Date:		June 3, 2024	
PATS: 1. Connector 6098-3802 (W); AVSST 0.3 B-V wire L=763a.5mm NO. PROCESS NAME WORK PROCEDURE/ ILLUSTRATION TOOLS/PPE UALITY POINTERS Safety Instruction for guilt swift house for guilt librarion lig // Connector 6098-3802 (W); AVSST 0.3 B-V wire L=763a.5mm TABLE LAY-OUT Black SY tube (Viryi) (Connector 1998-3802 (Viryi) (Con				Process Name/Title:	OFFLIN	E ASSEMBLY PRO	CESS		Validity Date:	## The stand of th		
PATS: 1. Connector 6098-3802 (W); AVSST 0.3 B-V wire L=763a.5mm NO. PROCESS NAME WORK PROCEDURE/ ILLUSTRATION TOOLS/PPE UALITY POINTERS Safety Instruction for guilt swift house for guilt librarion lig // Connector 6098-3802 (W); AVSST 0.3 B-V wire L=763a.5mm TABLE LAY-OUT Black SY tube (Viryi) (Connector 1998-3802 (Viryi) (Con				Model code/Part number:	00B / 7N0039-7020B	Document No.:	WI-ENG-PDE-882					
NO. PROCESS NAME WORK PROCEDURE/ ILLUSTRATION TOOLS/PPE QUALITY POINTERS TABLE LAY-OUT Black SV tube (Viry) (Connector 698-3802 (V), Connector 17 (Viry) (Connector 17 (Viry) (Connector 17 (Viry) (Connector 18 (Viry) (Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO		Revision No.:	1	Page No.:	1 of 7
TABLE LAY-OUT Black SV tube (Viny) (Connector Tray) (Connector T	PARTS:		1. Conr	ector 6098-3802 (W); AV	0.3 B-V wire L=763±3mm				JIG:			er
TABLE LAY-OUT Black SV tube (Vinyl) (a) (Connector 508-3302 (W) (Connector Tray Connector Tray AVSST 0.3 V L-76323mm AVSST 0.3 V L-76323mm Revision History A Marmandez C. Villanuses A Anales OR A Marmandez OR Villanuses A Anales OR A Marmandez OR Villanuses OR Villanuse OR Villanuses OR Villanus	NO.		Р	ROCESS NAME	WORK PI	ROCEDURE/ ILLUSTR	ATION		TOOLS/PPE	C	QUALITY POINT	ERS
06/03/24 1 Change pre-launch to mass pro. A.Hernandez C. Villanueva A. Arañes n/a Office C. Villanueva A. Arañes n/a A.Hernandez C. Villanueva A. Arañes n/a A.Hernan	TABLE LAY-OUT Black SV tube (Viny) (Connector 6098-3802 (W) (Connector Tray) Black SV tube (Viny) (Goves, finger cots, etc.) (Goves, finger cots, etc.) (Goves, finger cots, etc.) (For any trouble, inform the Assembly Assistant Supervisor or Line Leader for immediate corrective action.											's: 17 for
05/09/24 0 Initial issue. A.Hernandez C. Villanueva A. Arañes n/a A.Hernandez () C. Villanueva A. Arañes n/a					Revision History				Prepared by Re	eviewed by	Approved by	Noted by
05/09/24 0 Initial issue. A.Hernandez C. Villanueva A. Arañes n/a A.Hernandez () C. Villanueva A. Arañes n/a						-						
05/09/24 0 Initial issue. A.Hernandez C. Villanueva A. Arañes n/a A.Hernandez () C. Villanueva A. Arañes n/a												
05/09/24 0 Initial issue. A. Hernandez () C. Villanueva A. Arañes n/a A. Hernandez () C. Villanueva A. Arañes n/a				•			A.Hernandez C. Villanueva	a A. Arañes r	n/a Orman don	out) flow	4000	
Eff. Date Rev. No Details of Change Revised Reviewed Approved Noted Est. Date: May 09, 2024		-	Initial issu	ie.			A.Hernandez C. Villanueva	a A. Arañes r	n/a A.Hernandez () C.	Villanueva	/ A. Arabes	n/a
	Eff. Date Re	ev. No			Details of Change		Revised Reviewed	Approved No	oted Est. Date: May 09	9, 2024		






				WORK INST	Effectivity Date:		June 3, 2024	ı			
		Process Name/Title:		OFFLINI	Validity Date:		n/a				
		Model code/Part number:	700B /	7N0039-7020B	Customer: T	ſŖJ	Car Model: TOYOTA-LAND CRUISER	Document No.:		WI-ENG-PDE-8	382
		Purpose:	PROTOTYF	E [PRE-LAUNCH		MASSPRO	Revision No.:	1	Page No.:	3 of 7
PARTS:	1. AVS	Sf 0.3 B-V wire L=763±3mm						JIG:	1. Insertion	jig with switch cove	r
NO.	F	PROCESS NAME		WORK PR	TOOLS/PPE	(QUALITY POIN	TERS			
3	n/a	Wire insertion to insertion jig 6098-3802 (W)	1. Get the Violet to terminal slot (1) hand. 3. Get the Black we terminal slot (2) us	using right 2 Violet R		2. After insthumb and	r insertion of Violet wire press the using right hand. The slot for Black ill be opened. R Press Bertion, press the lock using left it then hold the wires and gently pull nnector from jig using right hand.		Important 1. Please 2. Make sinserted. Conduct insertion Do not e. Documer 1. Refer t Push pro 2. Refer t	g insertion one insertion rmed terminal g wire facing at reminders/Note e hold the wire ne sure wires are p Pull-Push-Pull-F exert extra force. on GL-PRO-ASY-	ear terminal. roperly Push after 029 for Pull- 017 for Wire

			WORK INSTR	Effectivity Date:		June 3, 202	4							
		Process Name/Title:			OFFLINE	ASSEME	3LY PRC	CESS	Validity Date:	n/a				
		Model code/Part number:	700B / 7N0039-7020B Customer: TRJ Car Model: TOYOTA-LAND CRUIS					Document No.:	WI-ENG-PDE-882					
		Purpose:		PROTOTYF	E [PRE-LAUNCH		MASSPRO	Revision No.:	1	Page No.:	4 of 7		
		<u> </u>							1		l			
PARTS:	1. Assy	parts							JIG:	1. Locking j				
NO.	F	PROCESS NAME			WORK PRO	OCEDURE	/ ILLUSTF	RATION	TOOLS/PPE	QUALITY POINTERS				
4	n/a	Connector lock	3. Press right hand	Right thu Left thus en press	Innector into the jig holding a connector, tip first. R Int thumb-Lower fit thumb-middle P parts of connector using fit hand holding the middle Imb-middle the connector in the and right hand.	de. 4	D. Press the land while learning the conneg	re lower part of connector to fully the locking jig. Right thumb-upper Left thumb-middle upper part of connector using right efft hand holding the middle. L Q nector is in locked condition by slide ector lock based on the sequence	LOCKING JIG	Importa 1. Manu damage 1. Use the connector.	After pressing GOOD Interminders/Normal locking may conditional locking may c	NG Half Lock He/s:		

					WORK INST	FRUCTION			Effectivity Date:		June 3, 2024	
		Process Name/Title:			OFFLIN	Validity Date:		n/a				
		Model code/Part number:	700B	1	7N0039-7020B	Customer	: TRJ	Car Model: TOYOTA-LAND CRUISER	Document No.:		WI-ENG-PDE-8	882
		Purpose:		PROTOTY	PE	PRE-LAUN	СН	MASSPRO	Revision No.:	1	Page No.:	5 of 7
PARTS:	1. Assy 2. Black	v parts k SV tube (Vinyl) ø5 L=193	±3mm						JIG:	n/a		
NO.	P	PROCESS NAME			WORK P	ROCEDUR	E/ ILLUSTF	RATION	TOOLS/PPE	(QUALITY POIN	TERS
5	n/a	Wire insertion to Black SV tube (Vinyl) ø5 L=193±3mm	usin	Black SV t g right han using left	ube (Vinyl) ø5 L=193±3 d then insert Black and	R Samm Violet			n/a	1. No wron 2. No defoi	g use of parts rmed terminal	



Process Name/Title: OFFLINE ASSEMBLY PROCESS Validity Date: n/a Model code/Part number: 700B / 7N0039-7020B Customer: TRJ Car Model: TOYOTA-LAND CRUISER Document No.: WI-ENG-PDE-8 Purpose: PROTOTYPE PRE-LAUNCH MASSPRO Revision No.: 1 Page No.:	00
	82
	7 of 7
PARTS: n/a JIG: n/a	
VISUAL INSPECTION/QUALITY CHECKPOINTS	
OFFLINE INSERTION 7N0039-7020B	
1 No Unlock connector 2 No Wrong insert 1 No Deformed terminal	OD