
			WORK INSTRUCTION									ivity Date:		January 26, 2024		
		H	Process Name/Title: TAPING ASSEMBLY PROCESS								Validit	ty Date:		n/a		
			Model code/Part number:	700B / 7N0037-7020B Customer: TRJ Car Model: TOYOTA LAND CRUI					AND CRUISER	R Document No.:			WI-ENG-PD-758C			
	<u></u>		Purpose:	□PF	OTOTYPE	[PRE-LAUNCH	MASS	PRO		Revisi	ion No.:		1	Page No.:	1 of 5
PARTS: 1. Assy Parts 2. Black Tape											JIG:	n/	n/a			
NO.	IO. PROCESS NAME			MORK PROCEDURE/ ILLUSTRATION						TOOLS/PPE		C	UALITY POIN	TERS		
1		P3	Tayble Lay-out			Pro-	Black ta with Tal Holde	pe	sy Parts		pr prc (g	Be sure to wearescribed person otective equipm during operation gloves, finger coetc.) Housekeeping Maintain and alway practice 5's. Personal things the workplace is ohibited. Keep in your locker. Alert level or any trouble, in Assembly Assi Supervisor or Lineader for immed corrective action.	r nal inent in nal inent in nal inent in nal inent in nal inent in		ng parts/tools ss parts/tools	
						Revision History						Prepared by	Revie	wed by	Approved by	Noted by
01/26/24	1 0	Changed purpose from are loungh to make are Additional of table law and an Additional of table law and a second surface and a second su										Mohnely	Mount	2 ifform	. Carrie	
							M. Ariola M. Ariola	C.Villanueva C.Villanueva		n/a Arañes	M. Ariola	4/1			2/2	
12/13/23 0 Initial issue. M. Ariola C. Villanueva A. Arañes M. Lydola 'C. Villanueva 'A. Arañes Eff. Date Rev. No Details of Change Revised Revised Reviewed Approved Noted Est. Date: December 13, 2023										n/a						





				WORK INSTRUC	Effectivity Date:	January 26, 2024				
		Process Name/Title:	TAPING ASSEMBLY PROCESS				Validity Date:	n/a		
		Model code/Part number:	700B /	7N0037-7020B Cu	ıstomer: TRJ	Car Model: TOYOTA LAND CRUISER	Document No.:		WI-ENG-PD-758	BC .
		Purpose:	PROTOTYPE	PR	E-LAUNCH	MASSPRO	Revision No.:	1	Page No.:	3 of 5
PARTS: 1. Assy Parts 2. Black tape										
		•		1 WORK PROCE	EDURE/ ILLUSTR		OUALITY POINTERS			
NO.	ŀ	PROCESS NAME		TOOLS/PPE	QUALITY POINTERS					
NO. 3	P3	Taping 2 Black corrugated tube to Black SV tube (Vinyl) near connector	Start of tapin	39 ±3mm 7N0099-7020A	Important reminders/Note/s: 1. Please use calibrated/verified measuring tape when getting the measurement. 1. No flip-out tape 2. No peel-off tape 3. No loose tape 4. No missing tape 5. No wrong use of tape 6. No wrong dimension					
			8 9	39 ±3mm 7N0099-7020A	4. Measure from en pointed tip 39±3mm	nd of COT up to terminal using both hands.				

