





			WORKI	Effectivity Date:	October 24, 2024 n/a WI-ENG-PDE-1062					
		Process Name/Title:	CLA	Validity Date:						
		Model code/Part number:						Document No.:		
		Purpose:	☐ PROTOTYPE	PRE-LAUNCH	MASSPI	RO	Revision No.:	1	Page No.:	4 of 6
PARTS:	1. Assy	parts	Clamp assembly jig							
NO.	F	PROCESS NAME	<u>∕</u> 1 wor	K PROCEDURE/ ILLUST	TRATION		TOOLS/PPE	QUALITY POINTERS		
3	Clamp Assy		3. On clamp location 2, hold the tap of tape then cut the tape using both button after taping. Continue the p light on location 4 was ON. 5. On clamp location 4, hold the tap of tape then cut the tape using both button after taping. Continue the p light on location 4 was ON. 5. On clamp location 4, hold the tap of tape then cut the tape using both button after taping. Continue the p light on location 5 was ON.	te then make 3 windings hands. Press the SW rocess if the sequence be then make 3 windings in hands. Press the SW rocess if the sequence be then make 3 windings in hands. Press the SW rocess if the sequence be then make 3 windings in hands. Press the SW	6. On clamp of tape their button after button after button after 8. After tap	82711-48210 (B) 5 6 6 location 5, hold the tape of cut the tape using both her taping. Continue the properties of the tape using both her taping. GO sound will be the taping. GONDUCT POINT Come harness from jig.	e then make 3 windings hands. Press the SW	Important Support In Must I and Stop 2. Make	ant reminders/ be no gap betweedper jig. CLAMP ILLUSTRATIC	/Note/s: In terminal

			WORK INS	Effectivity Date:	October 24, 2024					
		Process Name/Title:	Validity Date: n/a		n/a					
		Model code/Part number:	310D / 7N0199-7020B	CLAMP ASSEMBLY PROCESS Va 310D / 7N0199-7020B Customer: TRJ Car Model: TOYOTA-RAV4 Do		Document No.:	WI-ENG-PDE-1062			
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPI	RO	Revision No.:	1	Page No.:	5 of 6
PARTS:	n/a							n/a		
NO.	P	ROCESS NAME	∕₁ work	TOOLS/PPE	QUALITY POINTERS					
4	Clamp	Measurement	(A) 225±2 (B) 131±3 (C) 40±2 (C) 20±3 (C) 1 Taping (B) (C) - Clamp (B) (C) - Clamp (W) (D) - Clamp (W) (E) - Dimension of overlapped Sunprene and COT		↑ R	\$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$	(k) 102±5 (l) 102±5 (l) 0 *5 (l)	Import 1. Pleas measur measur 2. For I- Owarim Docum 1. Refe Assy I-	Hatsumono, Nakan	rerified ting the nono and e/s:

				Effectivity Date:	October 24, 2024							
			Process Name/Title:	CLAN	Validity Date:		n/a					
			Model code/Part number:	310D / 7N0199-7020B	Customer	: TRJ	Car Model:	TOYOTA-RAV4	Document No.:		WI-ENG-PDE-1	062
			Purpose:	PROTOTYPE	PRE-LAUN	СН	MASSPE	RO	Revision No.:	1	Page No.:	6 of 6
Ξ	1									ı		
Р	ARTS:	n/a							JIG:	n/a		

CLAMP ASSY

7N0199-7020B



1 No Wrong Facing of Clamp



CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.