

Layout partition board
Put the products
(9pcs*4bundles)
on the 2nd layer

4





2nd Layer



Bend the MR SW wire from the end of tape.

Put the 1 bundle in vinyl bag together with CSW and bended MR switch part.



| | 1 | | |
|---|---|--|--|
| Fold the vinyl sheet. | | The state of the s | |
| Put NBP Identification tag at the top.Then put the warehouse Identification | L | The state of the s | |



NOTE: If with 4M tag, put it at the left side of the box.

| | | • | | | | | Prepared by | Reviewed by | Approved by | Noted by |
|-----------|----------|--|-------------|--------------|-------------|----------|----------------|-------------|------------------|----------|
| 03/20/25 | 1 | Change control no. from WI-ENG-PDE-829 to WI-QAD-QAC-321 Add note & illustration for bending for MR switch wire | S.Malabuyoc | D.Dadulla | R. Pascua | n/a | | Ollins | ML | |
| 02/06/24 | 0 | Initial Issuance | | C.Villanueva | A. Arañes | | S) Malabuybc | D.Dadulla | R. Pascua | n/a |
| Eff. Date | Rev. No. | Details of change | Prepared by | Reviewed by | Approved by | Noted by | Establish Date | | February 06, 202 | 24 |

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

tag at lower right side of the box.

NBC (Philippines)

MASTER COPY