

PACKING INSTRUCTION

Document No:

Effective Date:

WI-QAD-QAC-073

July 2, 2024

WORK INSTRUCTION
Product Code/Name: Cus
7N0002

Customer Code: TRMX

Rev. No.:

3

Page No.:

Page 1 of 1

No.		Work Procedure/ Illustration			Records/Remarks/ Quality Pointers		
1)	Put Vinyl Sheet (1250 x 1250) inside TRMX box.	√3\		Qty/ Box Mat'l name	700 pcs	25pcs* 28bdls Qty	
		Put Vinyl Sheet		TRMX box	544*370* 228	1	
			Sheet	mm 1250*1250	1		
			11/1/12/15	Partition Board	343*510	1	
				Plastic Vinyl Bag	300*200mm	28	
2	Put 16 bdls of products. (25pcs/bdl) in opposite direction.			Note: 1. For CSW use Oricon box instead of DC box. 2. Step number 5 is applicable only in QC FG Inspection.			
3	ī	Put partition board					
4	Put 12bdls of products. (25pcs/bdl) in opposite direction.						
(5)	Fold the vinyl sheet. Put NBP Identification tag at the top and tape the flaps (two side and top portion). Then Warehouse Identification tag at the right side of the box.		Note: If need to attach 4M tag Put 4M tag at the left side				
				Prepare	Check	Approve	
07/02/2024	3	Change vinly shee	y size from 1520 x 1500 to 1250 x 1250mm S. Malabuyoc R. Pascua O. Merin		1 /		
02/15/2022	Change size of v 2 Change qua		on from 610*381*178 mm to 544*370*228 mm inyl bag from 420*280 mm to 300 * 200 mm ntity per bundle from 14 pcs to 25 pcs M. Garcia R. Alcantara A. Arañes	Cmardeyu	M/	1	
11/15/2018 Eff./Rev. Date	0 Rev. No.		Initial Issue C. Dimailig M.Lumbres E. Mendoza Details of change Revise Check Approve	S. Malabuyoc Est. date	R. Pascua 11/15/	Ø. Merin 2018	