

Process Name/ Title: **PACKING INSTRUCTION**

Document No:

WI-QAD-QAC-175

WORK INSTRUCTION Product Code/Name:

Customer Code:

Effective Date: April 16, 2024

	BU	Product Code/Name: 75N731	Customer Code: TRJ	Rev. No.:	2	Page No	.: Pag	e 1 of 1
No.			Records/Remarks/ Quality Pointers					
			7			Qty/box Mat'l name	400 Dim.	100pcs *4bdls Qty.
2						Partition board	343*510	3
1	Prepare empty oricon box in the "after inspection area"					Vinyl bag	545*450	4
2	Get the vinyl (plastic) bag then put the 100 pcs harness. Insert products in same direction. Put the ID tag inside then fold the plastic bag.		in the second se					
3	Put products on vertical position and partition board vertically & alternately with the products. (100pcs* 4 Bundles with I.D tag inside)					White connectors must be on top position.		
<u></u>	Put NBP Identification tag		Note: If	need to attack	h 4M			



Put NBP Identification tag at the top.Then warehouse Identification tag at lower right side of the box





Note: If need to attach 4M tag. Put 4M tag at the left side of the box

						Prepared	Checked	Approved
								. /
4/16/2024	2	Remove Vinyl Sheet	M. Garcia	D.Dadulla	R.Pascua			1. /
8/24/2022	1	Update product orientation to vertical position	M. Garcia	R. Alcantara	A. Arañes	mensfith	Mua	MH
7/20/2020	0	Initial issue	C.Dimailig	M.Lumbres	E. Mendoza	M. Garcia	D.Dadulla	R.Pascua
Eff. Date	Rev. No.	Details of change	Prepared	Checked	Approved	Establish Da	te: July 20, 2	020

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

NBC (Philippines) **MASTER COPY**