				WORK INS	Effectivity Date:	June 6, 2024					
			Process Name/Title:	CLAM	P ASSEMBLY PRO	CESS		Validity Date:		n/a	
		5	Model code/Part number:	310B / 7M0523-7020B	Customer: TRJ	Car Model:	TOYOTA RAV	Document No.:		WI-ENG-PDE-8	53
			Purpose:	PROTOTYPE	PRE-LAUNCH	MASSP	RO	Revision No.:	0	Page No.:	1 of 5
PARTS:		1. Assy parts; Clamp 82711-4807		70 (GR); Clamp 82711-52090 (W); Clamp 8	JIG:	, , ,					
N	0.	P	ROCESS NAME	WORK P	TOOLS/PPE	(	QUALITY POINTERS				
1		Clamp Assy	Table Lay-out	Clamp 82711-48070 (GR)/Clamp Tray  Clamp 82711-34490 (B) / Clamp Tray  Bando Gun  Tape Holder/Pink tap		BART SELECTION OF THE PROPERTY	Assembly jig	Safety Instruction Be sure to wear prescribed personal protective equipment during operation (gloves, finger cots, etc.)  Housekeeping 1. Maintain and always practice 5's. 2. Personal things on the workplace is prohibited. Keep it in your locker.  Alert level For any trouble, inform the Assembly Assistant Supervisor or Line Leader for immediate corrective action.	1. Refer Assemi	ment references r to WI-ENG-PDE- bly Process ng parts/tools ss parts/tools	
				Revision History				Prepared by F	Reviewed by	Approved by	Noted by
									./ /	Alax	
06/06/24	0 1	Initial issu	e.			D. Castillo	C. Villanueva A. Arañes	n/a Castillo C.	/out/)/for-	A. Arañes	n/a
Eff. Date	Rev. No			Details of Change		Revised	Reviewed Approved	Noted Est. Date: June	6, 2024		

			WORK INS	STRUCTION			Effectivity Date:		June 6, 2024		
		Process Name/Title:	CLAN	Validity Date:	n/a						
		Model code/Part number:	310B / 7M0523-7020B	Customer: TRJ	Car Model:	<b>TOYOTA RAV4</b>	Document No.:		WI-ENG-PDE-85	53	
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPI	RO	Revision No.:	0	Page No.:	2 of 5	
PARTS:	2. Clan	p 82711-34490 (B) p 82711-48070 (GR) p 82711-52090 (W)		4. Black tape 5. Pink tape			JIG:	1. Clamp A	ssembly Jig		
NO.	PROCESS NAME		WORK	TOOLS/PPE	QUALITY POINTERS						
2	Clamp	Clamp Setting	82711-34490  1. Get the clamp 82711-34490 using ① using both hands.  2. Get the clamp 82711-48070 using using both hands.		Color Sensor  Light  location	82711-52  3  3  4. Get the Pink tape and incation ② using both har	nitially attach tape to	1. No wron 2. No wron 3. No dam 4. No miss	STANDARD TAPING FOR CLAMP  One wind for under clamp  o wrong use of tape o wrong clamp position o damaged clamp o missing clamp  mportant reminders/Note/s:  Please check the Clamp first before lart of assembly to avoid wrong use of		
			3. Get the clamp 82711-52090 using r 3 using both hands.	right hand and set to clamp		5. Get the <b>Black tape</b> and ocation ③ using both har					

			WORK INS	Effectivity Date:	June 6, 2024						
		Process Name/Title:	CLAM	IP ASSEMBLY PRO	OCESS		Validity Date:		n/a		
		Model code/Part number:	310B / 7M0523-7020B	Customer: TRJ	Car Model:	TOYOTA RAV4	Document No.:		WI-ENG-PDE-8	53	
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPR	0	Revision No.:	0	Page No.:	3 of 5	
PARTS:	1. Assy parts						JIG:	1. Clamp Assembly Jig			
NO.	P	ROCESS NAME	AME WORK PROCEDURE/ ILLUSTRATION				TOOLS/PPE	QUALITY POINTERS			
3	Clamp Assy	Clamp Assembly	2. Check if all LED light for POWER ON and CLAMP was ON. Check also if clar sequence light is ON. If encountered al immediately CALL the attention of the kinstruction then continue the process.  3. Initially tighten the band clamp on loc hand.  4. Get the bando gun and cut the band (82711-34490) using right hand. Press sequence light to display the process.  5. Hold the tape on clamp location ② at aping (3 windings) using both hands. Fequence light button after cutting. Con location ② if light was on.	Sequence light  above picture for to Receiver base. not together within the Continue if the  N, WIRE1 and WIRE2 mp location ① bnormality, STOP and eader. WAIT for further cation ① using right  clamp the ntinue to band clar cutter degon the size the COTA tube.	and start taping both hands. Pres button after tapin heard.  7. CONDUCT Pour before removing  Must be perpendicular  BAN NG  pends be of Vinyl  1-2,	Stopper  On clamp location (3) (3) windings) using so the sequence light eg. GO buzzer will be DINT CHECKING from jig.  DO GUN ALIGNMENT  PERPENDICULARITY	Bando Gun	Import  1. Must and stop  2. Make	I-off tape se tape sing tape ng dimension t/loose clamp attact  tant reminders/libe no gap between per jig.  2-3 windings for cl.  BANDO GUN ILLUSTRA	Note/s: In terminal	

			WORK INS	TRUCTION	Effectivity Date:	June 6, 2024			
		Process Name/Title:	CLAMI	P ASSEMBLY PRO	CESS	Validity Date:		n/a	
		Model code/Part number:	310B / 7M0523-7020B	Customer: TRJ	Car Model: TOYOTA RAV4	Document No.:		WI-ENG-PDE-853	
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:	0	Page No.: 4 of 5	
PARTS:	1. Assy parts					JIG:	n/a		
NO.	P	ROCESS NAME	WORK P	ROCEDURE/ ILLUST	TOOLS/PPE	(	QUALITY POINTERS		
4	Clamp Assy	Measurement	(4) 216 ±3 (3) 131 ±3 (2) 31 ±3 (3) 120 ±5 (3) 10 ±2 (4) 216 ±3 (5) 20 ±5 (5) 20 ±5 (6) 20 ±5 (6) 20 ±5 (7) 20 ±5 (8) 20 ±5 (9) 20 ±5 (9) 20 ±5 (1) 20 ±5 (1) 20 ±5 (2) 20 ±5 (3) 20 ±5 (4) 20 ±5 (5) 20 ±5 (6) 20 ±5 (7) 20 ±5 (8) 20 ±5 (9) 20 ±5 (9) 20 ±5 (1) 20 ±5 (1) 20 ±5 (2) 20 ±5 (2) 20 ±5 (3) 20 ±5 (4) 20 ±5 (5) 20 ±5 (5) 20 ±5 (6) 20 ±5 (6) 20 ±5 (7) 20 ±5 (8) 20 ±5 (8) 20 ±5 (9	Q	6789	141 ±3   9 0 0   White   Whi	1. Please measurin measurer 2. For Ha Owarimo.  Docume 1. Refer to assembly Owarimor	atsumono, Nakamono and	

		WORK INSTRUCTION						Effectivity Date:	!		
		Process Name/Title:	ocess Name/Title: CLAMP ASSEMBLY PROCESS						n/a		
		Model code/Part number:	310B / 7M0523-7020I	3	Customer: TRJ	Car Model:	TOYOTA RAV4	Document No.:		WI-ENG-PDE-8	353
		Purpose:	PROTOTYPE		PRE-LAUNCH	MASSPF	RO	Revision No.:	0	Page No.:	5 of 5
	ı								ı		
PARTS: 1. Ass		/ parts						JIG:	n/a		

**VISUAL INSPECTION/ QUALITY CHECKPOINTS** 

**CLAMP ASSY** 

## 7M0523-7020B



(1)

**No Wrong Facing of Clamp** 

(2)

No Missing Tape (Black Tape)

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.