

					NSTRUCTION			Effectivity Date:		October 09, 20	024
			Process Name/Title:		INE ASSEMBLY P			Validity Date:		n/a	
		7	Model code/Part number:	920B / 7R0115-7021A	Customer: TRM	X Car Model: TOYOTA-	-TACOMA	Document No.:		WI-ENG-PDE-6	375
			Purpose:	PROTOTYPE	PRE-LAUNCH	■ MASSPRO		Revision No.:	1	Page No.:	1 of 8
PARTS:		1. Conne 12B10 (V		0.3 wires Y-OR L=338±2mm; Black SV Tu	be (Vinyl) Ø7 L=267±3mm; Co	onnector 6098-6653 (W); Clip clar	mp 82711-	JIG:		n jig with contoller n jig with Switch co jig	over
NC).	P	ROCESS NAME	WORI	K PROCEDURE/ ILLUS	STRATION		TOOLS/PPE	(QUALITY POIN	ITERS
1		Offline	Table lay-out	Connector 6098-6653 (W)/ Connector tray	AVSSf 0.3 wires L=338±2mm AVSSf 0.3 wire OR L=338±2mm	7189-09 =267±3mm Connec		Safety Instruction Be sure to wear prescribed persona protective equipme during operation (gloves, finger cots etc.) Housekeeping 1. Maintain and alwa practice 5's. 2. Personal things of the workplace is prohibited. Keep it i your locker. Alert level For any trouble, info the Assembly Assista Supervisor or Line Leader for immedia corrective action.	Importa I. Canno connect 2. Refer and Stri and 1. No missi 2. No excess Importa 1. Canno connect 2. Refer and Stri and stri and	ant reminders/ ot insert the inve- or. to WI-PRO-CNC- p Length Toleran ng parts/tools ss parts/tools	rted 017 for Wire
				Revision History	y			Prepared by	Reviewed by	Approved by	Noted by
10/09/24	0	Inclusion of		A" and Measurement. Improved Visual inspec	tion/Quality checkpoints.		Arañes N/ Villanueva A. Ara	- (eus)	South form	A. Atanes	n/a
Eff. Date R	Rev. No			Details of Change		Revised Reviewed A	Approved Not	ed Est. Date:	May 19, 2023		

MASTER COPY




			WORK INS	TRUCTION		Effectivity Date:		October 09, 202	24
		Process Name/Title:	OFFLIN	IE ASSEMBLY PROC		Validity Date:		n/a	
		Model code/Part number:	920B / 7R0115-7021A	Customer: TRMX	Car Model: TOYOTA-TACOMA	Document No.:		WI-ENG-PDE-6	75
		Purpose:	☐ PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:	1	Page No.:	3 of 8
PARTS:		Sf 0.3 wires Y L=338±2mm Sf 0.3 wires OR L=338±2mm				JIG:	1. Insertion	njig with switch cove	er
NO.	F	PROCESS NAME	WORK P	ROCEDURE/ ILLUSTRA	TION	TOOLS/PPE	(QUALITY POIN	TERS
3	Offline	Wire insertion to Connector 6098-6653 (W)	1. Get the Yellow wire using right hand then insert to terminal slot 1 using right hand. 2 Orange wire R 3. Get the Orange wire using right hand insert to terminal slot 2 using right hand.	then thumb and ther	2. Press the button using left hand, the slot for Orange wire will be opened. Press In, press the lock guide using left in hold the wires and gently pull out rom jig using right hand.	n/a	4. No defonds 5. No wrong Import 1. Pleastermina 2. Make inserted Conduct insertio Do not of	g insertion ne insertion med terminal g wire facing ant reminders/ e hold the wire no sure wires are p t t Pull-Push-Pull-I	ear roperly Push after ∵



				WORK INS			Effectivity Date:		October 09, 2024	4
		Process Name/Title:			NE ASSEMBLY F		Validity Date:		n/a	
		Model code/Part number:	920B / 7F	0115-7021A	Customer: TRI	MX Car Model: TOYOTA-TACOMA	Document No.:		WI-ENG-PDE-67	'5
		Purpose:	☐ PROTOTYPE		☐ PRE-LAUNCH	■ MASSPRO	Revision No.:	1	Page No.:	5 of 8
PARTS:	1. Assy 2. Black	parts SV Tube (Vinyl) Ø7 L=267±3	mm		3. Connector 7189	0995 (W)	JIG:	1. Inertion ji	ig with controller	
NO.	Р	ROCESS NAME		WORK P	ROCEDURE/ ILLU	STRATION	TOOLS/PPE	(QUALITY POINT	ERS
6		Wire insertion to Black SV Tube (Vinyl) Ø7 L=267±3mm	L		using	the SV tube (Vinyl) Ø7 L=267±3mm right hand then insert the Y-OR wire eft hand.	n/a		g use of parts med terminal	
7	Offline	Connector setting to insertion jig 7189-0995 (W)	Button Connector Orientation	Visual reference Slider Guide	Adju	Reset 1. Slide the slide lock using right thumb. Hole Rollease 3. Push the guide using left	n/a	1. Canno connect 1. Use prov 2. No wrong 3. No wrong	ant reminders/Not insert the invertor. ided jig per model gusage of parts gorientation of conneged connector	ed

				STRUCTION		Effectivity Date:		October 09, 202	24
		Process Name/Title:	OFFL	INE ASSEMBLY PRO	CESS	Validity Date:		n/a	
		Model code/Part number:	920B / 7R0115-7021A	Customer: TRMX	Car Model: TOYOTA-TACOMA	Document No.:		WI-ENG-PDE-6	75
		Purpose:	☐ PROTOTYPE	☐ PRE-LAUNCH	MASSPRO	Revision No.:	1	Page No.:	6 of 8
PARTS:	1. Assy	·				JIG:	· ·	ig with controller	
NO.	F	PROCESS NAME	WORK	PROCEDURE/ ILLUSTR	ATION	TOOLS/PPE	(QUALITY POIN	TERS
8	Offline	Wire insertion to connector 7189-0995 (W)	u tr h a o o iji	Push Button 2. Press the button using left hand. The slot for Orange wire will be opened. Slide the lock sing right numb and then old the wires nd gently pull ut the onnector from g using left and.		n/a	4. No defonds. 5. No wrong. Import. 1. Pleastermina. 2. Make inserted conductions of the conduction of	g insertion one insertion med terminal g wire facing ant reminders/ e hold the wire no l. sure wires are pr t. t Pull-Push-Pull-f n. exert extra force. tion jig will alarm t Pull-Push-Pull-f tion jig will alarm I not insert before	ear roperly Push after if will not ush if Yellow 5 ires after from jig. e done one wires 229 for 017 for



WORK INSTRUCTION Effectivity Date: October 09, 2024 OFFLINE ASSEMBLY PROCESS Validity Date: n/a Model code/Part number: 920B / 7R0115-7021A Customer: TRMX Car Model: TOYOTA-TACOMA Document No.: W-ENG-PDE-675 Purpose: PROTOTYPE PRE-LAUNCH MASSPRO Revision No.: 1 Page No.: 8 of 8 PARTS: 1. Assy parts JIG: n/a VISUAL INSPECTION/ QUALITY CHECKPOINTS TROUBLE TROUBLE
Model code/Part number: 920B / 7R0115-7021A Customer: TRMX Car Model: TOYOTA-TACOMA Document No.: WI-ENG-PDE-675
PARTS: 1. Assy parts OFFLINE INSERTION OFFLINE INSERTION OFFLINE OF
PARTS: 1. Assy parts OFFLINE INSERTION 7R0115-7021A 2 3 Y OR
OFFLINE INSERTION 7R0115-7021A 3 YEAR OFFLINE INSERTION
OFFLINE INSERTION 7R0115-7021A 3 YEAR OFFLINE INSERTION
OFFLINE INSERTION 7R0115-7021A 3 Y OR
OFFLINE INSERTION 7R0115-7021A 3 Y OR
3 Y X OR
3 Y X OR
6 OR V
OR V
(6) OR V
OR Y
1 No Unlock/Half-locked Connector 4 No Deformed terminal 6 No Missing
1 No Unlock/Half-locked Connector 4 No Deformed terminal 6 No Missing
Clin clown
(2) (3) No Wrong Insert (5) No Terminal Backing Out Clip clamp
Clin clown